

Volume Conversion Device EK280

Operating Instructions

Exclusion of liability

The information contained in this document is the property of Honeywell. The following information may only be used for its intended purpose. This document or its contents must not be copied, published or made accessible to a third party in full or in part without the express consent of Elster GmbH.

All specifications and descriptions in these operating instructions have been compiled following careful testing. In spite of this, errors cannot be completely ruled out. Honeywell can therefore not provide any guarantee that the content is complete or correct. The instructions must also not be seen as a warranty of product features. Furthermore, features are also described here which are only available as an option.

Honeywell cannot accept liability in any case for direct, special or consequential damage suffered by third parties. The information and specifications in this document may be amended without notice.

In view of extended product liability, the listed data and material properties should only be regarded as reference values and must always be checked for each individual case and corrected if necessary. This is especially the case when safety aspects are affected.

Further support is available from your local branch office or agent. The address is available on the Internet or from Honeywell.

This manual or parts of it may only be disclosed or copied with written consent from Honeywell.

If the product described here is improperly handled, repaired or changed by unauthorized persons or if spare parts other than those supplied by Honeywell are used, our warranty will be rendered void.

All rights reserved.

Copyright © 2019 Elster GmbH, D-55252 Mainz-Kastel. All rights reserved.

Mainz-Kastel, January 2019

Contents

| | | |
|----------|---|-----------|
| 1 | General | 7 |
| 1.1 | Information about this manual | 7 |
| 1.2 | Warranty provisions | 7 |
| 1.3 | Customer service and and Technical Support (TAC) | 7 |
| 1.3.1 | Customer service and repairs | 8 |
| 1.3.2 | Technical Assistance Center (TAC) | 8 |
| 1.4 | Meaning of symbols | 8 |
| 1.4.1 | Safety information | 8 |
| 1.4.2 | Tips and recommendations | 9 |
| 1.5 | Limitation of liability | 9 |
| 1.6 | Copyright protection | 10 |
| 1.7 | Scope of delivery | 10 |
| 1.8 | Spare parts and accessories | 10 |
| 1.9 | Storage | 11 |
| 2 | Safety | 12 |
| 2.1 | General | 12 |
| 2.2 | Intended use | 15 |
| 2.3 | Personnel | 16 |
| 2.4 | Personal protective equipment | 17 |
| 2.5 | Specific risks | 18 |
| 2.6 | Environmental protection | 19 |
| 2.7 | Operator's responsibility | 19 |
| 3 | Technical data | 20 |
| 3.1 | General data | 20 |
| 3.1.1 | Dimensions | 21 |
| 3.2 | Power supply for EK280 without integrated power supply unit | 22 |
| 3.2.1 | Battery power supply for the basic device | 22 |
| 3.2.2 | Battery power supply for the integrated modem | 22 |
| 3.2.3 | External power supply for the basic device | 22 |
| 3.3 | Power supply for EK280 with integrated power supply unit | 23 |
| 3.3.1 | Battery power supply for the basic device | 23 |
| 3.3.2 | External power supply | 23 |
| 3.3.3 | Buffer batteries for the integrated modem | 23 |
| 3.4 | Power supply for the EK280 with Power over Ethernet (PoE) | 23 |
| 3.5 | Pressure sensor | 24 |
| 3.5.1 | CT30 Type Pressure Sensor | 24 |
| 3.5.2 | Pressure Sensor Type 17002 | 25 |
| 3.6 | Temperature sensor | 25 |
| 3.7 | Digital inputs | 25 |
| 3.7.1 | LF pulse and signal inputs | 25 |
| 3.7.2 | HF pulse inputs (high frequency) | 26 |
| 3.7.3 | Encoder input | 26 |

| | | |
|----------|--|-----------|
| 3.8 | Digital outputs | 27 |
| 3.8.1 | Nominal data | 27 |
| 3.8.2 | LF pulse or signal outputs | 27 |
| 3.8.3 | HF pulse outputs | 27 |
| 3.9 | Interfaces | 28 |
| 3.9.1 | Serial optical interface | 28 |
| 3.9.2 | Serial electrical interface | 28 |
| 3.9.3 | Integrated modem | 28 |
| 3.9.4 | Ethernet adapter | 29 |
| 3.10 | Measurement conditions | 29 |
| 3.10.1 | Environment | 29 |
| 3.11 | Labelling | 29 |
| 3.11.1 | Type label of the volume corrector | 29 |
| 3.11.2 | ATEX marking | 30 |
| 3.11.3 | Device software identification | 31 |
| 4 | Construction and Function | 32 |
| 4.1 | External view | 32 |
| 4.2 | Internal view | 32 |
| 4.3 | Short description | 33 |
| 4.4 | Connections | 33 |
| 5 | Assembly, Connection and Putting into Operation | 34 |
| 5.1 | Assembly | 34 |
| 5.1.1 | Assembly on a gas meter | 35 |
| 5.1.2 | Assembly on a pipeline | 35 |
| 5.1.3 | Assembly on a wall | 36 |
| 5.1.4 | Three-way valve | 36 |
| 5.2 | Connection | 37 |
| 5.2.1 | Connecting the gas meter | 38 |
| 5.2.2 | Sealing the input terminals | 40 |
| 5.2.3 | Connecting the temperature sensor | 40 |
| 5.2.4 | Connecting the pressure pipe | 42 |
| 5.2.5 | Connecting the power supply | 43 |
| 5.2.6 | Connect outputs of the EK280 | 45 |
| 5.2.7 | Earthing the EK280 housing | 46 |
| 5.2.8 | Earthing the cable connections of the EK280 | 47 |
| 5.2.9 | Additional measures for installation in zone 2 | 47 |
| 5.3 | Putting into operation | 48 |
| 5.3.1 | Configuration of measurement parameters | 48 |
| 5.3.2 | Sealing | 59 |
| 5.3.3 | Closing the housing | 60 |
| 5.3.4 | Verifying assembly and connection | 61 |
| 5.3.5 | Programming a data transfer | 61 |
| 6 | Operation | 62 |
| 6.1 | Safety | 62 |
| 6.1.1 | Personal protective equipment | 62 |

| | | |
|----------|--|-----------|
| 6.2 | Operating personnel | 62 |
| 6.2.1 | Instructed personnel | 62 |
| 6.2.2 | Qualified personnel | 62 |
| 6.2.3 | Calibration officers | 63 |
| 6.3 | Basic principles | 63 |
| 6.3.1 | Display | 64 |
| 6.3.2 | Button functions | 65 |
| 6.3.3 | Data recall, display navigation | 66 |
| 6.3.4 | Meaning of status symbols | 67 |
| 6.3.5 | Error messages when entering values | 68 |
| 6.3.6 | Access rights | 69 |
| 6.4 | Data register content | 72 |
| 6.4.1 | Access rights | 72 |
| 6.4.2 | "Main" register (main display) | 72 |
| 6.4.3 | "Cust." register (Customer) | 74 |
| 6.4.4 | "Admin" register (Administrator) | 76 |
| 6.4.5 | "Serv." register (service) | 77 |
| 6.4.6 | "Ctrl." register (Control) | 78 |
| 7 | Maintenance | 80 |
| 7.1 | Safety | 80 |
| 7.1.1 | Personnel | 82 |
| 7.1.2 | Personal protective equipment | 82 |
| 7.1.3 | Environmental protection | 82 |
| 7.2 | Testing and changing device batteries | 83 |
| 7.2.1 | Changing and connecting device batteries | 83 |
| 7.2.2 | Entering the battery capacity | 85 |
| 7.2.3 | Display remaining battery power | 86 |
| 8 | Faults | 87 |
| 8.1 | Safety | 87 |
| 8.1.1 | Personnel | 88 |
| 8.1.2 | Personal protective equipment | 88 |
| 8.1.3 | Improper elimination of faults | 88 |
| 8.1.4 | Behaviour in the event of faults | 89 |
| 8.2 | Fault and other status messages | 89 |
| 9 | Appendix | 95 |
| 9.1 | List of spare parts and accessories | 95 |
| 9.1.1 | Fastening elements | 95 |
| 9.1.2 | Pressure connections | 95 |
| 9.1.3 | Temperature sensor pockets | 95 |
| 9.1.4 | Small parts and miscellaneous | 96 |
| 9.1.5 | Documentation | 96 |
| 9.2 | EC Declaration of Conformity | 97 |
| 9.3 | ATEX Type Examination Certificate | 98 |
| 9.3.1 | Zone 0, 1 | 98 |
| 9.3.2 | Zone 2 | 106 |

NOT UP-TO-DATE
www.docuthek.com

1 General

1.1 Information about this manual

This manual allows for safe and efficient use of the device.

Compliance with all safety information and instructions for use contained in this operating manual is a prerequisite for safe working processes and proper use of the device. Furthermore, the valid guidelines, standards, local accident prevention regulations, and general safety regulations must be complied with for the respective area of application of the device.

This manual forms a constituent part of the product and must be stored within the immediate vicinity of the device and be accessible to installation, service, maintenance, and cleaning personnel at all times. The graphic illustrations used in this manual serve as a visual representation of the described processes and are therefore not necessarily to scale and may deviate from the actual design of the device.



The data and material properties indicated serve as reference values. These must be verified on a case-by-case basis and adjusted as necessary.



The EK280 Application Manual is available for you at www.ek280.de (→ „Docuthek“) for the commissioning of the various communication and device applications.

In general, you can download the manuals in various languages directly from the Honeywell Docuthek. Enter "EK280" as search term.

1.2 Warranty provisions

The current warranty provisions can be found in the general terms and conditions online under:

<https://www.elster-instromet.com/en/general-terms-of-business>

1.3 Customer service and and Technical Support (TAC)

Our customer service team is responsible for providing technical information and repairs. Our employees are constantly striving to acquire new information and gain experience, and these are both valuable sources for improving our products.

1.3.1 Customer service and repairs

- Phone: +49 (0) 61 34 / 605-0
- Fax: +49 (0) 61 34 / 605-390
- E-mail: PMT-Reparatur_Mainz-GE4N@honeywell.com

1.3.2 Technical Assistance Center (TAC)

Our Technical Support (TAC Technical Assistance Center) is at your disposal in case of faults:

- Phone: +49 (0) 6134 / 605-123
- Website: www.elster-instromet.com/en/support
- E-Mail: ElsterSupport@honeywell.com

1.4 Meaning of symbols

1.4.1 Safety information

In this manual, safety information is denoted by the use of symbols. The safety information is introduced by signal words which identify the level of risk.

This safety information must be complied with and care should be taken to prevent accidents, personal injury, and material damage.



DANGER!

... indicates an imminently dangerous situation which, if not avoided, could lead to death or serious injury.



WARNING!

... indicates a potentially dangerous situation which, if not avoided, could lead to death or serious injury.



CAUTION!

... indicates a potentially dangerous situation which, if not avoided, may lead to minor or slight injuries.



... indicates dangers resulting from electrical current. A non-compliance of the safety information poses a risk of serious or life-threatening injuries.



CAUTION!

... indicates a potentially dangerous situation which, if not avoided, could lead to material damage.

1.4.2 Tips and recommendations



... provides useful tips and recommendations as well as information for ensuring efficient and smooth operations.

1.5 Limitation of liability

All of the information contained in this manual has been compiled under consideration of valid standards and regulations, the latest technological developments, and our many years of experience and expertise. The manufacturer shall accept no liability for damages resulting from:

- Non-compliance of the manual
- Improper use
- Deployment of unqualified personnel
- Unauthorized modifications
- Technical changes
- Use of unauthorized spare parts

The actual scope of delivery may deviate from the information and graphics presented herein due to special designs, the selection of additional ordering options, or the latest technological developments.

The obligations stipulated in the delivery contract, the general terms and conditions and delivery conditions of the manufacturer, and the statutory provisions valid at the time of signing the contract, shall apply.



This manual should be read carefully before commencing all works on and with the device, particularly before putting the device into operation! The manufacturer shall accept no liability for damages and losses arising from non-compliance with the manual.

We reserve the right to make technical changes within the scope of improving usability and further development.

1.6 Copyright protection

This manual is copyright-protected and is intended for internal use only. A transfer of this manual to third parties, a reproduction of any kind, whether partially or fully, and the use and/or disclosure of its content, are not permitted without written consent from the manufacturer, except for internal purposes. Contraventions to this provision shall result in damage compensation. We reserve the right to assert further claims.

1.7 Scope of delivery

The scope of delivery for the EK280 includes:

- Electronic volume conversion device EK280
- Dispatch list
- Design data sheet
- Manual
- Bag of accessories

1.8 Spare parts and accessories



WARNING!

Incorrect use of spare parts and accessories may present a risk to safety!

False or incorrect use of spare parts and accessories may impair safety and lead to damage, malfunctions, or total failures.

Therefore:

- Only use original spare parts and accessories produced by the manufacturer.
- The manufacturer should always be contacted in the event of uncertainty.

A list of spare parts and accessories can be found in the appendix. Spare parts and accessories can be ordered from an authorized retailer or from our customer service team directly.

The free "enSuite" program also belongs to the accessories for the EK280 and is available under www.elster-instromet.com. This can be used to program the EK280 volume conversion device via its data interfaces to perform advanced applications.

The EK280 can be supplied as a calibrated and non-calibrated device and is also available in a number of different models. Further details can be

found under www.elster-instromet.com and in the "Assembly, Connection and Putting into Operation" chapter.

1.9 Storage



CAUTION!

Exceeding or falling below the valid temperature range for the batteries may impair performance.

If the valid temperature range of the batteries during storage of the device is exceeded or fallen below, the performance of the batteries may be impaired.

Therefore:

- For long periods of storage, please ensure that the valid temperature range for the fitted batteries does not fall below $-25\text{ }^{\circ}\text{C}$ or exceed $+55\text{ }^{\circ}\text{C}$.



CAUTION!

Material damage caused by the formation of condensation.

Fluctuations in temperature during storage may cause condensation to form. This may lead to subsequent malfunctions of the device.

Therefore:

- After storage or transport in cold weather conditions or after having been exposed to strong temperature fluctuations, the device should slowly be adjusted to the room temperature before being put into operation.
- If condensation has formed, wait at least 12 hours before putting the device into operation.



If the power supply to the device is interrupted during storage due to the batteries being disconnected, the time and date have to be reprogrammed.

The following rules apply for storage:

- The relative humidity should be a maximum of 93%.
- Do not store packages in the open air.
- The storage temperature should not fall below $-25\text{ }^{\circ}\text{C}$ and should not exceed $+55\text{ }^{\circ}\text{C}$.
- Avoid mechanical vibrations during storage of the device.

2 Safety

This chapter gives an overview of all of the most important safety aspects in order to best protect personnel and to ensure a safe and smooth operation of the device. A non-compliance with the safety information and instructions for use specified in this manual could result in serious damage.

2.1 General

The EK280 is an intrinsically safe device as per the ATEX Product Directive 94/9/EC and the ATEX Operating Directive 1999/92/EC EN, and is suitable for operation within the following explosive gas atmospheres:

- EK280 without integrated power supply unit or modem:
Zones 1 and 2 for gases in temperature class T4
- EK280 without integrated power supply unit and with modem:
Zones 1 and 2 for gases in temperature class T3
- EK280 with integrated power supply unit (with or without modem):
Zone 2 for gases in temperature class T6
- EK280 with or without integrated power supply unit with Ethernet Adapter:
Zone 2 for gases in temperature class T...

Verification for use in zone 0, 1 as per the respectively valid technical rules and standards: see chapter 9.3: EC type examination certificate no. LCIE 11 ATEX 3027 X



DANGER!
Using the wrong model presents a risk of explosion!

The EK280 is available in different models for use in zones 1 and 2.

The model designed for zone 2 should not be used in zone 0, 1 as this presents a risk of explosion!

Therefore:

- Before installing the device in zone 0, 1, please check that the EK280 is suitable for use in zone 0, 1.
- The EK280 should only be operated in zone 0, 1, if category "II 1 G" or "II 2 G" have been marked on the ATEX label.
- If category "II 3 G" has been marked on the ATEX label, the EK280 should not be used in zone 0, 1, but only in zone 2.
- The ATEX label is located on the top panel of the EK280 housing.

**DANGER!**

The connection of non-intrinsically-safe or non-associated equipment presents a risk of explosion!

Operating the EK280 in zone 0, 1 and connecting devices which are not certified as "associated equipment" present a risk of explosion.

Therefore:

- When using the EK280 in zone 0, 1, it should only be connected to certified associated equipment as per the ATEX Product Directive 94/9/EC.
- The EK280 should only be connected to the intrinsically-safe circuits of associated equipment whose electrical data corresponds to those requirements stipulated in the declaration of conformity for the EK280 (see Appendix).

**DANGER!**

Using incorrect batteries presents a risk of explosion!

Connect only the prescribed Elster battery-types to the device (see chapter 9.1.4.)



When connecting and operating the EK280 in explosive gas atmospheres, the corresponding standards must be observed:

DIN EN 60079-0

DIN EN 60079-14

The device may only be used in zone 0, 1 or zone 2, if installation has been carried out according to the separate requirements stipulated under DIN EN 60079-14 and the operating conditions (see "Technical Data" chapter) as well as the connection conditions (see "Assembly, Connection and Putting into Operation" chapter).

The device may be dangerous if unqualified personnel use it incorrectly or do not use it according to its intended purpose.

- All of those persons who are charged performing works on or with the device, must have read and understood the manual before commencing such works. This shall also apply if the person in question has already worked with the same or a similar device or has been trained by the manufacturer.
- Being familiar with the content of the manual is a necessary condition for protecting personnel against risks, preventing errors from occurring, and therefore ensuring a safe and smooth operation of the device.
- In order to avoid risks and to ensure optimal performance of the device, neither modifications nor changes should be carried out without express consent from the manufacturer.
- All operating instructions should be kept in a clearly legible condition on the device. Damaged or illegible instructions should be replaced immediately.
- The setting values and value ranges specified in this manual should be complied with.

2.2 Intended use

This device is solely designed and constructed for the intended use described below.

The volume conversion device EK280 is used to convert the gas volume read from a gas pipe under measurement conditions, into base conditions, as well as to allocate the measured quantities to tariffs. Furthermore, the device can also be used to measure, record and monitor additional variables depending on the configuration set by the user.

Intended use also refers to compliance with all of the information contained in this manual. Any use beyond the intended use and/or other types of use, shall be considered as misuse and can result in dangerous situations. The manufacturer shall not be held liable for any claims for damages resulting from misuse of this device.



WARNING!

Danger resulting from misuse.

Misuse of the device may lead to dangerous situations.

Therefore:

- Only use the device according to its intended use.
- Do not use the device to regulate the gas flow or other variables affecting the gas volume in the entire system.

2.3 Personnel



WARNING!

Risk of injury to unqualified personnel.

Improper use of the device may lead to significant personal injury or material damage.

Therefore:

- All works should solely be carried out by qualified personnel.

The following qualifications are used in the manual to denote different areas of responsibility:

- **Instructed personnel**
will be informed of the tasks assigned to them and possible risks resulting from inappropriate behaviour, in a training session provided by the operator.
- **Qualified personnel**
who, on the basis of their specialist training, knowledge and experience, as well as their awareness of the relevant statutory provisions, are in a position to perform their assigned tasks on the device and are able to independently identify and prevent possible risks.
- **Gas specialists**
who, on the basis of their specialist training, knowledge and experience, as well as their awareness of the relevant standards and regulations, are in a position to perform works on gas-handling equipment and to independently identify possible risks. The gas specialist will be specially trained in the respective area and will be familiar with the relevant standards and regulations.
- **Calibration officers**
who, on the basis of their specialist training, knowledge and experience, as well as their awareness of the relevant standards and regulations, are in a position to perform the works subject to calibration regulations on gas-handling equipment. The calibration officer will be trained on works on devices and installations subject to calibration regulations and will be familiar with the relevant standards and regulations.

- **Electricians**

who, on the basis of their specialist training, knowledge and experience, as well as their awareness of the relevant standards and regulations, are in a position to perform the works on electrical installations and to independently identify and prevent possible risks. The electrician will be specially trained in the respective area and will be familiar with the relevant standards and regulations.



WARNING!
Risk to unauthorized persons!

Unauthorized persons, who do not meet the aforementioned criteria, will not be familiar with the risks in the working area.

Therefore:

- Please keep unauthorized persons away from the working area.
- In cases of doubt, approach said person and direct them out of the working area.
- Interrupt the works if unauthorized persons enter the working area.

Only those persons who can be trusted to reliably execute their works shall be authorized to work on or with the device. People whose reactivity is impaired, e.g. by drugs, alcohol or medication, shall not be authorized to perform such works.

- When selecting personnel, please observe the valid age and professional guidelines for all of the gas-handling equipment.

2.4 Personal protective equipment

When working on the device inside a gas-handling plant, personal protective equipment must be worn to minimize risks to health.

- During works on the device, the necessary personal protective equipment must be worn inside the respective plant at all times
- The notices relating to personal protective equipment mounted in the working area must be followed at all times.

2.5 Specific risks

The residual risks arising from the risk assessment will be listed below. Please observe the safety and warning information specified in the following chapters to reduce risks to health and to prevent dangerous situations from arising.



WARNING!

Misuse of batteries may present a risk of injury.

Special care must be taken when handling batteries.

Therefore:

- Do not throw batteries into the fire or expose these to high temperatures. There is a risk of explosion.
- Do not charge batteries. There is a risk of explosion.
- Liquids that are produced as a result of misuse may lead to skin irritation. Avoid physical contact with such liquid. In the event of contact, rinse with large quantities of water. If the liquid enters the eyes, immediately rinse with water for 10 minutes and seek medical attention.



WARNING!

Risk of fire from highly flammable substances!

Highly flammable substances, liquids or gases could catch fire and lead to serious or fatal injuries.

Therefore:

- Do not smoke within the danger zone or within close proximity to this zone. No naked flames or ignition sources are permitted within this zone.
- Have a fire extinguisher close to hand.
- Suspicious substances, liquids or gases should be reported to the responsible member of staff immediately.
- Work should be stopped immediately in the event of a fire. You should leave the danger zone until it is given the all-clear.

2.6 Environmental protection



CAUTION! **Environmentally hazardous substances!**

If environmentally hazardous substances are handled incorrectly this may cause significant damage to the environment, particularly if they are improperly disposed of.

Therefore:

- The instructions below should be observed at all times.
- Appropriate measures should be taken immediately if environmentally hazardous substances are accidentally released into the environment. In cases of doubt, please inform the responsible local authority about the damages.

The following environmentally hazardous substances are used:

- Batteries

Batteries contain toxic heavy metals. They must be treated as special hazardous waste and be disposed of in municipal waste collection points or by a waste specialist.

2.7 Operator's responsibility

The device will be used in the commercial sector. The operator of the device will therefore be subject to legal obligations concerning occupational safety.

In addition to the safety information contained in these instructions, the valid safety, accident prevention, and environmental protection regulations for the area of application of the device, must be adhered to. In particular:

- The operator must ensure that the valid safety, accident prevention, and environmental protection regulations for the entire plant in which the device is being integrated, are complied with.
- The operator must be familiar with the valid occupational safety regulations and must also be able to conduct a risk assessment to determine risks arising from the specific working conditions in the respective area of application of the device. The operator must then implement this in the form of operating instructions for the operation of the device.
- Throughout the entire life cycle of the device, the operator must determine whether their prepared operating instructions are compatible with current regulations and amend these if and when

necessary.

- The operator must clearly regulate and define responsibilities for the assembly, connection, putting into operation, and maintenance of the device.
- The operator must ensure that all employees who use the device have read and understood this manual. Furthermore, the operator must provide training to personnel at regular intervals and inform them of the potential risks.
- The operator of the entire plant in which the device is to be integrated, must provide personnel with the necessary protective equipment.

Furthermore, the operator is responsible for ensuring that the device remains in a perfect functioning order at all times. The following therefore apply:


- The operator must ensure that the installation and maintenance works described in this manual are carried out correctly.
- The operator must regularly have all safety mechanisms checked for their functionality and completeness.

3 Technical data

3.1 General data

| Data | Value | Unit |
|--|-------------|------|
| Width (incl. cable glands) | 230 | mm |
| Height (incl. cable glands) | 180 | mm |
| Depth | 115 | mm |
| Permissible ambient temperature range | -25 ... +55 | °C |
| Permissible gas temperature range | -30 ... +60 | °C |
| Mechanical ambient conditions accord. to MID Directive: | class | M2 |
| Electromagnetic ambient conditions accord. to MID Directive: | class | E2 |

3.1.1 Dimensions



3.2 Power supply for EK280 without integrated power supply unit

3.2.1 Battery power supply for the basic device

| Data | Value | Unit |
|---|-------|-------|
| Voltage | 3.6 | V |
| General nominal capacity | 16.5 | Ah |
| Usable capacity | 13.0 | Ah |
| Minimum number of batteries required | 2 | units |
| Minimum operating life (at standard measurement conditions) | 5 | years |

The **standard measurement conditions** are defined as follows:

| Data | Value |
|---------------------------|----------------------|
| Measurement cycle | 30 seconds |
| Mode input 1 | Pulse input |
| Display active | 60 minutes per month |
| Interface or modem active | 30 minutes per month |
| Ambient temperature | -10 ... +50°C |

3.2.2 Battery power supply for the integrated modem

| Data | Value | Unit |
|--------------------------|-------|------|
| Voltage | 3.9 | V |
| General nominal capacity | 16.0 | Ah |

3.2.3 External power supply for the basic device

| Data | Value | Unit |
|-------------------------|-------------|------|
| Supply voltage | 7.5 ... 8.5 | V |
| Supply current, maximum | 40 | mA |

3.3 Power supply for EK280 with integrated power supply unit

3.3.1 Battery power supply for the basic device

Batteries for switching to battery mode in the event of a power failure: see chapter 3.2.1 "Battery power supply for the basic device"

3.3.2 External power supply

| Data | Value | Unit |
|----------------------------|-----------|------|
| Supply voltage | 115...230 | V ~ |
| Power consumption, maximum | 10 | W |

3.3.3 Buffer batteries for the integrated modem

The buffer batteries can optionally be connected to the integrated power supply unit to ensure that data continues to be transmitted, even in the event of a power failure.

| Data | Value | Unit |
|--------------------------------------|-------|-------|
| Voltage | 3.6 | V |
| General nominal capacity | 13.0 | Ah |
| Usable capacity | 8.0 | Ah |
| Minimum number of batteries required | 2 | units |

3.4 Power supply for the EK280 with Power over Ethernet (PoE)

If the EK280 is equipped with an Ethernet module and if the Ethernet network (or a switch) provides the Power over Ethernet function, the EK280 can be supplied with power from the Ethernet module. An integrated power supply is not required.

| Data | Value | Unit |
|----------------|--------------|------|
| Supply voltage | 36 V to 56 V | V DC |

3.5 Pressure sensor

3.5.1 CT30 Type Pressure Sensor

| Data | Value | Unit |
|----------------------|------------|------|
| External thread | M12 x 1.5 | |
| Usable thread length | approx. 10 | mm |

3.5.1.1 Absolute pressure ranges

| Measuring range | Overload capacity |
|---------------------|-------------------|
| 0.7 ...2 bar abs. | 18 bar abs. |
| 0.8 ...5 bar abs. | 25 bar abs. |
| 1.4 ...7 bar abs. | 25 bar abs. |
| 2.0 ... 10 bar abs. | 40 bar abs. |
| 2.4 ... 12 bar abs. | 40 bar abs. |
| 4 ... 20 bar abs. | 40 bar abs. |
| 6 ... 30 bar abs. | 60 bar abs. |
| 8 ... 40 bar abs. | 60 bar abs. |
| 14 ... 70 bar abs. | 105 bar abs. |
| 16 ... 80 bar abs. | 105 bar abs. |



These pressure sensors are available as both an external and internal model. Further details can be found under www.elster-instromet.com or chapter "Assembly, Connection and Putting into Operation".

3.5.1.2 Relative pressure ranges

| Measuring range | Overload capacity |
|--------------------|-------------------|
| 1.4 ... 7 bar rel. | 40 bar rel. |
| 4 ... 20 bar rel. | 40 bar rel. |
| 16 ... 80 bar rel. | 105 bar rel. |



These pressure sensors are only available as an externally connected model and can only be used as a second pressure sensor for non-metrological measurements. Further details can be found under www.elster-instromet.com or chapter "Assembly, Connection and Putting into Operation".

3.5.2 Pressure Sensor Type 17002

| Data | Value | Unit |
|---------------------------------------|-------------------|------|
| External thread (internal model) | M12 x 1.5 | |
| Usable thread length (internal model) | approx. 10 | mm |
| Measuring range | Overload capacity | |
| 0.9 ... 7 bar abs. | 10 bar abs. | |



The pressure sensor is available as both an external and internal model. Further details can be found under www.elster-instromet.com or chapter "Assembly, Connection and Putting into Operation".

3.6 Temperature sensor

| Data | Value | Unit |
|-------------------------|----------------|------|
| Measuring range | -30 ... +60 | °C |
| Measurement uncertainty | max. ± 0.1 | % |
| Installation length | 50 | mm |

3.7 Digital inputs

3.7.1 LF pulse and signal inputs

The maximum counting frequency of the digital inputs can be adjusted using the "enSuite" software. The limit values specified for frequency and duration shall only apply if the so-called "software debounce" has been switched off.

The software debounce is activated ex-works to suppress interference pulses and therefore restrict safe readings to 2 Hz.



If the software debounce is parameterized to a frequency higher than 2 Hz, then it may lead to counting errors caused by electromagnetic interference under certain circumstances.

| Data | | Value | | Unit |
|------------------------------------|--------------------|-------|------|------|
| Open-circuit voltage U_0 | | | 5.0 | V |
| Internal resistance R_i | | | 1 | MΩ |
| Short circuit current I_k | | | 5 | μA |
| Switch point "ON": | ▪ Resistance R_e | max. | 100 | kΩ |
| | ▪ Voltage U_e | max. | 0.8 | V |
| Switch point "OFF": | ▪ Resistance R_a | min. | 2 | MΩ |
| | ▪ Voltage U_a | min. | 3 | V |
| Pulse duration t_e | | min. | 62.5 | ms |
| Pause duration t_a | | min. | 62.5 | ms |
| Counting frequency f | | max. | 10 | Hz |
| Counting frequency f for input 3 | | max. | 6 | Hz |

3.7.2 HF pulse inputs (high frequency)

High frequency pulse transducers can only be connected to inputs 1 and 2 (terminals DE1 and DE2) (see chapter 5.2.1.3).

| Data | Value | Unit |
|------------------------|-------------|------|
| Open-circuit voltage | 7.5 ... 8.5 | V |
| "High" switching level | max. 1.2 | mA |
| "Low" switching level | min. 2.1 | mA |
| Input frequency | max. 2500 | Hz |

3.7.3 Encoder input



An encoder can only be connected to input 1 (terminal DE1).

| Data | Value | Unit |
|------------------|------------|------|
| Encoder protocol | Namur, SCR | - |

3.8 Digital outputs

The digital outputs DA2 and DA3 can be configured as low or high frequency pulse or signal outputs.

The digital outputs DA1 and DA4 can exclusively be configured as low frequency pulse or signal outputs.

3.8.1 Nominal data

| Data | Value | Unit |
|---------------------------|-------|-------|
| Maximum switching voltage | 30 | V DC |
| Maximum switching current | 100 | mA DC |
| Maximum voltage drop | 1 | V |
| Maximum residual current | 0.001 | mA |

3.8.2 LF pulse or signal outputs

| Data | Value | | Unit |
|------------------|-------|-----|------|
| Pulse duration | min. | 125 | ms |
| Pause duration | min. | 125 | ms |
| Output frequency | max. | 4 | Hz |

3.8.3 HF pulse outputs

The use of outputs as high frequency output is only possible if an external power supply has been connected (see chapter 5.2.5).

Only outputs 2 and 3 (terminals DA2 and DA3) can be used as high frequency output.

| Data | Value | Unit |
|------------------|-----------|------|
| Output frequency | max. 1000 | Hz |



If the HF output is fed via a FE260, the maximum output frequency is limited to 500 Hz (depending on the configuration of the outputs).

3.9 Interfaces

3.9.1 Serial optical interface

| Data | Value | Unit |
|-----------|---------------------------------------|------|
| Baud rate | 9600 | Bd |
| Format | 1 start bit, 1 parity bit, 1 stop bit | |



The baud rate of the serial optical interface is adjustable to 19200 Bd. However, the function with this baud rate depends among others also from the optical read out head and therefore cannot be guaranteed.

3.9.2 Serial electrical interface

| Data | Value |
|------------------|----------------|
| Adjustable types | RS232 or RS485 |

3.9.2.1 Technical Data of the RS485 Interface

| Data | Value |
|--|---|
| Operating modes | RS485 2-wire (half-duplex) RS485 4-wire (full-duplex) |
| Termination | Do <u>not</u> use a termination resistor at any device connected |
| Maximal data transfer rate | 19.200 Baud |
| Number of devices connected to the bus | max. 16 unit loads ¹ Power consumption at the input ² : - 6 unit loads (RS485, not electr. insulated) - 3 unit loads (RS485, electrically insulated) |

3.9.3 Integrated modem

| Data | Value | Unit |
|-----------------|--|------|
| Modem type | 2G: GSM / GPRS 3G: GSM / GPRS / UMTS | |
| Frequency bands | 2G: 850 /900 /1800 /1900 3G: 850 /900 /1800 /1900 /2100 | MHz |

¹ Unit Load: Standard RS-485 receiver with an input resistance = 12kOhm

² For details on connecting the RS485 interface, see Application manual.

3.9.4 Ethernet adapter

| Data | Value | Unit |
|-----------|------------------------------|------|
| Type | 100 | Mbit |
| Supply | Internal mains-supply or PoE | |
| Functions | TCP-IP Client/Server, FTP | |

3.10 Measurement conditions

3.10.1 Environment


| Data | Value | Unit |
|-------------------------|-----------|------|
| Temperature range | -25...+55 | °C |
| Relative humidity, max. | 93 | % |

3.11 Labelling

The EK280 is approved as a volume corrector as per the Measuring Instruments Directive (MID). The label is placed on the front panel of the device (see Construction and Function chapter).

3.11.1 Type label³ of the volume corrector

The type label of the EK280 relating to its function as a volume corrector, contains the following information:



- 1 Type designation
- 2 CE marking
- 3 Metrology marking
- 4 Number of the EC type examination
- 5 Measurement accuracy data
- 6 Reference to EN 12405-1
- 7 IP protection class data
- 8 Serial number
- 9 Year of construction
- 10 Ambient temperature range

Fig. 1

³ The identification plate may contain other information depending on the design or the country of destination.

3.11.2 ATEX marking

The plate for the "Ex" marking of the EK280 is located on the top panel of the device housing.

3.11.2.1 Zone 0, 1 (without integrated power supply unit)




Fig. 2

- | | |
|---|----------------------------------|
| 1 Manufacturer and address | 4 Identification number |
| 2 Ex marking | 5 Type designation of the device |
| 3 Permissible ambient temperature range | 6 Temperature class data |

3.11.2.2 Zone 2 (with integrated power supply unit)




Fig. 3

- | | |
|---|----------------------------------|
| 1 Manufacturer and address | 5 Type designation of the device |
| 2 Ex marking | 6 Ex zone data |
| 3 Permissible ambient temperature range | 7 Warning notices |
| 4 Identification number | |

3.11.3 Device software identification

- Move the cursor using the arrow keys to the "Serv." register and to the values "Vers" (device software version) and "Chk" (checksum) via the following path:
Serv. → Identification → Volume Converter → "Vers" or "Chk"
- The checksum "Chk" can be recalculated for verification purposes by pressing the ENTER button.

4 Construction and Function

4.1 External view




Fig. 4

4.2 Internal view




Fig. 5

4.3 Short description

The volume conversion device EK280 is an explosion-protected electronic device that takes the volume of gas determined by an external meter at measurement conditions to calculate the volume at base conditions and therefore the energy portion of the respective gas volume.

Furthermore, the gas flow of a pipeline can be monitored, recorded and transmitted by means of the recording function, the signal inputs and outputs, as well as the serial and optical data interfaces of the device.

Recording the necessary state variables for this purpose takes place via an externally or internally connected pressure sensor as well as a temperature sensor. An alphanumeric display and a keyboard on the front panel of the device serve as the control elements for the EK280.

4.4 Connections

The EK280 volume corrector can be connected to:

- Four batteries
- An external power supply

The following can be used to monitor and record the calculated data and to transmit data and program functions:

- Six counting and signal inputs DE1, DE2, DE3, DE4, DE5, DE6
- Four pulse and signal outputs DA1, DA2, DA3, DA4
- Serial data interface
- Optical data interface



Further details on the connection possibilities for the EK280 and the available equipment versions can be found in the "Technical Data" chapter and in chapter "Assembly, Connection and Putting into Operation".

5 Assembly, Connection and Putting into Operation

5.1 Assembly



DANGER!

Using the wrong model presents a risk of explosion!

The EK280 is available in different models for use in zones 1 and 2.

The model designed for zone 2 should not be used in zone 0, 1 as this presents a risk of explosion!

Therefore:

- Before installing the device in zone 0, 1, please check that the EK280 is suitable for use in zone 0, 1.
- The EK280 should only be operated in zone 0, 1, if category "II 1 G" or "II 2 G" have been marked on the ATEX label.
- If category "II 3 G" has been marked on the ATEX label, the EK280 should not be used in zone 0, 1, but only in zone 2.
- The ATEX label is located on the top panel of the EK280 housing.

The following solely applies for the EK280 model with integrated power supply unit (ATEX category "II 3 G" for use in zone 2):



WARNING!

- Do not open when an explosive atmosphere may be present!
- Electrostatic hazard: Do not rub!



The EK280 can either be mounted on a gas meter, on a pipeline, or on a wall.



Should problems arise during assembly, e.g. with regard to the selection of suitable assembly tools, please contact our customer service team (see "General" chapter).

5.1.1 Assembly on a gas meter



Mount the EK280 on a gas meter using a mounting bracket (see Appendix) as well as the corresponding cylinder screws and square nuts.




Fig. 6

1. Using two M5 x 10 mm (Fig. 6: 4) cylinder screws, attach the mounting bracket (Fig. 6: 6) to the EK280 (Fig. 6: 1).
2. Tighten the cylinder screws so that the bracket is sitting in a fixed position.
3. Attach the mounting bracket using two square nuts M5 (Fig. 6: 7) and two M5 x 10 mm (Fig. 6: 5) cylinder screws at the back of the meter head (Fig. 6: 8).
4. Tighten the cylinder screws so that the device is in a fixed position and cannot fall down.

5.1.2 Assembly on a pipeline



Mount the EK280 to a pipeline using an A2 universal bracket with a pipe clamp (see Appendix) as well as corresponding cylinder screws.




Fig. 7

1. Using two M5 x 10 mm (Fig. 7: 1) cylinder screws, insert the A2 universal bracket in the boreholes provided (Fig. 7: 3) on the EK280 (Fig. 7: 2).
2. Tighten the cylinder screws so that the bracket is sitting in a fixed position.
3. The A2 universal bracket (Fig. 7: 3) and the device (Fig. 7: 2) should be fastened to the pipeline (Fig. 7: 5) using the pipe clamp (Fig. 7: 4).
4. The device should be mounted on the pipeline in such a way that it is in a fixed position and cannot fall down.

5.1.3 Assembly on a wall




Fig. 8

1. Bore four holes in the positions marked on the wall (see dimensions in Fig. 8).
2. Select wall plugs which correspond to the size of the screws and insert these in the boreholes in the wall.
3. To fasten the EK280, four M5 x 40 mm wood screws should be used for wall assembly.

5.1.4 Three-way valve

When mounting the pressure sensor, a three-way valve is usually incorporated in order to test the pressure sensor in an installed condition or to exchange a faulty sensor without switching off the entire gas pipeline. The three-way valve available from Elster is constructed as follows:




Fig. 9

- 1: From the meter: From the pressure connection of the gas meter. For diaphragm gas meters, this takes place on the input side of the meter.
- 2: To the VC: For the connection of the pressure sensor to the volume corrector.
- 3: Test connection: Possible to take the test pressure or to assert external pressure on the pressure sensor of the volume corrector.



When mounting the three-way valve, it must be ensured that the position of the control lever with the corresponding outlets is checked as the lever can be removed and may be mounted the wrong way round.



The pipeline from the pressure sensor to the meter must be laid at an angle in order to ensure that water does not damage the pressure sensor or affect the measurement accuracy.

5.2 Connection



The EK280 is available as both a calibrated and non-calibrated device. Information regarding additional equipment versions of the EK280 can be found under www.elster-instromet.com.



DANGER!

The connection of non-intrinsically-safe or non-associated equipment presents a risk of explosion!

The operation of the EK280 in zones 1 and 2 and the connection of non-intrinsically-safe equipment which exceeds those conditions and limit values specified in the declaration of conformity, presents a risk of explosion.

Therefore:

- The device should only be connected inside zones 1 and 2 and only to certified associated equipment as per the ATEX Product Directive 94/9/EC.
- Only devices with intrinsically-safe circuits and electrical data that corresponds to those requirements stipulated in the declaration of conformity for the EK280 (see Appendix), should be connected.



WARNING!

Risk caused by incorrect connection of the device!

The device should solely be connected by a gas specialist (see "Safety" chapter). Incorrect connections may lead to life-threatening situations or significant material damage.

Therefore:

- The calibrated device should only be connected by a gas specialist.
- The same specialist should also be consulted if subsequent changes to location arise.
- Please refrain from unauthorized connections and relocations of the device.

- When connecting the EK280 and putting it into operation, the guidelines of the corresponding DIN EN 60079-0 and DIN EN 60079-14 standards should be observed.
- The wiring of the connections should be professionally carried out by a gas specialist or a calibration officer.
- Active outputs cannot be switched.
- Connect unused cable glands as per DIN EN 60079-14 with the help of a plug or a suitable screw cap.
- Insulate any unused wire (e.g., in multicore cables) at the end by appropriate termination means. (see "Technische Regel für Betriebssicherheit (TRBS)")

In order to program the device and perform further applications, and in addition to the components specified in this chapter, you can also connect an external power supply to the other connections as well as the serial and optical interface of the EK280 (see "Construction and Function" chapter). Further details can be found under www.elster-instromet.com.



The connections described below should only be sealed by a calibration officer. If the EK280 is used for operations which are not subject to calibration regulations, the seals on the respective connections can be omitted.

5.2.1 Connecting the gas meter

In order to measure the gas volume, a gas meter with a low or high frequency pulse transducer or encoder can be connected to the digital input "DE1" of the EK280.




Fig. 10

1

The pulse transducer or encoder of the gas meter will be connected to the "DE1" terminal (1) of the EK280.

Further details and special features regarding the use of the pulse transducer and encoder are described in the following sub-chapters.



The cable core diameter for the connection to the EK280 inputs is 0.33 ... 2.5 mm².

5.2.1.1 Connection to a low frequency pulse transducer

1. Connect the pulse output of the gas meter to the "DE1" terminal (1 in Fig. 10, page 38) of the EK280.
The polarity can be freely selected (the symbols "+" and "-" on the terminals are used for the connection of other pulse transducers or encoders).
2. Adjust the measurement parameters, e.g. the cp value (pulse constant), as described in chapter 5.2.1.1.

5.2.1.2 Connection to an encoder

1. Connect the encoder of the gas meter to the "DE1" terminal (1 in Fig. 10, page 38) of the EK280.
The polarity should be taken into consideration, i.e. connect the "+" of the encoder to the "DE1 +" terminal and "-" to the "DE1 -" terminal respectively.
2. Adjust the measurement parameters, e.g. the encoder type, as described in chapter 5.3.1.3.

5.2.1.3 Connection to a high frequency pulse transducer



The EK280 can only count the pulses of a high frequency pulse transducer if there is an external power supply - not when in battery mode.

In order to ensure an uninterrupted measurement of the gas volume, the EK280 can be configured in such a way that the device automatically switches to a low frequency pulse transducer in the event of a failure of the external power supply; see chapter 5.2.1.4.



If you would like to use the automatic switching function of the pulse transducer, please proceed as per chapter 5.2.1.4 !

1. Connect the high frequency pulse output of the gas meter to the "DE1" terminal (1 in Fig. 10, page 38) of the EK280.
The polarity should be taken into consideration, i.e. connect the "+" of the pulse transducer with the "DE1 +" terminal and "-" with the "DE1 -" terminal respectively.
2. Adjust the measurement parameters, e.g. the cp value (pulse constant), as described in chapter 5.3.1.4.

5.2.1.4 Automatic switchover of the pulse transducer

The EK280 should be configured as described in order to ensure an uninterrupted measurement of the gas volume when using a high frequency pulse transducer.

If the power supply is in a functioning order, the volumes and flows (V_b , V_m , Q_b , Q_m) will be measured with the high frequency pulse transducer. In the event of a failure of the external power supply, the EK280 will automatically switch to the low frequency pulse transducer.




Fig. 11

1. Connect the low frequency pulse transducer of the gas meter to the "DE1" terminal (1) of the EK280.
2. Connect the high frequency pulse transducer of the gas meter to the "DE2" terminal (2) of the EK280.
3. Adjust the measurement parameters, e.g. the cp value (pulse constant), as described in chapter 5.3.1.5.

5.2.2 Sealing the input terminals

After connecting to the gas meter as per chapter 5.2.1, the input terminal "DE1" must be sealed for official calibration measurements.

For this purpose, terminal covers are provided in the bag of accessories. If required, these should be screwed over the connected terminals and an adhesive seal should then be bonded to the fastening screw (see chapter 5.3.2).

5.2.3 Connecting the temperature sensor



Any national requirements must be observed when connecting the temperature sensor.

The requirements of the PTB Testing Instructions, Volume 20, Electronic volume conversion device for gas, Chapter 5, shall apply to Germany.



Before connecting, the temperature sensor should be lubricated with heat transfer fluid in order to enhance its functionality.

5.2.3.1 Connection to a standard temperature sensor pocket




Fig. 12

1. Insert the temperature sensor Pt500 **4** into the temperature sensor pocket **5** (see Appendix).
2. Fasten the temperature sensor using the capstan screw **2** and screw connections provided **6**.
3. Have a calibration officer seal the temperature sensor using the sealing sleeve **1** and the wire seal **3** as per Fig. 12.

5.2.3.2 Connection to an older temperature sensor pocket




Fig. 13

1. Insert the temperature sensor Pt500 **5** into the temperature sensor pocket **6** (see Appendix).
2. Use the adapter **2** to seal the connection (see Appendix).
3. Fasten the temperature sensor using the capstan screw **3** and the screw connections **8** provided.
4. Have a calibration officer seal the temperature sensor using the sealing sleeve **1** and the wire seal **4**, **7**.

5.2.4 Connecting the pressure pipe



Any national requirements must be observed when connecting the pressure pipes.
The requirements of the PTB Testing Instructions, Volume 20, Electronic volume conversion device for gas, Chapter 5, shall apply to Germany.



Efforts must be made to ensure the pipes are installed downwards.

5.2.4.1 Connection to an internal pressure sensor




Fig. 14

1. Connect the pressure connection to the internal pressure sensor connection **1** using the union nut and the sealing insert **4**.
2. Have a calibration officer seal the connection with the sealing sleeve **2** and a wire seal **3**.

5.2.4.2 Connection to an external pressure sensor




Fig. 15

1. Connect the pressure connection **7** to the external pressure sensor **6**.
2. Have a calibration officer seal **2** the connection with a sealing sleeve **1**.

5.2.5 Connecting the power supply

5.2.5.1 Power supply for the EK280 without integrated power supply unit



DANGER!

The connection of non-associated equipment presents a risk of explosion!

Operating the EK280 in zone 0, 1 and connecting devices which are not certified as "associated equipment" present a risk of explosion.

Therefore:

- When using the EK280 in zone 0, 1, it should only be connected to certified associated equipment as per the ATEX Product Directive 94/9/EC.
- The EK280 should only be connected to the intrinsically-safe circuits of associated equipment whose electrical data corresponds to those requirements stipulated in the declaration of conformity for the EK280 (see Appendix).

For the external power supply of the EK280 (model without in-built power supply unit), the electrical data should be adhered to as per chapters 9.3 and 3.2.3.

The extended function unit "FE260" from Elster can also be used as a power supply unit, for example.




Fig. 16

Connect the power supply to the "Uext" terminal (**1**) of the EK280.

The polarity should be taken into consideration, i.e. connect the "+" of the power supply unit to the "Uext +" terminal and "-" to "Uext -".

5.2.5.2 Power supply for the EK280 with integrated power supply unit



DANGER!
Danger to life from electrical current!

Touching live parts poses an imminent danger to life.

Therefore:

- Works on the electrical components of the device, i.e. the connection of the power supply unit, should solely be carried out by qualified electricians.
- When performing all works to the electrical system, switch off the power, secure it against an accidental restart and check to ensure that the voltage has been cut.
- Keep live parts away from moisture. This could lead to a short-circuit.

The power supply unit to connect the 115...230 V~ power supply, is in-built into the base of the EK280.




Fig. 17

1. Switch off the supply voltage and secure it against an accidental restart!
2. Connect the 115...230 V~ supply voltage to the "J2" terminal block (1) of the EK280.



The cable core diameter for the connection to the integrated power supply unit is 0.2 ... 1.5 mm².



DANGER!
Danger to life from electrical current!

Connect protective ground wire of mains-supply to screw terminal J2, connection E!

5.2.6 Connect outputs of the EK280



The cable core diameter for the connection to the EK280 outputs is 0.33 ... 2.5 mm².



Different downstream devices can be connected to the digital outputs of the EK280. The outputs are preconfigured for this purpose (see chapter 5.3.1.13).

| | | | | | | | | | |
|-----|---|-----|---|-----|---|-----|---|--|--|
| | | | | | | | | | |
| K11 | | K12 | | K13 | | K14 | | | |
| | | | | | | | | | |
| + | - | + | - | + | - | + | - | | |
| DA1 | | DA2 | | DA3 | | DA4 | | | |
| | | | | | | | | | |
| + | - | + | - | + | - | + | - | | |
| DA1 | | DA2 | | DA3 | | DA4 | | | |

Fig. 18

1. Connect the downstream device to the corresponding digital outputs (terminals "DA1" to "DA4") of the EK280 (p. Fig. 18).
2. Terminal covers are provided in the bag of accessories to seal the output terminals. If required, these should be screwed over the connected terminals and a seal should then be bonded to the fastening screw (see chapter 5.3.2).

3. If necessary, adjust the cp value (pulse contact) for the pulse outputs as described in chapter 5.3.1.13.

5.2.6.1 Electrical insulation of the outputs

In standard cases, all negative poles of the outputs are electrically connected to the motherboard.

For special applications, i.e. switching a positive pole, each output can be electrically separated from the motherboard and from the other outputs.



CAUTION!

Reduced battery life

Activating the electrical insulation of outputs reduces the battery life when in battery mode!

It is then impossible to give a reliable prediction of the remaining battery life.



An electrically-insulated output only requires electricity if the output is active (switched-on). You can therefore minimize the negative influence of an electrically-insulated output on the battery life by setting the pulse duration to the lowest possible value when using it as a pulse output.

The configuration software "enSuite" can be used for this purpose.



The electrical insulation of the outputs is not an approved electrical isolation in accordance with ATEX. An approved Ex-isolator is required when using the device in Ex zone 0, 1.

In order to activate the electrical insulation of an output, please move the switch lever behind the corresponding output terminal away from the terminal:




Fig. 19

5.2.7 Earthing the EK280 housing



The housing of the EK280 must always be earthed. A M6 screw is provided for this on the left-hand side of the housing.

1. The earth-cable must have a minimum diameter of 4mm².
2. Use the cable to connect the screw on the left-hand side of the housing with the equipotential bonding strip.

5.2.8 Earthing the cable connections of the EK280



All cables firmly connected to the EK280 have a shield. This is connected to the cable glands of the EK280 in order to prevent electromagnetic interference.



Only shielded cables should be used for new connections.

The cable shield should be completely earthed on both sides. For this purpose, the EK280 is equipped with special cable glands.

5.2.9 Additional measures for installation in zone 2



For the installation of the EK280 model with an integrated power supply unit (ATEX category "II 3 G") in zone 2, the following additional measures are necessary:

- A cable-tie must be mounted on each cable inside the housing as strain relief.
Place the cable-tie right beside the cable gland.
- All cable glands have to be fastened with minimum
 - 6 Nm for metal glands
 - 1.5 Nm for plastic glands
- Use only cables with the following outside-diameters for installation of the different cable gland types

| | |
|---------------------|--------|
| M12, metal: | 4.5 mm |
| M16 and M20, metal: | 8 mm |
| M16, plastic: | 8 mm |

The ATEX category "II 1 G" models of the EK280 (without in-built power supply unit) should be installed in both zones 1 and 2 without these additional measures.

5.3 Putting into operation

5.3.1 Configuration of measurement parameters



If the EK280 is subject to calibration regulations, the works described below should only be performed by legally authorized individuals.

The necessary measurement parameters can be adjusted using the free configuration program "enSuite", which is available under www.elster-instromet.com.


If the program is not available, the configuration can also be carried out using the keyboard as described below.



Before adjusting the measurement parameters via the keyboard, please read chapter 6 to learn how the device is operated.

5.3.1.1 Opening the calibration lock

The calibration lock is located at the back of the housing cover in the form of a button, and this can be secured by means of an adhesive label. This button must be pressed in order to adjust the values and parameters protected by configuration regulations.



Position of the button to open the calibration lock.

5.3.1.2 Adjusting the parameters for the low frequency pulse transducer of the gas meter

If a low frequency pulse transducer is connected as per 5.2.1.1, adjust the input mode and the cp value as follows:

1. Adjusting the input mode:

- Move the cursor to the "Serv." register and to the input mode "Md.I1" via the following path:
Serv. → Inputs → Input 1 → Md.I1
- Press the ENTER button. ⇒ The set value will start to flash.
- Press one of the arrow keys ▲ or ▼ until the text "Pulse input" starts to flash.
- Press the ENTER button to confirm the set value. The input value can be deleted by pressing the ESC button.

2. Adjusting the cp value (pulse constant):

- Move the cursor to the cp value "cp.I1" via the same path.
- Press the ENTER button. ⇒ The value will start to flash.
- Move the cursor using the arrow keys ► or ◄ to the digits and change these using the arrow keys ▲ or ▼.
- Press the ENTER button to confirm the set value. The input value can be deleted by pressing the ESC button.

5.3.1.3 Activating encoder mode

If an encoder is connected as per 5.2.1.2, the encoder mode is activated as follows:

Start the "Auto Detect" function using the keyboard of the EK280 as follows:

- Move the cursor to the "Serv." register and to the value "Md.I1" (input mode) via the following path:
Serv. → Inputs → Input 1 → Md.I1
- Press the ENTER button. ⇒ The set value will start to flash.
- Press one of the arrow keys ▲ or ▼ until the text "Auto-Encoder" starts to flash.
- Press the ENTER button to confirm the set value. The input value can be deleted by pressing the ESC button.
- Wait until "Auto-Encoder" is replaced by another value. This may take up to one minute as the EK280 consecutively activates and tests all known encoder protocols.

- Once the EK280 has successfully detected the encoder, it will display the meter reading of the gas meter with the description "Vo":

Serv. → Volume → Inputs → Input 1 → Vo

Unlike the "Auto Detect" function, you can also select the connected encoder type directly under "Md.I1".

Serv. → Volume → Inputs → Input 1 → Md.I1

The following encoder types can be selected:

| Md.I1 | Meaning |
|--------------|--------------------------------|
| Enc.Namur a | Encoder Namur a protocol |
| Enc.SCR EDIS | Encoder SCR EDIS95 |
| Enc.SCR OBIS | Encoder SCR OBIS05 |
| Enc.Nam. a-b | Encoder Namur a and b protocol |

5.3.1.4 Adjusting the parameters for the high frequency pulse transducer of the gas meter

If a high frequency pulse transducer is connected as per 5.2.1.3, the input mode and the cp value should be adjusted as follows:

1. Adjusting the input mode:

- Move the cursor to the "Serv." register and to the input mode "Md.I1" via the following path:
Serv. → Inputs → Input 1 → Md.i1
- Press the ENTER button. ⇒ The set value will start to flash.
- Press one of the arrow keys ▲ or ▼ until the text "HF pulses" starts to flash.
- Press the ENTER button to confirm the set value. The input value can be deleted by pressing the ESC button.

2. Adjusting the cp value (pulse constant):

- Move the cursor to the cp value "cp.I1" via the same path.
- Press the ENTER button. ⇒ The value will start to flash.
- Move the cursor using the arrow keys ► or ◀ to the digits and change these using the arrow keys ▲ or ▼.
- Press the ENTER button to confirm the set value. The input value can be deleted by pressing the ESC button.

5.3.1.5 Adjusting the automatic switchover of the pulse transducer

If the automatic switchover of the pulse transducer (see chapter 5.2.1.4) is used, adjust the necessary parameters as follows:

1. Adjusting the automatic switchover:

- Move the cursor to the "Serv." register and to the value "Sc.Vm" (sources for the volume at measurement conditions) via the following path:
Serv. → Volume → Actual volume → Parameter settings → Sc.Vm
- Press the ENTER button. ⇒ The set value will start to flash.
- Press one of the arrow keys ▲ or ▼ until the text "Input 2" starts to flash.
- Press the ENTER button to confirm the set value. The input value can be deleted by pressing the ESC button.

2. Adjust the input mode of the high frequency pulse transducer:

- Press the button ▼ to display "Md.I2".
- Press the ENTER button. ⇒ The set value will start to flash.
- Press one of the arrow keys ▲ or ▼ until the text "HF pulses" starts to flash.
- Press the ENTER button to confirm the set value. The input value can be deleted by pressing the ESC button.

3. Adjust the cp value of the high frequency pulse transducer:

- Press the button ▼ to display "cp.I2".
- Press the ENTER button. ⇒ The set value will start to flash.
- Move the cursor using the arrow keys ► or ◄ to the digits and change these using the arrow keys ▲ or ▼ to the cp value of the pulse transducer connected to input 2.
- Press the ENTER button to confirm the set value. The input value can be deleted by pressing the ESC button.

4. Adjust the parameters for the low frequency pulse transducer:

- Adjust the parameters for the low frequency pulse transducer on input 1 as described in chapter 5.3.1.2.

5.3.1.6 Setting the volume at measurement conditions

In order to control the recording of the volume at measurement conditions, the EK280 meter can be set once to the same value as the gas meter if the administrator lock is open. It is always possible to set the volume if the calibration lock is open:

- Open the administrator lock or the calibration lock
- Move the cursor to the „Serv.“ tab and go to the value „VmA“ (adjustable volume at measurement conditions) via the following path:
Serv. → Volume → Actual volume → Synchronization Vm → VmA
- Press the ENTER key. ⇒ One of the value digits flashes.
- Move the cursor using the arrow keys ► or ◄ to the digits and change these using the arrow keys ▲ or ▼.
- Once you have changed all of the digits, press the ENTER key in order to confirm your entry. The entry can be cancelled by pressing the ESC key.
- In order to accept the set value, move the cursor to the value „Store“
- Press the ENTER key. ⇒ „0“ flashes.
- Change the value using the arrow keys ▲ or ▼ to „1“
- Once you have changed the value, press the ENTER key in order to confirm your entry. The entry can be cancelled by pressing the ESC key. ⇒ „Vm“ is assumed for „VmA“.



If, when the administrator lock is open, the assumption of „VmA“ for „Vm“ is rejected with the message –13--, then this process has already been carried out once.

Other changes are possible if the calibration lock is open or, if the administrator lock is open, after deleting the change information for comparison of „Vm“ with the gas meter (see chapter 5.3.1.7).

5.3.1.7 Deleting change information for comparison of Vm with the gas meter

In order to allow the volume at measurement conditions to be reset if the administrator lock is open, the change information for comparison of "Vm" with the gas meter must be deleted:

- Open the calibration lock
- Move the cursor to the „Serv.“ tab and go to the value „Clear“ (deleting change information) via the following path:
Serv. → Volume → Actual volume → Synchronization Vm → Clear
- Press the ENTER key ⇒ „0“ flashes.
- Change the value using the arrow keys ▲ or ▼ to „1“
- Once you have changed the value, press the ENTER key in order to confirm your entry. The entry can be cancelled by pressing the ESC key. ⇒ „TimeX“ (time stamp of comparison), „Vm_o“ (Vm old value), „Vm_n“ (Vm new value) are set to default value.

5.3.1.8 Setting the volume at base conditions

For the EK280 volume conversion device, there is the option available when commissioning the device to set the volume at base conditions meter once if the administrator lock is open. It is always possible to set the volume if the calibration lock is open:

- Open the administrator lock or the calibration lock
- Move the cursor to the „Serv.“ tab and go to the value „VbA“ (adjustable volume at base conditions meter) via the following path:
Serv. → Volume → Standard volume → Synchronization Vb → VbA
- Press the ENTER key ⇒ One of the value digits flashes.
- Move the cursor using the arrow keys ► or ◀ to the digits and change these using the arrow keys ▲ or ▼.
- Once you have changed all of the digits, press the ENTER key in order to confirm your entry. The entry can be cancelled by pressing the ESC key.
- In order to accept the set value, move the cursor to the value „Store“
- Press the ENTER key. ⇒ „0“ flashes.
- Change the value using the arrow keys ▲ or ▼ to „1“
- Once you have changed the value, press the ENTER key in order to confirm your entry. The entry can be cancelled by pressing the ESC key. ⇒ „Vb“ is assumed for „VbA“.



If, when the administrator lock is open, the assumption of „VbA“ for „Vb“ is rejected with the message –13–, then this process has already been carried out once.

Other changes are possible if the calibration lock is open or, if the administrator lock is open, after deleting the change information for comparison of „Vb“ (see chapter 5.3.1.9).

5.3.1.9 Deleting change information for comparison of Vb with the gas meter

In order to allow the volume at base conditions to be reset if the administrator lock is open, the change information for comparison of „Vb“ must be deleted:

- Open the calibration lock
- Move the cursor to the „Serv.“ tab and go to the value „Clear“ (deleting change information) via the following path:
Serv. → Volume → Standard volume → Synchronization Vb → Clear
- Press the ENTER key. ⇒ „0“ flashes.
- Change the value using the arrow keys ▲ or ▼ to „1“
- Once you have changed the value, press the ENTER key in order to confirm your entry. The entry can be cancelled by pressing the ESC key. ⇒ „TimeX“ (time stamp of comparison), „Vb_o“ (Vb old value), „Vb_n“ (Vb new value) are set to default values.

5.3.1.10 Adjust compressibility equation and gas analysis

- Move the cursor to the "Serv." register and to the value "Md.K" (compressibility equation) via the following path:
Serv. → Volume conversion → Parameter settings → Md.K
- Press the ENTER button. ⇒ The set value will start to flash.
- Change the value using the arrow keys ▲ or ▼. Adhere to the valid legal provisions for the area of application.

| Md.K | Meaning |
|-------------|---|
| fix value | No calculation of compressibility. The adjustable value "K.F" will be used. |
| S-Gerg-88 | Calculation of compressibility as per S-Gerg-88 |
| AGA-NX19 | Calculation of compressibility as per AGA-NX19 |
| AGA-8 GC1 | AGA8 Gross Characterization Method 1 |
| AGA-8 GC2 | AGA8 Gross Characterization Method 2 |
| AGA-NX19-HW | AGA-NX19 according to Herning and Wolowsky |
| AGA-8 DC92 | Calculation of compressibility as per AGA8 DC92 |

- Press the ENTER button to confirm the set value. The input value can be deleted by pressing the ESC button.
- After selecting the compressibility equation, move the cursor along to the gas analysis values (Ho,b, CO2 etc.) using the arrow keys ▲ or ▼.
- Change the values according to the gas used by confirming the input by pressing the ENTER button or use the arrow keys ► or ◄ to go to the digits and change these with the buttons ▲ or ▼.
- Press the ENTER button to confirm the set value. The input value can be deleted by pressing the ESC button.



The calorific value Ho,b applies to the basic conditions pbX, TbX and reference combustion temperature +25°C.
 pbX and TbX are adjustable under calibration lock.

5.3.1.11 Adjust alarm limits for gas pressure and temperature measurement

Alarm limits are set to default values ex-factory. If a change becomes necessary, please proceed as follows:

- Move the cursor to the "Serv." register and move to the alarm limit values via the following paths:

Serv. → Measured values → Pressure → Parameter settings → pMin and pMax

Serv. → Measured values → Temperature → Parameter settings → TMin and TMax

- Press the ENTER button to confirm the input.
- Use the arrow keys ► or ◀ to go to the digits and change these with the arrow keys ▲ or ▼.
- Press the ENTER button to confirm the set value. The input value can be deleted by pressing the ESC button.

5.3.1.12 Adjusting replacement values for gas pressure and gas temperature

If the gas pressure or gas temperature cannot be measured due to a fault, an adjustable replacement value (fixed value) will be used to calculate the volume at base conditions. The volume calculated in this way will be counted in the separate disturbance quantity meter "VbD".

The replacement values can be found under the following paths:

Serv. → Measured values → Pressure → Parameter settings → p.F

Serv. → Measured values → Temperature → Parameter settings → T.F

Changing the values generally takes place precisely as described in chapter 5.3.1.12 for the alarm limit values.

5.3.1.13 Configuration of the outputs



The cp values (pulse constants) for the outputs can also be configured using the enSuite software.

The following functions are preset ex-factory for the outputs:

| Outputs | Function |
|----------|---|
| Output 1 | Pulse output for the total volume at base conditions "VbT" (cp.O1 = 0.1) |
| Output 2 | Pulse output for the total volume at measurement conditions "VmT" (cp.O2 = 0.1) |
| Output 3 | Status output for warnings (see chapter 8.2) |
| Output 4 | Status output for alarms (see chapter 8.2) |

The cp value of an output indicates how many pulses are emitted per cubic meter. A cp value of 0.1 / m³ (0.1 pulses per m³) means, for example, that one pulse is emitted per 10 m³.

To change the cp values for output 1 or output 2, move the cursor to the "Serv." register and go to "cp.O1" (for output 1) or "cp.O2" (for output 2) via the following path:

Serv. → Outputs → Output 1 → cp.O1
or *Serv. → Outputs → Output 2 → cp.O2*

- Press the ENTER button. ⇒ The cp value will flash.
- Move the cursor using the arrow keys ► or ◀ to the digits and change these using the arrow keys ▲ or ▼.
- Press the ENTER button to confirm the set value. The input value can be deleted by pressing the ESC button.



Aside from the settings described here, a range of other functions can be configured for the outputs, e.g. high frequency or time-synchronous pulses.

A complete description can be found in the EK280 Application Manual that can be downloaded under www.elster-instromet.com.

5.3.1.14 Setting the daylight saving time

- Move the cursor to the "Serv." register and to the "MdTim" value (daylight saving mode) via the following path:
Serv. → Date and Time → MdTim
- Press the ENTER button. ⇒ The set value will start to flash.
- Change the value using the arrow keys ▲ or ▼:

| MdTim | Meaning |
|-------------|---|
| CEST off | No switchover to daylight saving time |
| CEST autom. | Automatic switchover to daylight saving time (CEST = Central European Summer Time) |
| CEST manual | The start and end of daylight saving time is configured by the control center every year. |

- Press the ENTER button to confirm the set value. The input value can be deleted by pressing the ESC button.

5.3.1.15 Deleting the measurement archive



Deleting the archive is not absolutely necessary when putting the device into operation.

- Move the cursor to the "Serv." register and to the "Clr.A" value (delete measurement archive) via the following path:
Serv. → Edit and delete → Clr.A



All measurement archives (no logs) will be deleted.

In order to ensure that the archive is not accidentally deleted, the serial number of the EK280 must be entered whilst the calibration lock is open (the number is located on EK280 identification plate).

- Press the ENTER button. ⇒ The value will start to flash.
- Move the cursor using the arrow keys ► or ◄ to the digits and enter the serial number of the device using the arrow keys ▲ or ▼.
- After you have entered the serial number of the device, press the ENTER button to confirm the input. The input value can be deleted by pressing the ESC button.

5.3.1.16 Deleting the certification data log



The log can only be deleted if the calibration lock is open.

- Move the cursor to the "Serv." register and to the value "CICDL" (delete certification data log) via the following path:
Serv. → Change and Delete → CICDL
- Press the ENTER button. ⇒ "0" will start to flash.
- Change the value to "1" with the arrow keys ▲ or ▼.
- After you have entered the value, press the ENTER button to confirm the input. The input value can be deleted by pressing the ESC button.

5.3.1.17 Closing and securing the calibration lock

After all settings subject to calibration regulations have been adjusted, close the calibration lock in the same way that it was opened: Press the buttons described in chapter 5.3.1.1 once again. The calibration switch is secured with an adhesive label as described in chapter 5.3.2.2.

5.3.2 Sealing

5.3.2.1 External view




Fig. 20

- 1 Possible sealing point to secure the identification plate via adhesive seal.
- 2 Optional user lock: Seal covers using wire seals through sealing eyelets.

5.3.2.2 Internal view




Fig. 21

- 1 Sealing point to secure the calibration switch.
- 2 Sealing points to secure the circuit board cover
- 3 Sealing points to secure the sensor covers for the pressure and temperature sensors.
- 4 Sealing points to secure the terminal covers of the inputs, outputs and interfaces if necessary.



These sealing points (4) to secure the pulse inputs and pulse outputs are subject to national regulations (cf. WELMEC 11.1, chapter 2.7.1).

Depending on the legal situation in the respective country of use, seals produced by legally authorized manufacturers or the metering point operators, should be used.

If the devices are supplied with connected input and/or output cables, seals will be provided with the manufacturing symbol as standard. If necessary, these can be replaced in the area of application as described above.

5.3.2.3 Sensors



Examples of how to seal the connected temperature and pressure sensors are presented in chapters 0 and 5.2.4.

5.3.3 Closing the housing



CAUTION!

Material damage may arise through improper closing of the device!

Improper closing of the device may lead to material damage as a result of cable connections being squashed.

Therefore:

- Please ensure that the cable ducts are positioned correctly when closing the device.
- To close, slightly raise the lid on its hinges.




Fig. 22

1. Close the housing using the four screws provided (1).
2. Close the unused cable glands using the sealing plugs provided within the scope of supply.

5.3.4 Verifying assembly and connection

**WARNING!****Risk as a result of incorrect assembly and connection**

Incorrect assembly and connection of the EK280 may lead to life-threatening situations.

Therefore:

- Assemble and connect the EK280 correctly.
- Sealing should solely be carried out by a calibration officer.
- Follow the guidelines of DIN EN 60079-14, DIN EN 60079-0, the ATEX Product Directive 94/9/EC as well as the ATEX Operating Directive 1999/92/EC EN.

5.3.5 Programming a data transfer

To discover the wide range of possibilities for remote data transfer to a control center via the integrated modem or via a device connected to the terminal interface, please follow the corresponding instructions in the EK280 Application Manual, which you can download from www.elster-instromet.com.

The data transfer settings can be configured without opening the calibration lock.

6 Operation



The "enSuite" software and data interfaces of the EK280 can be used to perform further applications other than those described below. Instructions can be found under www.elster-instromet.com.

6.1 Safety

6.1.1 Personal protective equipment

When working on the device inside a gas-handling plant, personal protective equipment must be worn to minimize risks to health.

- During works on the device, the necessary personal protective equipment must be worn inside the respective plant at all times
- The notices relating to personal protective equipment mounted in the working area must be followed at all times.

6.2 Operating personnel

The following groups of people are authorized to perform different functions when operating the EK280.

6.2.1 Instructed personnel

A person instructed on how to operate the EK280, who

- will be informed of the tasks assigned to them and possible risks resulting from inappropriate behaviour, in a training session provided by the operator.
- is authorized to read and take note of values and parameters using the control elements of the EK280.

6.2.2 Qualified personnel

A person qualified to operate the EK280, who,

- on the basis of their specialist training, knowledge and experience, as well as their awareness of the relevant statutory provisions, are in a position to perform their assigned tasks on the device and are able to independently identify and prevent possible risks.

- are authorized to read and take note of values and parameters using the control elements of the EK280, and to perform changes which are not subject to calibration regulations.

6.2.3 Calibration officers

A calibration officer, who,

- on the basis of their professional training, knowledge and experience and awareness of applicable standards and regulations, are in a position to perform the works on gas systems. The calibration officer will be trained on works on devices and installations subject to calibration regulations and will be familiar with the relevant standards and regulations.
- is authorized to read and take note of values and parameters using the control elements of the EK280, and to perform changes which are not subject to calibration regulations.

6.3 Basic principles

As already explained in the "Construction and Function" chapter, the EK280 can be operated and programmed using the control elements on the front panel of the device.




Fig. 23: Front panel of the EK280



The calibration lock is located on the circuit board built into the housing cover in the form of a button and can be sealed by means of an adhesive label. This button must be pressed in order to adjust the values and parameters protected by configuration regulations. For devices protected by calibration regulations, this may solely be carried out by a calibration officer.

6.3.1 Display

The display is divided into the five registers "Main", "Cust.", "Admin", "Serv." and "Ctrl." under which measurements, settings and other data are displayed.





Fig. 24 Display layout

- | | |
|--|-------------------------|
| 1 Device status | 6 Battery charge status |
| 2 Frozen display | 7 Active register |
| 3 External power supply | 8 Inactive register |
| 4 Reception strength of the external modem | 9 Cursor |
| 5 Reception strength of the internal modem | 10 Data field |

The display in the data field in Fig. 24/10 (starting here with "Vb") is different in each of the registers. All other display sections (in the top part of the screen) remain the same, regardless of the register displayed.

6.3.2 Button functions

The pressure and arrow buttons have the following functions:

| Button | Function |
|---|---|
| ▶ | Jump right to another data list. Jump to the second part of a two-part value. |
| ▼ | Jump down through a data list. |
| ◀ | Jump left to another data list. |
| ▲ | Jump up through a data list. |
| ENTER | Depending on the respective data class, you can: <ul style="list-style-type: none"> – Activate the input mode. – Open the respective sub-menu. – Update the corresponding measurement. |
| ESC | Depending on the respective data class, you can: <ul style="list-style-type: none"> – Leave a sub-menu and jump to its entry value (one menu level up). – Delete an input (input mode). |
| ◀ + ▲ | By pressing both of the buttons at the same time: <ul style="list-style-type: none"> – You can display the "Main" register. – You can set a value in input mode (reset to start value) |
| ◀ + ▶ | – Address display of the current value. |
|  | By pressing the function key, you can: <ul style="list-style-type: none"> – Display the "Main" register. – Freeze the current display. – Delete the status register. |

6.3.3 Data recall, display navigation

Using the arrow keys ►, ◀, ▲, ▼, you can move the cursor ► around the display and switch to the other values.

By pressing the ESC button one or more times, you will be directed to the "Main", "Cust.", "Admin", "Serv." or "Ctrl." registers (→ 6.3.1, Fig. 24). The active register over which the cursor is hovering, is presented with a light-coloured background (Fig. 25/1). In the "register" bar, you can move the cursor to other registers using the arrow keys ► and ◀ to display their content.

The "Cust." register contains more data than can simultaneously be displayed. The arrow key ▼ is used to move the cursor from the register to the data field (the bottom part of the display). By moving the cursor to the lowest visible value, the display can be shifted upwards by re-pressing the ▼ button to display further data. The ▲ button can also be used to move the cursor and therefore the display upwards by moving to the highest visible value.

If the cursor hovers over a value which has been saved with a corresponding timestamp, it will automatically display this value. (Fig. 25/2)




Fig. 25: "Cust." register

- 1 Active register
- 2 Value with corresponding timestamp

6.3.4 Meaning of status symbols

The status symbols displayed in the first line have the following meaning:










Fig. 26: Status symbols in the display

| Symbol | Meaning |
|----------------------|---|
| APTWP | In the upper left-hand side of the screen, individual letters are displayed as symbols for the following signals: |
| ok. | No special message. |
| A | Alarm – Collective message for "any alarm" |
| p | Pressure alarm – The gas pressure cannot be measured |
| T | Temperature alarm – The gas temperature cannot be measured |
| W | Warning – Collective message for "any warning" |
| B | Battery warning – The battery is almost empty |
| L⁴ | Certification data log - The certification data log is full |
| P | Calibration lock ("programming mode") - The calibration lock is open |
| M | Measurement error - The connected gas meter encoder is not giving accurate meter readings |
| o | Online – A data transfer is underway |
| a | Administrator lock is open |

If one of these letters (above) flashes, the indicated status remains active. If one of the letters is displayed constantly, the indicated status is no longer active but must be acknowledged.

For further details on the meaning and potentially necessary procedures, see chapter 8.1.4 "Behaviour in the event of faults"

⁴ If a configuration log is in a device.

| Symbol | Meaning |
|---|--|
|  | Frozen display The displayed values have "frozen" (are not up-to-date). The current values will be displayed after pressing any button. The display freezing can be caused by pressing the function key  . |
|  | External power supply If this symbol appears, the EK280 is being supplied power from an external unit connected to the terminals. |
|  | Signal strength of the radio network for the external modem (connected to the terminals). This symbol will only be shown if an external modem has been connected and is active. |
|  | Signal strength of the radio network for the internal (in-built) modem. This symbol will only be shown if the in-built modem is active. |
|  | Charge status of the battery |

6.3.5 Error messages when entering values

If a value has been entered incorrectly via the keyboard, input error messages will be displayed.

This is shown as follows: --x-- with x = error code according to the following table

| Code | Description |
|------|--|
| 1 | The archive is empty. No values have been entered. |
| 2 | The archive value cannot be read. The archive may already have been opened by the interface for readings. |
| 4 | This parameter cannot be changed (constant). |
| 5 | You are not authorized to change this value. To change this value, a corresponding lock must be opened. |
| 6 | Invalid value The value entered is outside the permissible limits. |
| 7 | Incorrect code The code entered (numerical code) is incorrect; the lock will not be opened. |
| 11 | Input not possible due to special settings or configuration, e.g. - The input of „Vm“ and „VmD“ is not possible in encoder mode. - The calorific value can only be changed in the gas analysis list; not in the energy list. |

| Code | Description |
|------|--|
| 12 | The input of this source (address) is not permitted. |
| 13 | Entry based on specific setting or configuration not possible, e.g.: - This function „Clr.X“ can only be performed once the time has been set to its start value with the key combination ◀ + ▶. - The function „Store“ can only be performed once the change information for comparison of „Vm“ (see chapter 5.3.1.7) or „Vb“ (see chapter 5.3.1.9) has been deleted. |
| 14 | Gas analysis parameters do not correspond. |
| 20 | Value has not been defined for the user-specific display. The displayed value can be defined by the user by entering the address. As this address, has not yet been entered, no value will be displayed. |
| 21 | The value can only be changed when the calibration lock is open as the PTB log is full. |

6.3.6 Access rights

The following parties can access the EK280.

| Access | Meaning |
|------------------|------------------------|
| C | Calibration officer |
| CDL ⁵ | Certification data log |
| A | Administrator |
| Cu | Customer |
| - | No access |

Each access party has one lock and a corresponding key.

The access rights apply for entries made via the keyboard, and for access via the optical, electrical (hard-wired) or integrated modem interface. If the lock is closed, all attempts to enter values will result in a corresponding error message being displayed (see chapter 6.3.5 “Error messages when entering values”).

For data protection reasons, reading values from the interfaces is only possible if one of the locks is open.

⁵ If a configuration log is in a device.

6.3.6.1 Calibration lock

The calibration lock is used to protect parameters subject to calibration regulations. This includes all values which influence volume readings or the volume conversion.

The calibration lock is designed as a button which is positioned inside the EK280 housing underneath the circuit board cover. It can be protected with an adhesive label (see chapter 5.3.1.1).

The calibration lock is opened by pressing the button ("P" symbol flashes in the display) and is closed again by pressing the same button ("P" symbol fades). It can also be closed by deleting the value "St.PL" (see chapter 6.4.6) via the keyboard or interface. Using the configuration software "enSuite", a time can also be set (in minutes) after which the calibration lock will automatically close.

The level of protection can be changed for all parameters upon request, particularly for applications which are not subject to German calibration guidelines or the MID.

For example, parameters which are protected by the calibration lock as standard, can also be protected with an administrator's lock or a certification data log.

6.3.6.2 Certification data log

The certification data log is activated as standard but can also be disabled. The corresponding parameters will then be protected by the calibration lock.

Using the "certification data log" as per PTBA 50.7, several parameters subject to calibration regulations can also be adjusted when the calibration lock is closed. This is subject to the following conditions:

- The administrator's lock (see below) must be open.
- There are at least three free entries in the certification data log.

The following parameters are set as default:

- "cp.l1" cp value for input 1
- "MPer" measurement period
- "Md.K" K-factor mode
- "Clr.A" delete measurement archive
- "Md.l1" mode for input 1
- "qMax" maximum flow (plausibility check in encoder mode)

For every change of a parameter listed under "CDL" when the calibration lock is closed, one row of data will be entered for the value before and after the change.

If the certification data log is full, it can be deleted using the command "CICDL" if the calibration lock is open (see chapter 5.3.1.16).



If the calibration lock is opened when the certification data log is full, it can only be closed again after the certification data log has been deleted.

6.3.6.3 Administrator and customer locks

Administrator and customer locks are used to protect data which is not subject to calibration regulations, but which should also not be modified without authorization.

These locks can be opened by entering a code (i.e. the "key") under "Cod.A" or "Cod.C" and are closed by entering "0" for "St.AL" or "St.CL". These values can be found under the following path:

Admin → Device settings → Access

or *Serv. → Device settings → Access*

A time (in minutes) can also be set here for each lock, after which it will automatically close.

6.4 Data register content

6.4.1 Access rights

The "Access" column in the tables in the following chapter describes which lock must be opened in order to change a parameter. All parameter changes are saved in a log.

| Access | Meaning |
|------------------|------------------------|
| C | Calibration officer |
| CDL ⁶ | Certification data log |
| A | Administrator |
| Cu | Customer |
| - | No access |

6.4.2 "Main" register (main display)

An overview of the most important measurements is presented in the "Main" register. The contents may vary depending on the parameterization (→ chapter 6.4.6.5).

It is not possible to move the cursor to a value in this register⁷. By pressing the "ENTER" button, the displayed values are updated.

| Display | Meaning | Unit | Access | Address |
|---------|----------------------------------|----------------|--------|---------|
| Vb | Volume at base conditions | m ³ | C | 2:300 |
| Vm | Volume at measurement conditions | m ³ | C | 4:300 |
| P | Pressure | bar | - | 7:310_1 |
| K | Compressibility ratio factor | - | - | 8:310 |
| T | Temperature | °C | - | 6:310_1 |
| C | Conversion factor | - | - | 5:310 |

6.4.2.1 Vb – Volume at base conditions

The volume measured by the connected gas meter will be converted into a quantity at base conditions and totalled in this counter.

If there is a fault (see chapter 8 "Faults"), the Vb counter will be stopped and the volume will be totalled in a special disturbance quantity counter.

⁶ If a configuration log is in a device.

⁷ The exception is if the „Main“ tab was set to „List“ (see chapter 6.4.6.5).

6.4.2.2 Vm – Volume at measurement conditions

The volume measured by the connected gas meter will be totalled in this counter.

If there is a fault (see chapter 8 "Faults"), the Vm counter will be stopped and the volume will be totalled in a special disturbance quantity counter. To control the measurements, the Vm can be kept at the same level as the gas meter when putting the device into operation (→ chapter 5.3.1 "Configuration of measurement parameters").

6.4.2.3 p – Gas pressure

The measured gas pressure is used to calculate the volume at base conditions. The pressure is displayed as absolute pressure.

If the pressure cannot be measured due to a fault, an adjustable replacement value is displayed and is used to calculate the disturbance quantity. The replacement value is determined when putting the device into operation (→ chapter 5.3.1 "Configuration of measurement parameters").

6.4.2.4 T – Gas temperature

The measured gas temperature is used to calculate the volume at base conditions.

If the temperature cannot be measured due to a fault, an adjustable replacement value is displayed and is used to calculate the disturbance quantity. The replacement value is determined when putting the device into operation (→ chapter 5.3.1 "Configuration of measurement parameters").

6.4.2.5 K – Compressibility ratio factor

The calculated compressibility ratio factor is used to calculate the volume at base conditions.

The EK280 supports several equations to calculate the compressibility ratio factor. The corresponding equation is determined by the applicable guidelines and standards for the area of application of the device. This can be adjusted at the ordering or commissioning phase (→ chapter 5.3.1 "Configuration of measurement parameters").

6.4.2.6 C – Conversion factor

The currently valid factor for converting the volume at measurement conditions to base conditions.

6.4.3 "Cust." register (Customer)

This register is used to display and check special device settings and conditions. This application is provided for gas customers.

This register can be freely programmed by the user via the enSuite configuration software.

The following parameters are programmed in-house:

| Display | Meaning | Unit | Access | Address |
|---------|--|-------------------|--------|---------|
| Time | Date and time | - | - | 1:400 |
| Vb | Volume at base conditions | m ³ | C | 2:300 |
| Vm | Volume at measurement conditions | m ³ | C | 4:300 |
| p | Pressure | bar | - | 7:310_1 |
| T | Temperature | °C | - | 6:310_1 |
| K | Compressibility ratio factor | - | - | 8:310 |
| C | Conversion factor | - | - | 5:310 |
| SReg | Status register (total) | - | - | 1:101 |
| VbMP↑ | Maximum measurement period counter Vb in the current month | - | - | 3:161 |
| VbDy↑ | Maximum daily counter Vb in the current month | - | - | 4:161 |
| Qb | Flow at base conditions | m ³ /h | - | 2:310 |
| Qm | Actual flow rate | m ³ /h | - | 4:310 |

6.4.3.1 Time - Date and time

The displayed time is updated every 30 seconds in battery mode and every 2 seconds in power supply operation.

6.4.3.2 Values from the "Main" register

- Vb – Volume at base conditions, see chapter 6.4.2.1
- Vm – Volume at measurement conditions, see chapter 6.4.2.2
- p – Gas pressure, see chapter 6.4.2.3
- T – Gas temperature, see chapter 6.4.2.4
- K – Compressibility ratio factor, see chapter 6.4.2.5
- C – Conversion factor, see chapter 6.4.2.6

6.4.3.3 SReg – Status register (total)

In the status register all messages since the last manual clearing are collected. Here, you can also see what has happened, for example, since the last station inspection. The messages can be cleared at the device (Serv. -> Status -> Clr).

Only alarms and warnings (→ chapter 8.2) are displayed in status registers.

6.4.3.4 VbMP↑ – Maximum measurement period counter Vb in the current month

The maximum time stamp is displayed in the following line after moving the cursor to the value "VbMP↑".

The maximum values from the past 15 months can be requested in the monthly archive 1 (see chapter 6.4.4 "Admin" register (Administrator)).

6.4.3.5 VbDy↑ – Maximum measurement period counter Vb at the current day

The time stamp for the maximum value is displayed in the following line when moving the cursor to the value "VbDy↑".

The maximum values from the past 15 months can be requested in the monthly archive 1 (see chapter 6.4.4 "Admin" register (Administrator)).

6.4.3.6 Qb – Flow at base conditions

Current flow at base conditions (standard flow rate)

$$Q_b = Q_m \cdot C \quad \text{with} \quad Q_m = \text{actual flow rate} \\ C = \text{Conversion factor}$$

The maximum inaccuracy of the displayed value roughly corresponds to the maximum inaccuracy of the Q_m .

For the alarm, the Q_b is calculated with the replacement values of the disturbed measurements.

6.4.3.7 Qm – Actual flow rate

Current actual flow rate (measurement flow rate)

The measurement inaccuracy of the displayed actual flow rate is dependent on whether a pulse transducer or encoder is connected:

If a pulse transducer is connected:

For a maximum pulse interval of 15 minutes (at least four pulses per hour) and

$cp.11 \leq 1$, the measurement inaccuracy of Q_m is maximum 1%. For a pulse

interval of more than 15 minutes, $Q_m = "0"$ will be displayed. After the gas flow rate has changed, the precise value can only be displayed if at least two pulses have been transmitted to the gas meter.

If an encoder is connected:

If the meter reading changes every two seconds or less, the measurement inaccuracy of Q_m will be max. 1%.

If the meter reading changes every 200 seconds or less, the measurement inaccuracy will be max. 10%. This can be reduced by decreasing the measurement cycle (Serv. -> Device settings -> Measurement -> MCyc) by up to 2% for MCyc = 4 seconds.

If the meter reading of the encoder does not change after 200 seconds, $Q_m = "0"$ will be displayed.

6.4.4 "Admin" register (Administrator)

This register is used to display and check special device settings and conditions. This application is provided for metering point operator.

| Display | Meaning |
|--------------------------|--|
| User values ⁸ | Sub-menu for user-specific parameters |
| Volume | Sub-menu for volume and the corresponding parameters |
| Volume conversion | Sub-menu for volume conversion and the corresponding parameters |
| Measured values | Sub-menu for measured values and the corresponding parameters |
| Archives | Sub-menu for existing archives in the device |
| Status | Sub-menu for current status, status register and logs |
| Date and time | Sub-menu for date, time and the corresponding parameters |
| Batteries | Sub-menu for the device battery and the corresponding parameters |
| Inputs | Sub-menu for inputs and the corresponding parameters |
| Outputs | Sub-menu for all outputs and the corresponding parameters |
| Interfaces | Sub-menu for device interfaces |
| Device settings | Sub-menu for all device settings |
| Identification | Sub-menu for the identification of the gas system |

⁸ In the "User Values" sub-menu, the user can set up to 10 freely programmable parameters and up to 12 freely programmable parameters in a further sub-menu within this list.

6.4.5 "Serv." register (service)

This register is used to display, check and configure special device settings and conditions. This application is only intended for service technicians (specialists) or a calibration officer for putting the device into operation or maintenance.

| Display | Meaning |
|-------------------|---|
| Volume | Sub-menu for volume and the corresponding parameters |
| Volume conversion | Sub-menu for volume conversion and the corresponding parameters |
| Measured values | Sub-menu for analogue measurements and the corresponding parameters |
| Archives | Sub-menu for existing archives in the device |
| Status | Sub-menu for current status, status register and logs |
| Date and time | Sub-menu for date, time and the corresponding parameters |
| Batteries | Sub-menu for device battery and the corresponding parameters |
| Inputs | Sub-menu for inputs and the corresponding parameters |
| Outputs | Sub-menu for all outputs and the corresponding parameters |
| Interfaces | Sub-menu for device interfaces |
| Device settings | Sub-menu for all device settings |
| Identification | Sub-menu for the identification of the gas system |
| Edit and delete | Sub-menu to activate a range of delete functions |
| Examination | Sub-menu with freeze function and archive with frozen data |
| Data book | Sub-menu with information from the device data book |

6.4.6 "Ctrl." register (Control)

This register is used to monitor special device settings. This application is only intended for service technicians (specialists) or a calibration officer for putting the device into operation or maintenance.

| Display | Value | Unit | Access | Address |
|--------------------|-----------------------------------|------|--------|---------|
| St.AL ⁹ | Administrator lock: State / close | - | - | 3:170 |
| Cod.A ⁹ | Administrator key enter / change | - | - | 3:171 |
| St.PL | Calibration lock: State / close | - | - | 1:170 |
| Menu | Selection of the display menu | - | C | 1:1A1 |
| Main | Content of the "Main" register | - | A | 2:1A1 |

6.4.6.1 St.AL – Administrator lock: State / close

The administrator lock must be opened in order to modify certain measurement parameters. The administrator lock should be closed when in normal operating mode.

| Display | Meaning |
|---------|-----------------------------------|
| locked | The administrator lock is closed. |
| open | The administrator lock is open. |

6.4.6.2 Cod.A – Administrator key enter / change

By entering the right key (hexadecimal notation) the administrator lock can be opened. After the administrator lock is open the key can be changed. The individual characters of the key can take on values from 0 to 9 and from A to F.

6.4.6.3 St.PL – Calibration lock: State/close

The calibration lock must be opened in order to modify certain measurement parameters. The calibration lock should be closed when in normal operating mode.

| Display | Meaning |
|---------|---|
| locked | The calibration lock is closed. |
| open | The calibration lock is open. In this case, the "P" will also flash in the upper left-hand side of the display (see chapter 6.3.4 "Meaning of status symbols") |

6.4.6.4 Menu - Selection of the display menu

In an as-delivered condition, the display of the EK280 has the following five

⁹ When using the device with high communication security („High Level Security“ see application manual), the parameter will not be displayed.

registers: "Main", "Cust.", "Admin", "Serv." and "Ctrl.". Registers can be displayed and hidden for certain purposes using the "Menu" value.

6.4.6.5 Main – Content of the "Main" register

The content of the "Main" display register can be adjusted here.

The default setting is "volume+meas.". This corresponds to the content displayed in chapter 6.3.1.

| Display | Meaning |
|-------------------|--|
| volume+meas. . | <ul style="list-style-type: none"> - The following are displayed: Volume at base conditions, volume at measurement conditions, pressure, temperature, compressibility ratio factor and conversion factor - Format: 8 pre-decimal and 3 post-decimal places for counters - With short descriptions for each value |
| volume short | <ul style="list-style-type: none"> - The following are displayed: Volume at base conditions and volume at measurement conditions - Format: 8 pre-decimal and 3 post-decimal positions respectively - With short descriptions |
| volume long | <ul style="list-style-type: none"> - The following are displayed: Volume at base conditions and volume at measurement conditions - Format: 9 pre-decimal and 4 post-decimal places - Without short descriptions |
| volume,p,T,Q | <ul style="list-style-type: none"> - The following are displayed: Volume at base conditions, volume at measurement conditions, pressure, temperature, flow at base conditions and actual flow rate - Format: 8 pre-decimal and 3 post-decimal places for counters - With short descriptions for each value |
| List | <ul style="list-style-type: none"> - The following are displayed: Volume at base conditions, volume at measurement conditions, total meter reading the original meter reading of the gas meter at Input DE1, pressure, temperature, Conversion factor, compressibility ratio factor, actual flow rate, flow at base conditions, date and time |
| Vb,Vo,meas. | <ul style="list-style-type: none"> - The following are displayed: Volume at base conditions, meter reading of the gas meter (Encoder), pressure, temperature, compressibility ratio factor and conversion factor - Format: 8 pre-decimal and 3 post-decimal places for counters - With short descriptions for each value |

7 Maintenance

7.1 Safety



DANGER!

Danger to life from electrical current!

Touching live parts poses an imminent danger to life. Damage to the insulation or individual components may be life-threatening.

Therefore:

- Safely protect electrical connections and live components against possible human contact.
- In the event of insulation damage, switch off the power supply immediately and arrange for repairs to be carried out.
- Works on the electrical components of the device, i.e. the connection of the external power supply unit, should only be carried out by qualified electricians.
- When performing all works to the electrical system, switch off the power and ensure that the voltage has been cut.
- Before performing maintenance works, switch off the power supply and protect against an accidental restart.
- Do not attempt to bypass or deactivate fuses. When exchanging fuses, ensure that you adhere to the correct ampere rating.
- Keep live parts away from moisture. This could lead to a short-circuit.

**WARNING!****Misuse of batteries may present a risk of injury.**

Special care must be taken when handling batteries.

Therefore:

- Do not throw the batteries into the fire or expose these to high temperatures. There is a risk of explosion.
- Do not charge batteries. There is a risk of explosion.
- Liquids that are produced as a result of misuse may lead to skin irritation. Avoid all contact with liquids. In the event of contact, rinse with large quantities of water. If the liquid enters the eyes, immediately rinse with water for 10 minutes and seek medical attention.

**CAUTION!****Environmentally hazardous substances!**

If environmentally hazardous substances are handled incorrectly this may cause significant damage to the environment, particularly if they are improperly disposed of.

Therefore:

- The instructions below should be observed at all times.
- Appropriate measures should be taken immediately if environmentally hazardous substances are accidentally released into the environment. In cases of doubt, please inform the responsible local authority about the damages.

7.1.1 Personnel

Maintenance works must be carried out correctly.

- The maintenance works described in this document should solely be carried out by specialized electricians (see "Operation" chapter).



WARNING!

Risk of injury if maintenance works are carried out incorrectly.

Incorrect maintenance may lead to serious personal injury or material damage.

Therefore:

- Ensure that there is sufficient assembly space before commencing works.
- Ensure that the installation location is clean and tidy. Components that are loosely stacked or lying around can cause accidents.
- If parts have been removed, ensure that they have been installed correctly, re-mount all fastenings, and adhere to tightening torque values for screws.

7.1.2 Personal protective equipment

- During maintenance works on the device, the necessary personal protective equipment for the work must be worn inside the respective plant.
- The notices relating to personal protective equipment mounted in the working area must be followed at all times.

7.1.3 Environmental protection

Please observe the following notice regarding environmental protection when performing maintenance works:



The batteries used contain toxic heavy metals. These must be treated as special hazardous waste and must be disposed of in municipal waste collection points or by a waste specialist.

7.2 Testing and changing device batteries

7.2.1 Changing and connecting device batteries

**DANGER!**

Using the incorrect batteries may present a risk of explosion!

Connect only the prescribed Elster battery-types to the device (see chapter 9.1.4.

**WARNING!**

Misuse of batteries may present a risk of injury.

Special care must be taken when handling batteries.

Therefore:

- Do not throw the batteries into the fire or expose them to high temperatures. There is a risk of explosion.
- Do not charge the batteries. There is a risk of explosion.
- Liquids that are produced as a result of misuse may lead to skin irritation. Avoid all contact with liquids. In the event of contact with the skin, rinse with plenty of water. If the liquid enters the eyes, immediately rinse with water for 10 minutes and seek medical attention.

**CAUTION!**

Reduced battery power!

The simultaneous use of old and new batteries considerably reduces battery power.

Therefore:

- You should always replace all batteries together.

The batteries can be exchanged without a calibration officer as the housing does not need to be sealed.



In an as-delivered condition, two batteries are connected to the base board of the EK280. To double the service life of the batteries, two additional batteries can be connected.



You should always connect at least two batteries (to X10 and X13 or X11 and X14) to the EK280. This way, the EK280 will continue to work whilst the batteries are being changed.




Fig. 27




Fig. 28



Fig. 29

1. If the external power supply is connected, this should be removed.
2. Loosen the four screws Fig. 27: **1** which are keeping the housing closed.
3. Open the cover of the EK280.
4. Loosen the screws on the battery cover Fig. 28: **1** or **2** and remove the battery cover.
5. Mark the old batteries, e.g. using a felt-tipped pen or stickers.
6. Select the two free connections on the board to connect the new batteries (X10 and X13 or X11 and X14, Fig. 29).
7. Place the new batteries inside (Fig. 28: **1** or **2**).
8. Position the new batteries and secure them using the battery cover.
9. Remove the old batteries from the housing and dispose of these correctly.
10. Close the housing using the screws provided (Fig. 27: **1**).

11. Re-enter the start capacity of the batteries, as described in chapter 7.2.2.
12. Check the calculated service life as described in chapter 7.2.3. At standard measurement conditions (see chapter 3.2.1), the service life should display at least 60 months. If not, compare the settings with those for standard measurement conditions and repeat step 11 if necessary.



Please ensure that the new batteries are connected correctly and are in a fixed position inside the EK280.

**CAUTION!**

Material damage may arise through improper closing of the device!

Improper closing of the device may lead to material damage as a result of cable connections being squashed.

Therefore:

- When closing, ensure that the cable ducts are positioned correctly.

7.2.2 Entering the battery capacity



The battery capacity must be re-entered after changing a battery.

When using the device with high communication security („High Level Security“ see application manual), the battery capacity can only be entered with the enSuite software!

- For opening the administrator lock move the cursor to the "Admin" register and to the "Cod.A" value (enter administrator key) via the following path:

Admin. → Device settings → Access → Cod.A



After delivery of the device, the administrator key for input via keypad is "00000000".

- Press the ENTER button. ⇒ The value will start to flash.
- Move the cursor using the arrow keys ► or ◀ to the digits and change these using the arrow keys ▲ or ▼.
- After you have changed all digits, press the ENTER button to confirm the inputs. The input value can be deleted by pressing the ESC button.
- For entering the battery capacity move the cursor to the "Serv." register and to the "Bat.C" value (battery capacity) via the following path:

Serv. → Batteries → Bat.C

- Press the ENTER button. ⇒ The value will start to flash.
- Move the cursor using the arrow keys ► or ◀ to the digits and change these using the arrow keys ▲ or ▼.



When using two size D batteries, the value 13.0 Ah should be entered for "Bat.C". When using four batteries, the value 26.0 Ah must be entered.

- After you have changed all digits, press the ENTER button to confirm the inputs. The input value can be deleted by pressing the ESC button.
- For closing the administrator lock move the cursor to the "Admin" register and to the "St.AL" value (status administrator lock) via the following path:
Admin. → Device settings → Access → St.AL
- Press the ENTER button. ⇒ "open" will start to flash.
- Move the cursor using the arrow keys ▲ or ▼ to change the value to "locked".
- After you have changed the value, press the ENTER button to confirm the inputs. The input value can be deleted by pressing the ESC button.

7.2.3 Display remaining battery power



The remaining battery power is calculated separately from the consumed power (which is measured) and from the anticipated future consumption (giving the theoretical remaining battery power). Therefore, for applications which are very power-consuming, the remaining battery power may drop quicker than is shown on the battery power display.

The remaining battery power will automatically be recalculated after entering a new battery capacity "Bat.C" (see above). The value cannot be edited.

- Move the cursor to the "Serv." register and to the "Bat.R" value (remaining battery power) via the following path:
Serv. → Batteries → Bat.R



After entering the new battery capacity, a value of at least 60 months will be displayed in standard measurement conditions (see chapter 3.2.1) for "Bat.R".

8 Faults

Possible causes and solutions for device faults will be described in the following chapter.



For faults, which cannot be resolved by the instructions below, please contact our customer service team (see chapter General) or our Electronic Hotline:

Tel. +49 (0) 6134 / 605-123

<http://www.elster-instromet.com/de/support>

E-Mail: ElsterSupport@honeywell.com

8.1 Safety



DANGER!

Danger to life from electrical current!

Touching live parts poses an imminent danger to life.

Damage to the insulation or individual components may be life-threatening.

Therefore:

- In the event of insulation damage, switch off the power supply immediately and arrange for repairs to be carried out.
- Works on the electrical components of the device, i.e. the connection of the external power supply unit, should only be carried out by qualified electricians.
- When performing all works to the electrical system, switch off the power and ensure that the voltage has been cut.
- Before performing maintenance works, switch off the power supply and protect against an accidental restart.
- Keep live parts away from moisture. This could lead to a short-circuit.

8.1.1 Personnel

- The works described below for the elimination of a fault can, unless specified otherwise, be performed by the operator.
- Some works may only be carried out by specially trained professionals or exclusively by manufacturers themselves; special reference will be made to this in the descriptions of individual faults.
- Works on the electrical appliance may only be carried out by qualified electricians.

8.1.2 Personal protective equipment

- When eliminating faults on the device, the necessary personal protective equipment for the work must be worn inside the respective plant.
- The notices relating to personal protective equipment mounted in the working area must be followed at all times.

8.1.3 Improper elimination of faults



WARNING!

Risk of injury through improper elimination of faults!

An improper elimination of faults on the device may lead to serious personal injury or material damage.

Therefore:

- Ensure that there is sufficient assembly space before commencing works.
- Ensure that the installation location is clean and tidy. Components that are loosely stacked or lying around can cause accidents.
- If parts have been removed, ensure that they have been installed correctly, re-mount all fastenings, and adhere to tightening torque values for screws.



The following information on possible faults provide indications as to who is authorized to eliminate the fault.

8.1.4 Behaviour in the event of faults

The following generally applies:

1. If works in the danger zone are necessary, the entire plant must be switched off and protected against an accidental restart.
2. The cause of the fault must be determined.
3. The person responsible for the area in which the fault occurred should be informed immediately.
4. Depending on the type of fault, the manufacturer may have to be contacted and will then have the fault removed by an authorized specialist or will remove the fault themselves.

8.2 Fault and other status messages

Faults (synonymously used here for "alarms") during the operation of the EK280, can be identified by means of status symbols in the first line of the display (see chapter 6.3.4).

You can obtain further information and messages under the current status "Stat" and in the status register "SReg". These can be found:

In the "Cust." register (only "SReg")

Under the path: *Admin* → *Status*

Effects and recommended action in the event of fault and status messages:

| Message | Meaning, action |
|---------------------------|--|
| a) Faults, alarms: | |
| Restart | If this message appears whilst in operation, the device is faulty. Please contact the Elster support (see chapter 1.3 "Customer service"). |
| C-fact. err. | The conversion factor could not be calculated as the measured gas temperature was outside -100°C to +100°C or no usable compressibility ratio factor was available. |
| Data error | An error was detected during the cyclic check of the data subject to calibration regulations. Please contact the Elster support (see chapter 1.3 "Customer service"). |
| T Alarm Lim. | The measured gas temperature is outside the permissible limits. The limit values can be changed when putting the device into operation in the presence of a calibration officer (see chapter 5.3.1.11, page 55) |

| Message | Meaning, action |
|---------------------|--|
| p Alarm Lim. | The measured gas pressure is outside the permissible limits. The limit values can be changed when putting the device into operation in the presence of a calibration officer (see chapter 5.3.1.11, page 55) |
| K-val. error | The compressibility ratio factor could not be calculated as no valid real gas factor could be determined. |
| z-fact. err. | The real gas factor could not be calculated. At least one of the gas analysis values $H_o.n$, CO_2 , H_2 , ρ_{hon} , is outside the permissible range. |
| Vm-Alarm | No volume was recorded at the used input for conversion. (The automatic switchover of the pulse transducer to a second pulse transducer is not configured acc. chapter 5.2.1.4.). |
| Vm-Inp.Alarm | No volume at measurement conditions was recorded at the connected encoder on input 1 for 20 seconds (with ext. power supply) or for two measurement cycle + 1 second (battery powered). |
| T Inp. error | The gas temperature cannot be measured due to a fault. Please contact the Elster support (see chapter 1.3 "Customer service"). |
| p Inp. error | The gas pressure cannot be measured due to a fault. Please contact the Elster support (see chapter 1.3 "Customer service"). |
| b) Warnings: | |
| Data restore | The batteries of the EK280 are intermittently dropping out. As a result of this, the time has not changed and no measurement and volume conversion have happened. However, all data is available. This message appears when old batteries are removed before connecting the new ones (see chapter 7.2). Proceed with the help of the configuration program "enSuite": <ul style="list-style-type: none"> – Set the time of the EK280 – Delete the status register |

| Message | Meaning, action |
|--|---|
| Outp.1 Error Outp.2 Error Outp.3 Error Outp.4 Error | <p>There should be more pulses being emitted from the specified output than are permitted under its configured settings.</p> <p>In order to eliminate the cause of the problem, you can use the configuration program "enSuite" to either:</p> <ul style="list-style-type: none"> – reduce the cp value of the output – or increase the output frequency. <p>In both cases, the change must be aligned with the connected device.</p> |
| I1-Warning | The encoder could not be read at the end of the measurement period. The flow recording at this point is invalid. |
| I2 Pulse cmp | In the pulse comparison, e.g. between input 1 and input 2, the deviation was too high. |
| W Warn Lim. | <p>The displayed value is outside the set warning limit values.</p> <p>The warning limits can be adjusted using the configuration program "enSuite".</p> |
| Vb Warn Lim. | <p>The monitored volume at base conditions consumption value (standard: hourly consumption) is outside the set warning limit values.</p> <p>The monitored values and the warning limits can be adjusted using the configuration program "enSuite".</p> |
| Vc Warning | The parameters for the corrected volume at measurement conditions are not sorted in ascending order or one of the values is outside the permissible limits. |
| Qm Warn Lim. | The actual flow rate (gas flow rate) is outside the set warning limit values. The warning limits can be adjusted using the configuration program "enSuite". |
| T Warn Lim. | <p>The measured gas temp. is outside the warning limit values.</p> <p>The warning limits can be adjusted using the configuration program "enSuite".</p> |
| p Warn Lim. | <p>The measured gas pressure is outside the warning limit values.</p> <p>The warning limits can be adjusted using the configuration program "enSuite".</p> |

| Message | Meaning, action |
|--|--|
| z Warning | The sum of gas analysis values for AGA-8 DC92 is more or less than 100%. An accurate calculation of the real gas factor and the compressibility ratio factor can therefore not be carried out. |
| Vm warning | If a HF-NF switch is configured, then this message is enabled in the event of a fault at the HF input, e.g. loss of external power supply. |
| Update error | Before the software update, an error was detected in the cached software image. |
| Softw. error | This message is used for factory diagnosis. Please contact the Elster support (see chapter 1.3 "Customer service"). |
| Sett. error | The programming of the device has generated an unusable combination of settings. Please contact the Elster support (see chapter 1.3 "Customer service"). |
| I2 Warn.sig. I3 Warn.sig. I4 Warn.sig. I5 Warn.sig. I6 Warn.sig. | If an input has been configured as a warning input, this message will be displayed if an active signal appears at the corresponding terminal (e.g. terminal DE2). The input configuration can be adjusted using the configuration program "enSuite". |
| T2 Warn Lim. | The measured gas temperature of the second sensor is outside the set warning limit values. The warning limits can be adjusted using the configuration program "enSuite". |
| p2 Warn Lim. | The measured gas pressure of the second sensor is outside the set warning limit values. The warning limits can be adjusted using the configuration program "enSuite". |
| Batt. low | The remaining battery power is less than six months. The batteries need to be changed soon. |
| c) Signals: | |
| TA Warn Lim. | The measured ambient temperature is outside the set warning limit values. The warning limits can be adjusted using the configuration program "enSuite". |
| Repair mode | The device is in revision mode. |
| Clock n. set | The internal clock of the volume corrector has not been adjusted at the factory. |

| Message | Meaning, action |
|--|---|
| Encoder err. | No volume at measurement conditions was recorded at the connected encoder on input 1 for 20 seconds (with ext. power supply) or for one measurement cycle + 1 second (battery powered). |
| CDL full | The certification data log is full. Changing the parameters marked with "CDL" without a calibration lock is only possible if the content of the certification data log has been deleted. |
| U.Logb. full | The software update log is full. An update is only possible if the content of the software update log has been deleted. |
| online | Data is currently being transmitted via an interface (modem, optical interface, terminal interface or Ethernet adapter). If this message is displayed, the "o" will flash in the "Status" field of the display (see chapter 6.3.4, page 67). |
| I2-Rep.sig I3-Rep.sig I4-Rep.sig I5-Rep.sig I6-Rep.sig | If an input has been configured as a signal input, this message will be displayed if an active signal has appeared at the corresponding terminal (e.g. terminal DE2). The input configuration can be adjusted using the configuration program "enSuite". |
| Cal.lock | The calibration lock is open. In normal operating conditions, the calibration lock should be closed to prevent unauthorized changes. To close the calibration lock, please go to Ctrl. → St.PL and enter the value "0". |
| Admin.lock Cust.lock o. | The administrator / customer lock is open. |
| Bat. operat. | The EK280 is in battery mode. This signal is primarily used to inform a remote data transmission system that the batteries run down more quickly during long periods of data transmission. |
| Dayl.Sav.Tim | The time displayed in volume corrector is daylight saving time. The switchover mode can be changed using the configuration program "enSuite". |

| Message | Meaning, action |
|--|--|
| Call Win.1 Call Win.2 Call Win.3 Call Win.4 Call Win.5 Call Win.6 | The specified call pickup time is active, i.e. the volume corrector will accept data transmission calls. |

NOT UP-TO-DATE
www.docuthek.com

9 Appendix

9.1 List of spare parts and accessories



Images of the spare parts and accessories described below can be found in the manufacturer's catalogue which is available to order under www.elster-instromet.com.

9.1.1 Fastening elements

| Spare parts and accessories | Order no. |
|--|------------|
| Set mounting bracket EK220/280 for MI-2 | 73 021 952 |
| Set mounting bracket EK220/280 for Rabo | 73 021 953 |
| Set mounting bracket EK280 for S1/Encoder | 73 021 954 |
| Set Bracket EK/DL for pipe mounting | 73 021 955 |
| Universal bracket with pipe clamps for pipe mounting | 73 018 057 |
| Mounting bracket for meter head S1D | 73 021 050 |



When ordering the universal bracket with pipe clamps for pipe mounting, please specify the pipe diameter.

9.1.2 Pressure connections

| Spare parts and accessories | Order no. |
|--------------------------------------|------------|
| Shut-off valve with t-piece | 03 152 266 |
| Three-way check valve | 73 008 403 |
| Pressure pipe C2 Ø6 x 700 mm | 73 017 659 |
| Pressure pipe C5 Ø6 x 400 mm | 73 017 656 |
| Minimess test connections (adapters) | 73 016 167 |

9.1.3 Temperature sensor pockets

| Spare parts and accessories | Order no. |
|--|------------|
| Temp. sensor pocket EBL 50, with welded sockets M10 x 1 | 73 012 634 |
| Temp. sensor pocket EBL 67, with welded sockets M10 x 1 | 73 014 456 |
| Temp. sensor pocket EBL 160, with welded sockets G 3/4" and sealing ring | 73 012 100 |
| Temp. sensor pocket EBL 250, with welded sockets G 3/4" and sealing ring | 73 015 695 |

| | |
|---|------------|
| Sealing sleeve for the connection of an old temp. sensor pocket EBL 45, 50 and 67 | 73 019 951 |
| Sealing sleeve for the connection of an old temp. sensor pocket EBL 160 and 250 | 73 019 950 |

9.1.4 Small parts and miscellaneous

| Spare parts and accessories | Order no. |
|--|------------------|
| Sealing sleeve for pressure connection and temp. sensor | 73 017 997 |
| Connecting cable for two low frequency pulser transducers, approx. 700 mm long | 73 017 093 |
| Device battery module 13 Ah | 73 015 774 |
| Device battery module 13 Ah ¹⁰ | 730 23 225 |
| 16 Ah battery module for the modem of the EK280 without integrated power supply unit | 73 021 211 |
| 13 Ah battery module for connection to the integrated power supply unit (modem battery mode in the event of power failure) | 73 017 964 |
| Ext. GSM antenna, 3 m connecting cable, SMA connector | 04 407 115 |
| Ext. GSM antenna, 5 m connecting cable, SMA connector | 04 407 116 |
| Ext. GSM antenna, 10 m connecting cable, SMA connector | 04 407 117 |
| 10 m antenna extension cable with SMA connector | 73 020 149 |
| 2G/3G stub antenna, SMA, straight | 04 407 113 |
| Breather Drain Plug for outdoor application | 73 020 775 |

9.1.5 Documentation

| Spare parts and accessories | Order no. |
|------------------------------------|------------------|
| German manual | 73 021 805 |
| English manual | 73 021 209 |

¹⁰ After consultation for special applications.

9.2 EC Declaration of Conformity



EU Declaration of Conformity No. **DEMZE1719**
EU-Konformitätserklärung Nr.

Honeywell

Type, Model
Typ, Ausführung

EK280

Manufacturer
Hersteller

Elster GmbH, Postfach 1880, D - 55252 Mainz-Kastel; Steinern Straße 19-21

Product
Produkt

Volume conversion device
Zustands-Mengenumwerter

The object of the declaration described above is in conformity with the relevant Union harmonisation legislation:
Der oben beschriebene Gegenstand der Erklärung erfüllt die einschlägigen Harmonisierungsrechtsvorschriften der Union.

| | | | | | |
|---------------------|---------------------|----------------------|----------------------|---------------------|----------------------|
| 2014/32/EU (MID) | 2014/30/EU (EMC) | 2014/34/EU (ATEX) | 2014/34/EU (ATEX) | 2014/53/EU (RED) | 2011/65/EU (RoHS) |
|---------------------|---------------------|----------------------|----------------------|---------------------|----------------------|

Relevant harmonised standards used:

Einschlägige harmonisierte Normen, die zugrunde gelegt wurden:

| | | | | | |
|---|-----------------|--|---|--|---------------|
| EN 12405-1:2011-04, OIML D11 Edition 2004 (E) | EN 61326-1:2013 | EN 60079-0:2012 + A11:2013, EN 60079-11:2012 | EN 60079-0:2012 + A11:2013, EN 60079-15:2010, EN 60079-11:2012 | EN 301511 V9.0.2, EN 301908-1 V11.1.1, EN 301908-2 V11.1.1 | EN 50581:2012 |
|---|-----------------|--|---|--|---------------|

Certificates and interventions by notified bodies:

Bescheinigungen und Maßnahmen durch notifizierte Stellen:

| | | | | | |
|---|---|--|---|---|---|
| T10339 | - | LCIE 11 ATEX 3027 X | LCIE 12 ATEX 1015 X | - | - |
| EC-type Examination EG-Baumusterprüfung | | EC-type Examination EG-Baumusterprüfung | Voluntary supplementary Type Examination Freiwillige ergänzende Baumusterprüfung | | |
| Notified Body 0122 NMI Certin B.V. Hugo de Grootplein 1 NL-3314 EG Dordrecht | | Notified Body 0081 Bureau Veritas LCIE 33, avenue du Général Leclerc F-92260 Fontenay-aux-Roses | | | |

This declaration of conformity is valid for products labelled accordingly:

Diese Konformitätserklärung gilt für entsprechend gekennzeichnete Produkte:

| | | | | | |
|----------|--|---------------------------------|--|--|--|
| M... 102 | | 0044 | | | |
| T10339 | | II 1 G Ex ia IIB T4 or T3 Ga | II 3 G Ex nA IIC T6 Gc II 3(3) G Ex nA[ic] IIC T6 Gc | | |

The production is subject to the following surveillance procedures:

Die Herstellung unterliegt folgenden Überwachungsverfahren:

| | | | | |
|--|--|--|--|---|
| Directive Module D Richtlinie Modul D | Directive Module C Richtlinie Modul C | Directive Annex IV + VII Richtlinie Anhang IV + VII | Directive Annex II Richtlinie Anhang II | Directive Article 7 Richtlinie Artikel 7 |
| Notified Body 0102 Physikalisches Technische Bundesanstalt (PTB) D-38116 Braunschweig | | Notified Body 0044 TÜV NORD CERT GmbH D-30519 Hannover | | |

This declaration of conformity is issued under the sole responsibility of the manufacturer. If alterations are made to the product or it is modified, this declaration becomes void with immediate effect.

Die alleinige Verantwortung für die Ausstellung dieser Konformitätserklärung trägt der Hersteller. Bei Umbau des Produkts oder Änderungen am Produkt verliert diese Erklärung mit sofortiger Wirkung ihre Gültigkeit.

Elster GmbH

Mainz-Kastel, 24.08.2017

Signed for and on behalf of
Unterszeichnet für und im
Namen von

Place and date of issue
Ort und Datum der
Ausstellung

Piet Plattschorre,
Managing Director, General
Manager PMC Europe

Jörg Kern,
Sr R&D Manager
Gas Metering

9.3 ATEX Type Examination Certificate

9.3.1 Zone 0, 1



ATTESTATION D'EXAMEN UE DE TYPE


EU TYPE EXAMINATION CERTIFICATE



| 1 Version : 05 | | LCIE 11 ATEX 3027 X | | Issue : 05 | |
|----------------------|--|--|--|----------------------|--|
| Directive 2014/34/UE | | | | Directive 2014/34/EU | |
| 2 | Appareil ou Système de Protection destiné à être utilisé en Atmosphères Explosibles | Equipment or Protective System Intended for use in Potentially Explosive Atmospheres | | | |
| 3 | Produit : Convertisseur de volume | Product : Volume conversion device | | | |
| | | Type: EK280 | | | |
| 4 | Fabricant : | Manufacturer : ELSTER GMBH | | | |
| 5 | Adresse : | Address : Steinern Straße 19-21 55252 Mainz-Kastel Germany | | | |
| 6 | Ce produit et ses variantes éventuelles acceptées sont décrits dans l'annexe de la présente attestation et dans les documents descriptifs cités en référence. | This product any acceptable variation thereto is specified in the schedule to this certificate and the documents therein referred to. | | | |
| 7 | Le LCIE, Organisme Notifié sous la référence 0081 conformément à l'article 17 de la directive 2014/34/UE du Parlement européen et du Conseil du 26 février 2014, certifie que ce produit est conforme aux Exigences Essentielles de Sécurité et de Santé pour la conception et la construction de produits destinés à être utilisés en atmosphères explosibles, données dans l'annexe II de la Directive. Les résultats des vérifications et essais figurent dans le(s) rapport(s) confidentiel(s) N° : | LCIE, Notified Body number 0081 in accordance with article 17 of the Directive 2014/34/EU of the European Parliament and the Council of 26 February 2014 certifies that product has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of products intended for use in potentially explosive atmospheres, given in Annex II to the Directive. The examination and test results are recorded in confidential report(s) N° : 121241-642207-01; 137850-677466-01; 144186-692011 | | | |
| 8 | Le respect des Exigences Essentielles de Sécurité et de Santé est assuré par la conformité à : | Compliance with the Essential Health and Safety Requirements has been assured by compliance with : EN 60079-0:2012 + A11:2013 EN 60079-11:2012 | | | |
| 9 | Le signe « X » lorsqu'il est placé à la suite du numéro de l'attestation, indique que cet appareil est soumis aux conditions particulières d'utilisation, mentionnées dans l'annexe de cette attestation. | If the sign "X" is placed after the certificate number, it indicates that the product is subject to the Specific Conditions of Use specified in the schedule to this certificate. | | | |
| 10 | Cette Attestation d'Examen UE de Type concerne uniquement la conception et la construction du produit spécifié. Des exigences supplémentaires de la directive sont applicables pour la fabrication et la fourniture du produit. Ces dernières ne sont pas couvertes par la présente attestation. | This EU Type Examination Certificate relates only to the design and construction of the specified product. Further requirements of the Directive apply to the manufacturing process and supply of this product. These are not covered by this certificate. | | | |
| 11 | Le marquage du produit est mentionné dans l'annexe de cette attestation. | The marking of the product is specified in the schedule to this certificate. | | | |

Fontenay-aux-Roses, le 25 novembre 2016

Responsable de Certification
Certification Officer



LABORATOIRE CENTRAL des

INDUSTRIES ELECTRIQUES

S.A.S au capital de 15.745.984 €

RCS Nanterre B 408 363 174

33 avenue du Général Leclerc

F - 92266 FONTENAY-AUX-ROSES

Seul le texte en français peut engager la responsabilité du LCIE. Ce document ne peut être reproduit que dans son intégralité, sans aucune modification. Il est établi en accord avec le référentiel de certification ATEX du LCIE. The LCIE's liability applies only on the French text. This document may only be reproduced in its entirety and without any change. It is issued in accordance with LCIE's ATEX Certification Rules.
CERT-ATEX-FORM 04 Rev. 02



ATTESTATION D'EXAMEN UE DE TYPE - ANNEXE

EU TYPE EXAMINATION CERTIFICATE - SCHEDULE

1 Version : 05

LCIE 11 ATEX 3027 X

Issue : 05

12 DESCRIPTION DU PRODUIT

L'appareil est un convertisseur de volume destiné à mesurer, enregistrer et surveiller des paramètres variables fournis par des compteurs de gaz ou des capteurs de température ou de pression.

L'appareil se compose principalement :

- d'une enveloppe en aluminium,
- d'un module LCD,
- d'une carte CPU alimentée par une source externe ou par un ou deux packs de batterie (optionnel: quatre packs de batteries montés 2x2 en série),
- d'une carte modem-adaptateur, alimentée par un pack de batterie, équipée d'un module radio interne (optionnel) et d'une antenne pour la communication sans fil des données,
- des capteurs de température ou de pression, internes ou externes,
- et des bornes pour l'alimentation ou la communication des données.

Les composants Ex suivants sont évalués dans le cadre de l'appareil :

| Désignation du produit <i>Designation of product</i> | Fabricant <i>Manufacturer</i> | Type | Document de référence <i>Document of reference</i> |
|---|----------------------------------|-----------------------------------|---|
| Module radio / <i>Radio module</i> | Elster | ECM-GW 120 | LCIE 10 ATEX 3026U |
| Module radio / <i>Radio module</i> | Elster | ECM-2G-UG350 ou / or ECM-3G-UU270 | LCIE 16 ATEX 3047U |
| Fusible / <i>Fuse</i> | Littelfuse | Safe-T-Plus 0259 series | BASEEFA 02 ATEX 0071U |

Paramètres spécifiques du ou des modes de protection concerné(s) :

Les piles utilisées dans l'appareil sont les suivantes :

- carte CPU: Elster N°73015774, N°73020663 ou N°73023225.
- carte modem-adaptateur: Elster N°73021211

DESCRIPTION OF PRODUCT

The equipment is a volume conversion device intended to measure, record and monitor variable parameters provided from gas meters, pressure or temperature sensors.

The equipment consists mainly of:

- an aluminum housing,
- a LCD module,
- CPU board powered by external supply or by one or two battery packs (optional: four battery packs connected 2x2 in series),
- Modem-adaptor board, powered by battery pack, equipped with internal radio-module (optional) and an antenna for wireless data communication,
- internal or external temperature or pressure sensors,
- and terminals for power supply or data communication.

The following Ex components are assessed as part of the equipment:

Specific parameters of the concerned protection mode:

Batteries used within the apparatus are as follows:

- CPU board: Elster N°73015774, N°73020663 or N°73023225.
- Modem-adaptor board: Elster N°73021211

| Connecteur / <i>Connector</i> | Paramètres électriques / <i>Electrical parameters</i> | | | | | |
|-------------------------------|---|--------------------------|-------------------------|------------------------|-------------------------|--|
| Uext | U: 30 V | I: 140 mA | P: 0.5 W | C: 0 | L: 0 | |
| DA1, DA2, DA3, DA4 | U: 30 V | I: 140 mA | P: 0.5 W | C: 13.2 nF | L: 6 µH | |
| DDO Rx/D | U: 30 V | I: 140 mA | P: 0.5 W | C: 0 | L: 0 | |
| RI | U: 30 V | I: 140 mA | P: 0.5 W | C: 8.9 nF | L: 0 | |
| DE1, DE2 | U ₀ : 9.7 V | I ₀ : 19.7 mA | P ₀ : 48 mW | C ₀ : 24 µF | L ₀ : 367 mH | |
| DE3, DE4 | U ₀ : 9.7 V | I ₀ : 21 mA | P ₀ : 51 mW | C ₀ : 24 µF | L ₀ : 322 mH | |
| DE5, DE6 | U ₀ : 9.7 V | I ₀ : 1.0 mA | P ₀ : 2.4 mW | C ₀ : 24 µF | L ₀ : 142 H | |
| DTR Tx/D | U ₀ : 9.7 V | I ₀ : 87 mA | P ₀ : 211 mW | C ₀ : 24 µF | L ₀ : 18 mH | |

DETAIL DE LA GAMME

Un seul modèle.

RANGE DETAILS

Only one model.

MARQUAGE

Le marquage du produit doit comprendre :

Elster GmbH

Adresse : ...

Type : EK280

N° de fabrication : ...

Année de fabrication : ...

MARKING

The marking of the product shall include the following :

Elster GmbH

Address: ...

Type: EK280

Serial number: ...

Year of construction: ...

Seul le texte en français peut engager la responsabilité de LCIE. Ce document ne peut être reproduit que dans son intégralité, sans aucune modification. Il est établi en accord avec le référentiel de certification ATEX de LCIE. The LCIE's liability applies only on the French text. This document may only be reproduced in its entirety and without any change. It is issued in accordance with LCIE's ATEX Certification Rules.

CERT-ATEX-FORM 04 Rev. 02

Page 2 of 4

LCIE

Laboratoire Central des Industries Electriques
Une société de Bureau Veritas

33 Avenue du Général Leclerc
92260 Fontenay-aux-Roses
FRANCE

WWW.LCIE.FR



ATTESTATION D'EXAMEN UE DE TYPE - ANNEXE
EU TYPE EXAMINATION CERTIFICATE - SCHEDULE

1 Version : 05 LCIE 11 ATEX 3027 X Issue : 05

II 1 G
Ex ia IIB T4 Ga (sans module-radio)
Ex ia IIB T3 Ga (avec module-radio)
LCIE 11 ATEX 3027 X
Tamb : -40°C à +60°C
U_i : ..., I_i : ..., P_i : ..., C_i : ..., L_i : ..., (*)
U_o : ..., I_o : ..., P_o : ..., C_o : ..., L_o : ..., (*)
AVERTISSEMENT :
- UTILISER UNIQUEMENT DES BATTERIES ELSTER
N°73015774, N°73020663, N°73021211 et N°73023225
- DANGER POTENTIEL DE CHARGES
ELECTROSTATIQUES – VOIR INSTRUCTIONS.
(*) : complété par des paramètres électriques des connecteurs

L'appareil doit également comporter le marquage normalement prévu par les normes de construction qui le concernent sous la responsabilité du fabricant.

13 CONDITIONS PARTICULIERES D'UTILISATION

- a. Les connecteurs de sécurité intrinsèque de l'appareil ne doivent être raccordés qu'à des appareils certifiés de sécurité intrinsèque ou à des appareils simples. Cette association doit être compatible vis-à-vis de la sécurité intrinsèque.
- b. Les connecteurs X23 et X24 ne doivent pas être utilisés en zone explosible.
- c. Les connecteurs U_{ext} sur la carte Modem-adaptateur et X9 sur la carte CPU ne doivent pas être utilisés en zone explosible.
- d. Les connecteurs X17 et X18 ne peuvent être connectés qu'aux capteurs de température définis par le fabricant dans le dossier technique.
- e. Les connecteurs X7, X15, X16, X28, X29 et X30 ne peuvent être connectés qu'aux capteurs de pression définis par le fabricant dans le dossier technique.
- f. Paramètres électriques des connecteurs d'un autre matériel ou capteur certifié de sécurité intrinsèque pouvant être raccordé aux connecteurs de l'EK280 :

| Connecteur de l'EK280 Connector of EK280 | Paramètres électriques des connecteurs d'un autre matériel certifié de sécurité intrinsèque Electrical parameters of connectors from another intrinsically safe certified equipment or sensor | | | | |
|---|--|--------------------------|-------------------------|--|---|
| U _{ext} | U ₀ ≤ 30 V | I ₀ ≤ 140 mA | P ₀ ≤ 0.5 W | C ₀ - C _{0max} ≥ 0 | L ₀ - L _{0max} ≥ 0 |
| DA1, DA2, DA3, DA4 | U ₀ ≤ 30 V | I ₀ ≤ 140 mA | P ₀ ≤ 0.5 W | C ₀ - C _{0max} ≤ 13.2 nF | L ₀ - L _{0max} ≤ 6 μH |
| DOD Rx/D | U ₀ ≤ 30 V | I ₀ ≤ 140 mA | P ₀ ≤ 0.5 W | C ₀ - C _{0max} ≥ 0 | L ₀ - L _{0max} ≥ 0 |
| RI | U ₀ ≤ 30 V | I ₀ ≤ 140 mA | P ₀ ≤ 0.5 W | C ₀ - C _{0max} ≤ 8.9 nF | L ₀ - L _{0max} ≤ 0 |
| DE1, DE2 | U ₀ ≥ 9.7 V | I ₀ ≥ 19.7 mA | P ₀ ≥ 48 mW | C ₀ + C _{0max} ≤ 24 μF | L ₀ + L _{0max} ≤ 367 mH |
| DE3, DE4 | U ₀ ≥ 9.7 V | I ₀ ≥ 21 mA | P ₀ ≥ 51 mW | C ₀ + C _{0max} ≤ 24 μF | L ₀ + L _{0max} ≤ 322 mH |
| DE5, DE6 | U ₀ ≥ 9.7 V | I ₀ ≥ 1.0 mA | P ₀ ≥ 2.4 mW | C ₀ + C _{0max} ≤ 24 μF | L ₀ + L _{0max} ≤ 142 H |
| DTR Tx/D | U ₀ ≥ 9.7 V | I ₀ ≥ 87 mA | P ₀ ≥ 211 mW | C ₀ + C _{0max} ≤ 24 μF | L ₀ + L _{0max} ≤ 18 mH |

C_{0max}, L_{0max} : valeur maximale de capacité et d'inductance du câble de liaison entre EK280 et un autre matériel certifié de sécurité intrinsèque.

C_{0max}, L_{0max} : maximum value of capacitance and inductance of the connected cable between EK280 and intrinsically safe certified equipment.

- g. L'enveloppe de l'appareil contient plus de 10% aluminium. Elle doit être montée de manière à éviter le risque d'étincelle par frottement ou impact.

II 1 G
Ex ia IIB T4 Ga (without radio-module)
Ex ia IIB T3 Ga (with radio-module)
LCIE 11 ATEX 3027 X
Tamb : -40°C to +60°C
U_i : ..., I_i : ..., P_i : ..., C_i : ..., L_i : ..., (*)
U_o : ..., I_o : ..., P_o : ..., C_o : ..., L_o : ..., (*)
WARNING:
- USE ONLY ELSTER N°73015774, N°73020663, N°73021211 and N°73023225 BATTERIES
- POTENTIAL ELECTROSTATIC CHARGING HAZARD – SEE INSTRUCTIONS.
(*) : completed with electrical parameters of connectors.

The equipment shall also bear the usual marking required by the product standards applying to such equipment under the manufacturer responsibility.

SPECIFIC CONDITIONS OF USE

The intrinsically safe connectors of equipment shall only be connected to certified associated intrinsically safe equipment or simple apparatus. This combination must be compatible as regards the intrinsically safe rules.
Connectors X23 and X24 cannot be used in hazardous area.

Connectors U_{ext} on Modem-adaptor board and X9 in CPU board cannot be used in hazardous area.

Connectors X17 and X18 can only be connected to temperature sensors defined by the manufacturer in technical file.

Connectors X7, X15, X16, X28, X29 and X30 can only be connected to pressure sensors defined by the manufacturer in technical file.

Electrical parameters of connectors from another intrinsically safe certified equipment or sensor that can be connected to the connectors of EK280:

The equipment housing contains more than 10% in total of aluminium. It must be mounted in such a manner as to eliminate the risk of sparks caused by friction or impact.

14 EXIGENCES ESSENTIELLES DE SANTE ET DE SECURITE

Couvertes par les normes listées au point 8.

ESSENTIAL HEALTH AND SAFETY REQUIREMENTS

Covered by standards listed at 8.

Seul le texte en français peut engager la responsabilité de LCIE. Ce document ne peut être reproduit que dans son intégralité, sans aucune modification. Il est établi en accord avec le référentiel de certification ATEX de LCIE. The LCIE's liability applies only on the French text. This document may only be reproduced in its entirety and without any change. It is issued in accordance with LCIE's ATEX Certification Rules.
CERT-ATEX-FORM 04 Rev. 02



ATTESTATION D'EXAMEN UE DE TYPE - ANNEXE

EU TYPE EXAMINATION CERTIFICATE - SCHEDULE

1 Version : 05

LCIE 11 ATEX 3027 X

Issue : 05

15 DOCUMENTS DESCRIPTIFS**DESCRIPTIVE DOCUMENTS**

| N° | Description | Reference | Rev. | Date | Page(s) |
|----|------------------|-----------|------|------------|---------|
| 1. | Technical file | EE0254 | 2 | 2016-11-02 | 288 |
| 2. | Operating manual | 73021209 | b | 2013-10-25 | 91 |

16 INFORMATIONS COMPLEMENTAIRES**ADDITIONAL INFORMATION****Essais individuels**

Néant.

Routine tests

None.

Conditions de certification

Les détenteurs d'attestations d'examen UE de type doivent également satisfaire les exigences de contrôle de production telles que définies à l'article 13 de la Directive 2014/34/UE.

Conditions of certification

Holders of EU type examination certificates are also required to comply with the production control requirements defined in article 13 of Directive 2014/34/UE.

En accord avec l'Article 41 de la Directive 2014/34/UE, les attestations d'examen CE de type mentionnant la Directive 94/9/CE émises avant la date d'application de la Directive 2014/34/UE (20 avril 2016) peuvent être considérées comme émises en accord avec la Directive 2014/34/UE. Les nouvelles versions de ces attestations peuvent conserver le numéro de l'attestation d'origine émise avant le 20 avril 2016.

In accordance with Article 41 of Directive 2014/34/UE, EC-Type Examination Certificates referring to Directive 94/9/EC that were in existence prior to the date of application of Directive 2014/34/UE (20 April 2016) may be referenced as if they were issued in accordance with Directive 2014/34/UE. New issues of such certificates may continue to bear the original certificate number issued prior to 20 April 2016.

17 DETAILS DES MODIFICATIONS**DETAILS OF CHANGES**

Version 00 : Evaluation de la conformité selon les normes
 (20/04/2011) EN 60079-0:2009 et EN 60079-11:2007.

Issue 00:
 (2011/04/20) Conformity assessment according to EN 60079-0:2009 and EN 60079-11:2007 standards.

Version 01 : Modification de composants.

Issue 01:
 (2012/07/13) Modification of components.

Version 02 : Carte modem-adaptateur Q24 :
 (30/08/2012) - Modification de composants.

Issue 02:
 (2012/08/30) Q24 modem-adaptor board:
 - Modification of components.

- Modification du circuit imprimé.

- Modification of the printed board.

- Mise à jour des documents.

- Update of documents.

Version 03 : Modification de valeurs de résistances.

Issue 03:
 (2014/08/20) - Modification of some resistor values.

(20/08/2014) - Mise à jour normative selon les normes
 EN 60079-0:2009 et EN 60079-11:2012.

- Normative update according to
 EN 60079-0:2009 and EN 60079-11:2012 standards.

Version 04 : - Ajout de la batterie Tekcell comme une
 (28/01/2016) alternative pour l'alimentation de la carte
 CPU.

Issue 04:
 (2016/01/28) - Addition of Tekcell battery as alternative
 supply for CPU board.

- Mise à jour normative selon la norme
 EN 60079-0:2012 + A11:2013.

- Normative update according to
 EN 60079-0:2012 + A11:2013 standard.

Version 05 : Ajout d'une nouvelle carte modem-adaptateur
 équipée du module radio certifié ECM-2G-
 UG350 ou ECM-3G-UU270.

Issue 05:
 Addition of new Modem-adaptor board
 equipped with Ex certified radio module ECM-
 2G-UG350 or ECM-3G-UU270.

Seul le texte en français peut engager la responsabilité du LCIE. Ce document ne peut être reproduit que dans son intégralité, sans aucune modification. Il est établi en accord avec le référentiel de certification ATEX du LCIE. The LCIE's liability applies only on the French text. This document may only be reproduced in its entirety and without any change. It is issued in accordance with LCIE's ATEX Certification Rules.
 CERT-ATEX-FORM 04 Rev. 02

Page 4 of 4

LCIE

Laboratoire Central des Industries Electriques

Une société de Bureau Veritas

33 Avenue du Général Leclerc

92260 Fontenay-aux-Roses

FRANCE

WWW.LCIE.FR



ATTESTATION D'EXAMEN UE DE TYPE EU TYPE EXAMINATION CERTIFICATE



1 Version : 06

LCIE 11 ATEX 3027 X

Issue : 06

- Directive 2014/34/UE**
Appareil ou Système de Protection destiné à être utilisé en Atmosphères Explosibles
- Equipment or Protective System Intended for use in Potentially Explosive Atmospheres**
- Produit :
Convertisseur de volume
- Product :
Volume conversion device
- Type: EK280
- Fabricant :
ELSTER GmbH
- Manufacterur :
Address :
Steinern Straße 19-21
55252 Mainz-Kastel
GERMANY
- Adresse :
- This product and any acceptable variations thereto are specified in the schedule to this certificate and the documents therein referred to.
- LCIE, Notified Body number 0081 in accordance with article 17 of the Directive 2014/34/EU of the European Parliament and the Council of 26 February 2014 certifies that product has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of products intended for use in potentially explosive atmospheres, given in Annex II to the Directive.
- Les résultats des vérifications et essais figurent dans le(s) rapport(s) confidentiel(s) N°
101963-602949; 114997-928941; 115333-629915; 121241-642207-01; 137850-677466-01; 144186-692011; 157464-727343.
- The examination and test results are recorded in confidential report(s) N°
- Le respect des Exigences Essentielles de Sécurité et de Santé est assuré par la conformité à :
EN 60079-0:2012 + A11:2013, EN 60079-11:2012
- Compliance with the Essential Health and Safety Requirements has been assured by compliance with :
- If the sign "X" is placed after the certificate number, it indicates that the product is subject to the Specific Conditions of Use specified in the schedule to this certificate.
- Cette Attestation d'Examen UE de Type concerne uniquement la conception et la construction du produit spécifié.
Des exigences supplémentaires de la directive sont applicables pour la fabrication et la fourniture du produit. Ces dernières ne sont pas couvertes par la présente attestation.
- This EU Type Examination Certificate relates only to the design and construction of the specified product.
Further requirements of the Directive apply to the manufacturing process and supply of this product. These are not covered by this certificate.
- Le marquage du produit est mentionné dans l'annexe de cette attestation.
- The marking of the product is specified in the schedule to this certificate.
- Fontenay-aux-Roses, le 26 décembre 2018
- Directeur Certification
Director for Certification
Marie-Elisabeth d'Ornano

Seul le texte en français peut engager la responsabilité de LCIE. Ce document ne peut être reproduit que dans son intégralité, sans aucune modification. Il est établi en accord avec le référentiel de certification ATEX de LCIE. The LCIE's liability applies only on the French text. This document may only be reproduced in its entirety and without any change. It is issued in accordance with LCIE's ATEX Certification Rules.
CERT-ATEX-FORM 04 Rev. 05

Page 1 / 4

LCIE

Laboratoire Central des Industries Electriques
Une société de Bureau Veritas

33 Avenue du Général Leclerc
92260 Fontenay-aux-Roses
FRANCE

WWW.LCIE.FR



ATTESTATION D'EXAMEN UE DE TYPE - ANNEXE

EU TYPE EXAMINATION CERTIFICATE - SCHEDULE

1 Version : 06

LCIE 11 ATEX 3027 X

Issue : 06

12 DESCRIPTION DU PRODUIT

L'appareil est un convertisseur de volume destiné à mesurer, enregistrer et surveiller des paramètres variables fournis par des compteurs de gaz ou des capteurs de température ou de pression.

L'appareil se compose principalement :

- d'une enveloppe en aluminium,
- d'un module LCD,
- d'une carte CPU alimentée par une source externe ou par un ou deux packs de batterie (optionnel: quatre packs de batteries montés 2x2 en série),
- d'une carte modem-adaptateur, alimentée par un pack de batterie, équipée d'un module radio interne (optionnel) et d'une antenne pour la communication sans fil des données,
- de capteurs de température ou de pression, internes ou externes,
- de bornes pour l'alimentation ou la communication des données.

DETAIL DE LA GAMME

Un seul modèle avec ou sans Module Radio.

CARACTERISTIQUES

| Connector | | Electrical parameters | | | | | |
|--|------------------------|--------------------------|-------------------------|------------------------|-------------------------|--|--|
| DA1, DA2, DA3, DA4, DTR/T+, Tx/D/Tr-, Rx/D/R-DCCD/R+, Ri, Uext (Carte CPU/CPU-Karte) | U _i : 30 V | I _{sc} : 140 mA | Σ P: 0.5 W | C _i : 0 | L _i : 0 | | |
| DE1, DE2 | U _o : 9.7 V | I _o : 49.7 mA | P _o : 48 mW | C _o : 24 μF | L _o : 367 mH | | |
| DE3, DE4 | U _o : 9.7 V | I _o : 2.1 mA | P _o : 51 mW | C _o : 24 μF | L _o : 322 mH | | |
| DE5, DE6 | U _o : 9.7 V | I _o : 1.0 mA | P _o : 2.4 mW | C _o : 24 μF | L _o : 142 H | | |

Paramètres spécifiques du ou des modes de protection concerné(s):

Les piles utilisées dans l'appareil sont les suivantes :

- carte CPU: Elster N°73015774, N°73020663 ou N°73023225.
- carte modem-adaptateur: Elster N°73021211.

MARQUAGE

Le marquage du produit doit comprendre :

Elster GmbH

Adresse : ...

Type : EK280

N° de fabrication : ...

Année de fabrication : ...

Ex II 1 G

Ex ia IIB T4 Ga (sans module radio)

Ex ia IIB T3 Ga (avec module radio)

LCIE 11 ATEX 3027 X

Tamb : -40°C à +60 °C

U_i: ..., I_i: ..., P_i: ..., C_i: ..., L_i: ... (*)

U_o: ..., I_o: ..., P_o: ..., C_o: ..., L_o: ... (*)

DESCRIPTION OF PRODUCT

The equipment is a volume conversion device intended to measure, record and monitor variable parameters provided from gas meters, pressure or temperature sensors.

The equipment consists mainly of:

- an aluminum housing,
- a LCD module,
- CPU board powered by external supply or by one or two battery packs (optional: four battery packs connected 2x2 in series),
- Modem-adaptor board, powered by battery pack, equipped with internal radio-module (optional) and an antenna for wireless data communication,
- internal or external temperature or pressure sensors,
- and terminals for power supply or data communication.

RANGE DETAILS

Only one model with or without Radio Module.

RATINGS

Specific parameters of the concerned protection mode:

Batteries used within the apparatus are as follows:

- CPU board: Elster N°73015774, N°73020663 or N°73023225.
- Modem-adaptor board: Elster N°73021211.

MARKING

The marking of the product shall include the following :

Elster GmbH

Address : ...

Type : EK280

Serial number : ...

Year of construction : ...

Ex II 1 G

Ex ia IIB T4 Ga (without radio-module)

Ex ia IIB T3 Ga (with radio-module)

LCIE 11 ATEX 3027 X

Tamb : -40°C to +60°C

U_i: ..., I_i: ..., P_i: ..., C_i: ..., L_i: ... (*)

U_o: ..., I_o: ..., P_o: ..., C_o: ..., L_o: ... (*)

Seul le texte en français peut engager la responsabilité de LCIE. Ce document ne peut être reproduit que dans son intégralité, sans aucune modification. Il est établi en accord avec le référentiel de certification ATEX de LCIE. The LCIE's liability applies only on the French text. This document may only be reproduced in its entirety and without any change. It is issued in accordance with LCIE's ATEX Certification Rules.

CERT-ATEX-FORM 04 Rev. 05

Page 2 / 4

LCIE

Laboratoire Central des Industries Electriques

Une société de Bureau Veritas

33 Avenue du Général Leclerc

92260 Fontenay-aux-Roses

FRANCE

WWW.LCIE.FR



ATTESTATION D'EXAMEN UE DE TYPE - ANNEXE
EU TYPE EXAMINATION CERTIFICATE - SCHEDULE

1 Version : 06

LCIE 11 ATEX 3027 X

Issue : 06

MARQUAGE (suite)

Le marquage du produit doit comprendre :

AVERTISSEMENT :

- UTILISER UNIQUEMENT DES BATTERIES ELSTER N°73015774, N°73020663, N°73021211 et N°73023225
- DANGER POTENTIEL DE CHARGES ELECTROSTATIQUES – VOIR INSTRUCTIONS.

L'appareil doit également comporter le marquage normalement prévu par les normes de construction qui le concernent sous la responsabilité du fabricant.

13 CONDITIONS PARTICULIERES D'UTILISATION

- Les connecteurs de sécurité intrinsèque de l'appareil ne doivent être raccordés qu'à des appareils certifiés de sécurité intrinsèque ou à des appareils simples. Ces associations doivent répondre aux exigences de la norme EN 60079-25.
- Les connecteurs X23 et X24 ne doivent pas être utilisés en zone explosible.
- Les connecteurs U_{ext} sur la carte Modem-adaptateur et X9 sur la carte CPU ne doivent pas être utilisés en zone explosible.
- Les connecteurs X17 et X18 ne peuvent être connectés qu'aux capteurs de température définis par le fabricant dans le dossier technique.
- Les connecteurs X7, X15, X16, X28, X29 et X30 ne peuvent être connectés qu'aux capteurs de pression définis par le fabricant dans le dossier technique.
- L'enveloppe de l'appareil contient plus de 10% aluminium. Elle doit être montée de manière à éviter le risque d'étincelle par frottement ou impact.

14 EXIGENCES ESSENTIELLES DE SANTE ET DE SECURITE

Couvertes par les normes listées au point 8.

15 DOCUMENTS DESCRIPTIFS

| N° | Description | Reference | Rev. | Date | Page(s) |
|----|--|-----------|------|------------|---------|
| 1 | Dossier Technique / Technical file | EE0308 | 03 | 2018/10/30 | 290 |
| 2 | Notice d'instructions / Operating manual | 73021209 | - | - | 91 |

16 INFORMATIONS COMPLEMENTAIRES

Essais individuels

Néant.

Composants intégrés

| Désignation Designation | Fabricant Manufacturer | Type | Document de référence Reference document | Normes de référence Reference standards | |
|------------------------------|---------------------------|--------------------------------|---|---|-----|
| Module radio Radio module | Elster | ECM-GW 120 | LCIE 10 ATEX 3026U | EN 60079-0 :2012 + A11 :2013 EN 60079-11 :2012 | (1) |
| Module radio Radio module | Elster | ECM-2G-UG350 / ECM-3G-UJ270 | LCIE 16 ATEX 3047U | EN 60079-0 :2012 + A11 :2013 EN 60079-11 :2012 | (1) |
| Fusible Fuse | Littelfuse | Safe-T-Plus 0259 series | BASEEFA 02 ATEX 0071U | EN 60079-0 :2012 + A11 :2013 EN 60079-11 :2012 | (1) |

(1) Pas de modifications techniques majeures applicables.

MARKING (continued)

The marking of the product shall include the following :

WARNING:

- USE ONLY ELSTER N°73015774, N°73020663, N°73021211 and N°73023225 BATTERIES
- POTENTIAL ELECTROSTATIC CHARGING HAZARD – SEE INSTRUCTIONS.

The equipment shall also bear the usual marking required by the product standards applying to such equipment under the manufacturer responsibility.

SPECIFIC CONDITIONS OF USE

The intrinsically safe connectors of equipment shall only be connected to certified associated intrinsically safe equipment or simple apparatus. These combinations shall comply with the requirements of the standard EN 60079-25.
Connectors X23 and X24 cannot be used in hazardous area.

Connectors U_{ext} on Modem-adaptor board and X9 in CPU board cannot be used in hazardous area.
Connectors X17 and X18 can only be connected to temperature sensors defined by the manufacturer in technical file.

Connectors X7, X15, X16, X28, X29 and X30 can only be connected to pressure sensors defined by the manufacturer in technical file.
The equipment housing contains more than 10% in total of aluminium. It must be mounted in such a manner as to eliminate the risk of sparks caused by friction or impact.

ESSENTIAL HEALTH AND SAFETY REQUIREMENTS

Covered by standards listed at 8.

DESCRIPTIVE DOCUMENTS

ADDITIONAL INFORMATION

Routine tests

None.

Integrated components

(1) No applicable Technical Differences.

Seul le texte en français peut engager la responsabilité de LCIE. Ce document ne peut être reproduit que dans son intégralité, sans aucune modification. Il est établi en accord avec le référentiel de certification ATEX de LCIE. The LCIE's liability applies only on the French text. This document may only be reproduced in its entirety and without any change. It is issued in accordance with LCIE's ATEX Certification Rules.
CERT-ATEX-FORM 04 Rev. 06

Page 3 / 4



ATTESTATION D'EXAMEN UE DE TYPE - ANNEXE

EU TYPE EXAMINATION CERTIFICATE - SCHEDULE

1 Version : 06

LCIE 11 ATEX 3027 X

Issue : 06

16 INFORMATIONS COMPLEMENTAIRES (suite)

Conditions de certification

Les détenteurs d'attestations d'examen UE de type doivent également satisfaire les exigences de contrôle de production telles que définies à l'article 13 de la Directive 2014/34/UE.

En accord avec l'Article 41 de la Directive 2014/34/UE, les attestations d'examen CE de type mentionnant la Directive 94/9/CE émises avant la date d'application de la Directive 2014/34/UE (20 avril 2016) peuvent être considérées comme émises en accord avec la Directive 2014/34/UE. Les nouvelles versions de ces attestations peuvent conserver le numéro de l'attestation d'origine émise avant le 20 avril 2016.

ADDITIONAL INFORMATION (continued)

Conditions of certification

Holders of EU type examination certificates are also required to comply with the production control requirements defined in article 13 of Directive 2014/34/UE.

In accordance with Article 41 of Directive 2014/34/UE, EC-Type Examination Certificates referring to Directive 94/9/EC that were in existence prior to the date of application of Directive 2014/34/UE (20 April 2016) may be referenced as if they were issued in accordance with Directive 2014/34/UE. New issues of such certificates may continue to bear the original certificate number issued prior to 20 April 2016.

17 DETAILS DES MODIFICATIONS DE L'ATTESTATION

Version 00 : Evaluation de la conformité selon les normes
(20/04/2011) EN 60079-0:2009 et EN 60079-11:2007.

Version 01 : Modification de composants.
(13/07/2012)

Version 02 : Carte modem-adaptateur Q24 :
(30/08/2012)
- Modification de composants.
- Modification du circuit imprimé.
- Mise à jour des documents.

Version 03 : - Modification de valeurs de résistances.
(20/08/2014) - Mise à jour normative selon les normes EN 60079-0:2009 et EN 60079-11:2012.

Version 04 : - Ajout de la batterie Tekcell comme une
(28/01/2016) alternative pour l'alimentation de la carte CPU.
- Mise à jour normative selon la norme EN 60079-0:2012 + A11:2013.

Version 05 : Ajout d'une nouvelle carte modem-adaptateur
(25/11/2016) équipée du module radio certifié ECM-2G-UG350 ou ECM-3G-UU270.

Version 06 : Mise à jour des paramètres de sécurité
intrinsèque.

DETAILS OF CERTIFICATE CHANGES

Issue 00: Conformity assessment according to EN 60079-
(2011/04/20) 0:2009 and EN 60079-11:2007 standards.

Issue 01: Modification of components.
(2012/07/13)

Issue 02: Q24 modem-adaptor board:
(2012/08/30)
- Modification of components.
- Modification of the printed board.
- Update of documents.

Issue 03: - Modification of some resistor values.
(2014/08/20) - Normative update according to EN 60079-0:2009 and EN 60079-11:2012 standards.

Issue 04: - Addition of Tekcell battery as alternative
(2016/01/28) supply for CPU board.
- Normative update according to standard EN 60079-0:2012 + A11:2013.

Issue 05: Addition of new Modem-adaptor board equipped
(2016/11/25) with Ex certified radio module ECM-2G-UG350 or ECM-3G-UU270.

Issue 06: Update of intrinsic safety parameters.

Seul le texte en français peut engager la responsabilité du LCIE. Ce document ne peut être reproduit que dans son intégralité, sans aucune modification. Il est établi en accord avec le référentiel de certification ATEX du LCIE. The LCIE's liability applies only on the French text. This document may only be reproduced in its entirety and without any change. It is issued in accordance with LCIE's [ATEX Certification Rules](#).
CERT-ATEX-FORM 04 Rev. 05

Page 4 / 4

LCIE

Laboratoire Central des Industries Electriques
Une société de Bureau Veritas

33 Avenue du Général Leclerc
92240 Fontenay-aux-Roses
FRANCE

WWW.LCIE.FR

9.3.2 Zone 2



ATTESTATION D'EXAMEN DE TYPE

TYPE EXAMINATION CERTIFICATE



1 Version : 04

LCIE 12 ATEX 1015 X

Issue : 04

Directive 2014/34/UE
Appareil ou Système de Protection destiné à être utilisé en
Atmosphères Explosibles

Directive 2014/34/EU
Equipment or Protective System Intended for use in Potentially
Explosive Atmospheres

3 Produit :
Convertisseur de volume électronique

Product :
Volume conversion device

Type: EK280

4 Fabricant :

Manufacturer :

5 Adresse :

Elster GmbH

Address :

Steinmstrasse 19-21
55252 Mainz-Kastel
Germany

6 Ce produit et ses variantes éventuelles acceptées sont décrits dans l'annexe de la présente attestation et dans les documents descriptifs cités en référence.

This product any acceptable variation thereto is specified in the schedule to this certificate and the documents therein referred to.

7 Le LCIE certifie que ce produit est conforme aux Exigences Essentielles de Sécurité et de Santé pour la conception et la construction de produits destinés à être utilisés en atmosphères explosibles, données dans l'annexe II de la Directive.
Les résultats des vérifications et essais figurent dans le(s) rapport(s) confidentiel(s) N° :

LCIE certifies that product has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of products intended for use in potentially explosive atmospheres, given in Annex II to the Directive.
The examination and test results are recorded in confidential report(s) N°:

109797-618988; 132192-666243; 137853-677467-01; 147881-701514-01; 147881-701514-02;
147339-700071-01; 147339-700071-02

8 Le respect des Exigences Essentielles de Sécurité et de Santé est assuré par la conformité à :

Compliance with the Essential Health and Safety Requirements has been assured by compliance with :

EN 60079-0:2012 + A11:2013
EN 60079-11:2012
EN 60079-15:2010

9 Le signe « X » lorsqu'il est placé à la suite du numéro de l'attestation, indique que cet appareil est soumis aux conditions particulières d'utilisation, mentionnées dans l'annexe de cette attestation.

If the sign "X" is placed after the certificate number, it indicates that the product is subject to the Specific Conditions of Use specified in the schedule to this certificate.

10 Cette Attestation d'Examen de Type concerne uniquement la conception et la construction du produit spécifié.
Des exigences supplémentaires de la directive sont applicables pour la fabrication et la fourniture du produit. Ces dernières ne sont pas couvertes par la présente attestation.

This Type Examination Certificate relates only to the design and construction of the specified product.
Further requirements of the Directive apply to the manufacturing process and supply of this product. These are not covered by this certificate.

11 Le marquage du produit est mentionné dans l'annexe de cette attestation.

The marking of the product is specified in the schedule to this certificate.

Fontenay-aux-Roses, le 30 mars 2018

Responsable de Certification



Certification Officer
Julien Gauthier

Seul le texte en français peut engager la responsabilité du LCIE. Ce document ne peut être reproduit que dans son intégralité, sans aucune modification. Il est établi en accord avec le [référentiel de certification ATEX](#) du LCIE. The LCIE's liability applies only on the French text. This document may only be reproduced in its entirety and without any change. It is issued in accordance with LCIE's [ATEX Certification Rules](#).
CERT-ATEX-FORM 05 Rev. 02

Page 1 of 5

LCIE

Laboratoire Central des Industries Electriques
Une société de Bureau Veritas

33 Avenue du Général Leclerc
92260 Fontenay-aux-Roses
FRANCE

WWW.LCIE.FR



ATTESTATION D'EXAMEN DE TYPE - ANNEXE

TYPE EXAMINATION CERTIFICATE - SCHEDULE

1 Version : 04

LCIE 12 ATEX 1015 X

Issue : 04

12 DESCRIPTION DU PRODUIT

L'appareil convertit et affiche le volume mesuré par un compteur de gaz en état de fonctionnement au volume standard à l'aide des variables d'état de la pression et de la température.

L'appareil se compose principalement des composants suivants :

- Boîtier en aluminium avec écran LCD, claviers et entrées de câble.
- Cartes électroniques (Alimentation, CPU, Modem-adaptateur ou Ethernet).
- Six entrées numériques (DE1 à DE6) pour capteurs passifs, quatre sorties numériques (DA1 à DA4), interface série (DTR/T+, TxD/T-, RxD/R-, DCD/R+, RI) et Ethernet port.
- Un ou deux capteurs de pression ou de température.
- Piles (3.6 V) comme alimentation pour carte CPU et carte modem-adaptateur.

Paramètres spécifiques des modes de protection concernés :

Les piles utilisées dans les deux modèles sont les suivantes :

| Pile / Cell | Carte CPU / CPU board | Carte modem-adaptateur / Modem-adaptor board |
|-------------|-----------------------|--|
| 73015774 | x | |
| 73020663 | x | |
| 73017964 | | x |
| 73023225 | x | |

Modèle protégé par Ex nA :

| Borne / Terminal | Paramètres électriques / Electrical parameters |
|--|--|
| L-N-PE (Carte Alimentation / Power supply board) | $U_{max} = 90$ à 170 VAC |
| Uext (Carte CPU / CPU board) | $U_{max} = 30$ V |
| Ethernet (Carte Ethernet / Ethernet board) | $U_{max} = 57$ V |

Modèle protégé par Ex nA [ic] :

Model protected by Ex nA:

| Borne / Terminal | Paramètres électriques / Electrical parameters | | | | |
|--|--|----------------|---------------|-------------------|---------------|
| L-N-PE (Carte Alimentation / Power supply board) | $U_n: 230$ V | - | - | - | - |
| Ethernet (Carte Ethernet / Ethernet board) | $U_i: 57$ V | - | - | - | - |
| DA1, DA2, DA3, DA4, DTR/T+, TxD/T-, RxD/R-, DCD/R+, RI, Uext (Carte CPU / CPU board) | $U_i: 30$ V | $I_g: 140$ mA | $P_g: 0.5$ W | $C_i: 0$ | $L_i: 0$ |
| DE1, DE2 (Carte CPU / CPU board) | $U_o: 9.7$ V | $I_o: 19.7$ mA | $P_o: 48$ mW | $C_o: 26$ μ F | $L_o: 206$ mH |
| DE3, DE4 (Carte CPU / CPU board) | $U_o: 9.7$ V | $I_o: 21$ mA | $P_o: 51$ mW | $C_o: 26$ μ F | $L_o: 181$ mH |
| DE5, DE6 (Carte CPU / CPU board) | $U_o: 9.7$ V | $I_o: 1.0$ mA | $P_o: 2.4$ mW | $C_o: 26$ μ F | $L_o: 80$ H |

DETAIL DE LA GAMME

Un seul modèle. L'appareil peut être utilisé comme appareil protégé par Ex nA ou par Ex nA [ic].

RANGE DETAILS

Only one model. The equipment might be used as equipment protection by Ex nA or by Ex nA [ic].

Seul le texte en français peut engager la responsabilité de la LCIE. Ce document ne peut être reproduit que dans son intégralité, sans aucune modification. Il est établi en accord avec le référentiel de certification ATEX de la LCIE. The LCIE's liability applies only on the French text. This document may only be reproduced in its entirety and without any change. It is issued in accordance with LCIE's ATEX Certification Rules.

CERT-ATEX-FORM 05 Rev. 02

Page 2 of 5

LCIE

Laboratoire Central des Industries Electriques
Une société de Bureau Veritas

33 Avenue du Général Leclerc
92260 Fontenay-aux-Roses
FRANCE

WWW.LCIE.FR



ATTESTATION D'EXAMEN DE TYPE - ANNEXE

TYPE EXAMINATION CERTIFICATE - SCHEDULE

1 Version : 04

LCIE 12 ATEX 1015 X

Issue : 04

MARQUAGE

Le marquage du produit doit comprendre :

Elster GmbH ou Elster
 Adresse : ...
 Type : EK280
 N° de fabrication : ...
 Année de fabrication : ...
 LCIE 12 ATEX 1015 X
 Ta = -25°C à +60°C

AVERTISSEMENT :

- UTILISER UNIQUEMENT DES BATTERIES ELSTER N°73015774, N°73020663, N°73017964, 73023225
- DANGER POTENTIAL DE CHARGES ELECTROSTATIQUES – VOIR INSTRUCTIONS
- NE PAS OUVRIR EN PRESENCE D'UNE ATMOSPHERE EXPLOSIVE

Modèle protégé par Ex nA :

Ex II 3 G
 Ex nA IIC T6 Gc

Modèle protégé par Ex nA IIC :

Ex II 3(3) G
 Ex nA IIC T6 Gc
 U_i : ..., I_i : ..., P_i : ..., C_i : ..., L_i : ..., (*)
 U₀ : ..., I₀ : ..., P₀ : ..., C₀ : ..., L₀ : ..., (*)
 (*) : complété par les paramètres de sécurité intrinsèque

L'appareil doit également comporter le marquage normalement prévu par les normes de construction qui le concernent sous la responsabilité du fabricant.

13 CONDITIONS PARTICULIERES D'UTILISATIONModèle protégé par Ex nA :

- a. Utiliser uniquement les capteurs de température et de pression, et les entrées de câble définies par le fabricant dans le dossier technique
- b. L'appareil ne doit pas subir des chocs mécaniques d'une énergie supérieure à 2J

Modèle protégé par Ex nA IIC :

- a. Les connecteurs de sécurité intrinsèque de l'appareil ne doivent être raccordés qu'à des matériels de sécurité intrinsèque certifiés pour l'usage considéré. Cette association doit répondre aux exigences de la norme EN 60079-25.
- b. Les connecteurs X23, X24 et X9 de la carte CPU ne doivent pas être utilisés en zone explosive.
- c. Le connecteur U_{ext} de la carte Modem-adaptateur ne doit pas être utilisé en zone explosive.
- d. Les connecteurs X17 et X18 de la carte CPU ne peuvent être connectés qu'aux capteurs de température définis par le fabricant dans le dossier technique.

MARKING

The marking of the product shall include the following :

Elster GmbH or Elster
 Address: ...
 Type: EK280
 Serial number: ...
 Year of construction: ...
 LCIE 12 ATEX 1015 X
 Ta = -25°C to +60°C

WARNING:

- USE ONLY ELSTER N°73015774, N°73020663, N°73017964, 73023225 BATTERIES
- POTENTIAL ELECTROSTATIC CHARGING HAZARD – SEE INSTRUCTIONS
- DO NOT OPEN WHEN AN EXPLOSIVE ATMOSPHERE MAY BE PRESENT

Model protected by Ex nA:

Ex II 3 G
 Ex nA IIC T6 Gc

Model protected by Ex nA IIC:

Ex II 3(3) G
 Ex nA IIC T6 Gc
 U_i : ..., I_i : ..., P_i : ..., C_i : ..., L_i : ..., (*)
 U₀ : ..., I₀ : ..., P₀ : ..., C₀ : ..., L₀ : ..., (*)
 (*) : completed by intrinsic safety parameters

The equipment shall also bear the usual marking required by the product standards applying to such equipment under the manufacturer responsibility.

SPECIFIC CONDITIONS OF USEModel protected by Ex nA:

Use only temperature, pressure sensors and cable glands defined by the manufacturer in technical file
 The apparatus shall not be submitted to mechanical impacts with an energy above 2 J

Model protected by Ex nA IIC:

The intrinsically safe apparatus shall only be connected to associated intrinsically safe apparatus certified for the intended use. This association shall comply with the requirements of the standard EN 60079-25
 Connectors X23, X24 and X9 of CPU board cannot be used in hazardous area
 Connector U_{ext} of Modem-adaptor board cannot be used in hazardous area.
 Connectors X17 and X18 of CPU board can only be connected to temperature sensors defined by the manufacturer in technical file.

Seul le texte en français peut engager la responsabilité de LCIE. Ce document ne peut être reproduit que dans son intégralité, sans aucune modification. Il est établi en accord avec le [référentiel de certification ATEX](#) du LCIE. The LCIE's liability applies only on the French text. This document may only be reproduced in its entirety and without any change. It is issued in accordance with LCIE's [ATEX Certification Rules](#)

CERT-ATEX-FORM DE Rev. 02

Page 3 of 5

LCIE

Laboratoire Central des Industries Electriques
 Une société de Bureau Veritas

33 Avenue du Général Leclerc
 92260 Fontenay-aux-Roses
 FRANCE

WWW.LCIE.FR



ATTESTATION D'EXAMEN DE TYPE - ANNEXE

TYPE EXAMINATION CERTIFICATE - SCHEDULE

1 Version : 04

LCIE 12 ATEX 1015 X

Issue : 04

- e. Les connecteurs X7, X15, X16, X28, X29 et X30 de la carte CPU ne peuvent être connectés qu'aux capteurs de pression définis par le fabricant dans le dossier technique.
- f. L'appareil ne doit pas subir des chocs mécaniques d'une énergie supérieure à 2J.
- g. Les connecteurs K2 et K3 de la carte Ethernet ne doivent pas être utilisés en zone explosible.
- h. Paramètres électriques des bornes d'un matériel associé certifié de sécurité intrinsèque ou d'une sonde pouvant être raccordé aux bornes de l'EK280 :

Connectors X7, X15, X16, X28, X29 and X30 of CPU board can only be connected to pressure sensors defined by the manufacturer in technical file.

The apparatus shall not be submitted to mechanical impacts with energy above 2J.

Connectors K2 and K3 of Ethernet board cannot be used in hazardous area

Electrical parameters of terminals from associated intrinsically safe certified equipment or sensor that can be connected to the terminals of EK280:

| Bornes de l'EK280 Terminals of EK280 | Paramètres électriques de l'appareil associé de sécurité intrinsèque ou d'une sonde Electrical parameters of associated intrinsically safe certified equipment or sensor | | | | |
|--|---|------------------------------|-----------------------------|--|---|
| DA1, DA2, DA3, DA4, DTR/T+, Tx/D/T-, Rx/D/R-, DCD/R+, RI, Uext | $U_0 \leq 30 \text{ V}$ | $I_{0T} \leq 140 \text{ mA}$ | $P_{0T} \leq 0.5 \text{ W}$ | $C_0 - C_{c \text{ max}} \leq 0$ | $L_0 - L_{c \text{ max}} \geq 0$ |
| DE1, DE2 | $U_i \geq 9.7 \text{ V}$ | $I_i \geq 19.7 \text{ mA}$ | $P_i \geq 48 \text{ mW}$ | $C_i + C_{c \text{ max}} \leq 26 \text{ pF}$ | $L_i + L_{c \text{ max}} \leq 206 \text{ mH}$ |
| DE3, DE4 | $U_i \geq 9.7 \text{ V}$ | $I_i \geq 21 \text{ mA}$ | $P_i \geq 51 \text{ mW}$ | $C_i + C_{c \text{ max}} \leq 26 \text{ pF}$ | $L_i + L_{c \text{ max}} \leq 181 \text{ mH}$ |
| DE5, DE6 | $U_i \geq 9.7 \text{ V}$ | $I_i \geq 1.0 \text{ mA}$ | $P_i \geq 2.4 \text{ mW}$ | $C_i + C_{c \text{ max}} \leq 26 \text{ pF}$ | $L_i + L_{c \text{ max}} \leq 80 \text{ H}$ |

$C_{c \text{ max}}$, $L_{c \text{ max}}$: Valeur maximale de capacité et d'inductance du câble de liaison entre EK280 et un matériel associé certifié de sécurité intrinsèque.

$C_{c \text{ max}}$, $L_{c \text{ max}}$: maximum value of capacitance and inductance of the connected cable between EK280 and an associated intrinsically safe certified equipment.

14 EXIGENCES ESSENTIELLES DE SANTE ET DE SECURITE

Couvertes par les normes listées au point 8.

ESSENTIAL HEALTH AND SAFETY REQUIREMENTS

Covered by standards listed at 8.

15 DOCUMENTS DESCRIPTIFS

| N° | Description | Reference | Rev. | Date | Page(s) |
|----|-------------------------------------|-----------|------|------------|---------|
| 1 | Notice d'utilisation / Instructions | 73021209 | - | - | 102 |
| 2 | Dossier technique / Technical file | EE0245 | 4 | 2018-02-19 | 271 |

DESCRIPTIVE DOCUMENTS

16 INFORMATIONS COMPLEMENTAIRES

Essais individuels

Chaque appareil doit être soumis à un essai de rigidité diélectrique sous 1500 V efficace conformément au paragraphe 6.5.1 de la norme EN 60079-15:2010

ADDITIONAL INFORMATION

Routine tests

Each apparatus shall be submitted to a dielectric strength test under 1500 Vrms carried out in accordance with clause 6.5.1 of EN 60079-15:2010 standard

17 DETAILS DES MODIFICATIONS

- Version 00: 2012/09/25 Evaluation de la conformité suivant les normes EN 60079-0:2009 et EN 60079-15:2010
- Version 01: 2015/01/27
- Ajout d'un nouveau modèle Ex nA[c] protégé par sécurité intrinsèque et sans étincelles
 - Evaluation de la conformité suivant la norme EN 60079-11:2012
- Version 02: 2016/01/28
- Ajout de la pile Tekcell comme alimentation alternative pour la carte CPU
 - Mise à jour normative selon la norme EN 60079-0:2012 + A11:2013
 - Correction de la capacité nominale des piles

DETAILS OF CHANGES

- Issue 00: 2012/09/25 Conformity assessment according to EN 60079-0:2009 and EN 60079-15:2010 standards
- Issue 01: 2015/01/27
- Addition of new model Ex nA [c] protected by intrinsic safety and non-sparking
 - Conformity assessment according to EN 60079-11:2012 standard
- Issue 02: 2016/01/28
- Addition of Tekcell cell as alternative supply for CPU board
 - Normative update according to EN 60079-0:2012 + A11:2013
 - Correction of the nominal capacity of the cells

Seul le texte en français peut engager la responsabilité du LCIE. Ce document ne peut être reproduit que dans son intégralité, sans aucune modification. Il est établi en accord avec le [règlement de certification ATEX](#) du LCIE. The LCIE's liability applies only on the French text. This document may only be reproduced in its entirety and without any change. It is issued in accordance with LCIE's [ATEX Certification Rules](#).
CERT-ATEX-FORM 05 Rev. 02

Page 4 of 5

LCIE

Laboratoire Central des Industries Electriques
Une société de Bureau Veritas

33 Avenue du Général Leclerc
92260 Fontenay-aux-Roses
FRANCE

WWW.LCIE.FR



ATTESTATION D'EXAMEN DE TYPE - ANNEXE TYPE EXAMINATION CERTIFICATE - SCHEDULE

1 Version : 04

LCIE 12 ATEX 1015 X

Issue : 04

Version 03:
2017/07/21

- Ajout d'une nouvelle carte modem-adaptateur pour les deux modèles
- Mise à jour des paramètres de sécurité intrinsèque pour les bornes d'interface série du modèle protégé par Ex nA [ic]

Version 04:
Actuelle

- Ajout d'une nouvelle carte Ethernet qui peut être branchée à la carte CPU alternativement à la carte modem-adaptateur.
- Ajout de paramètres de sécurité intrinsèque pour la borne Uext sur la carte CPU en cas d'utilisation avec une alimentation de sécurité intrinsèque externe.
- Ajout du nouveau presse-étoupe type EMSKE 16 EMV-Z.

Issue 03:
2017/07/21

- Addition of new Modem-adaptor board for two models
- Update of intrinsic safety parameters for serial interface terminals of model protected by Ex nA [ic]

Issue 04:
Current

- Addition of new Ethernet board which can be plugged to the CPU board alternatively to the modem-adaptor board.
- Addition of intrinsic safety parameters for Uext terminal on the CPU board when used with external intrinsic safety power supply.
- Addition of new cable gland type EMSKE 16 EMV-Z.

Seul le texte en français peut engager la responsabilité du LCIE. Ce document ne peut être reproduit que dans son intégralité, sans aucune modification. Il est établi en accord avec le [référentiel de certification ATEX](#) du LCIE. The LCIE's liability applies only on the French text. This document may only be reproduced in its entirety and without any change. It is issued in accordance with LCIE's [ATEX Certification Rules](#).
CERT-ATEX-FORM 05 Rev. 02

Page 5 of 5

LCIE

Laboratoire Central des Industries Electriques
Une société de Bureau Veritas

33 Avenue du Général Leclerc
92260 Fontenay-aux-Roses
FRANCE

WWW.LCIE.FR