


# Short-Form Instructions (73018350, c) Volume Conversion Device Type EK210



If any key is pressed, the display is activated and the present counter reading  $V_b$  (volume at base conditions, predecimal places) is displayed in the User menu. All other data associated with the volume at base conditions can be displayed by pressing the keys  $\rightarrow$  (1x) and  $\downarrow$  (see second column "Standard volume" in the operation overview to these instructions).

To display a value in the column, Actual volume, the key  $\rightarrow$  is pressed. Now the menu Act. V (Actual volume) is displayed. With the key  $\downarrow$  all values can be viewed which are associated with the actual volume.

To change to another menu (e.g. Pressure) the key  $\rightarrow$  is pressed, until the desired menu name appears in the display. The transitions from one menu to another take place at the points identified with the arrows (see operation overview to these instructions).

## Entering values

Even without a PC or read-out device, values in the volume corrector (Volume Conversion Device) can be changed which are not subject to the calibration lock or are only calculated (e.g. flow) or measured (e.g. pressure or temperature).

In these short-form instructions all values which are subject to the calibration lock are identified with a "C". All values which are determined or measured and can only therefore be read are identified with a ".".

### Example of changing a value

(adjustable counter in the menu Actual volume (Act.V. ))

- The display is activated by pressing any key. In the display the present counter reading  $V_b$  (Volume at base conditions, predecimal places) is displayed in the **User** menu.

				Status		Menu								
				o	k	.	U	s	e	r				
V	b			0	0	0	0	0	1	2	3	4	m	3

- Changing to the column Actual volume occurs by pressing the key  $\rightarrow$  twice. The present counter reading  $V_m$  (Actual volume) is displayed in the menu **Act.V.**

				Status		Menu								
				o	k	.	A	c	t	.	V	.		
V	m			0	0	0	0	0	1	2	3	4	m	3

- With the Actual volume menu you change to the value  $V_m A$  by pressing the key  $\downarrow$  repeatedly to obtain the value  **$V_m A$**  (adjustable counter).

				Status		Menu								
				o	k	.	A	c	t	.	V	.		
V	m	A		0	0	0	0	0	2	3	4	5	m	3

- The entry mode is activated by pressing the key combination  $\downarrow + \rightarrow$  (ENTER). The first place to the left **flashes**. The key  $\rightarrow$  enables skipping to the required positions of the displayed value. They can be changed with the key  $\downarrow$ . After modification, the counter reading must be accepted by pressing the key combination  $\downarrow + \rightarrow$  (ENTER).

				Status		Menu											
V	m	A															
				0	0	0	0	0	2	3	4	5	.	0	0	0	0

**Important:** The entry mode cannot be left via key depression. Wait until the display switches off or changes to the standard display ( $V_b$ ). (Standard setting is one or two minutes.)

This product is discontinued!

User list	Standard volume	Actual volume	Pressure	to "Temp."
User	Std.V.	Act.V.	Press.	
Vb Volume at base conditions (predecimal places)	Vb Volume at base conditions (post-decimal places)	Vm Actual volume	p Pressure	-
VmA Adjustable counter	Qb Standard flow	Qm Actual flow	pMin Lower alert limit	C
p Pressure	VbD Disturbance quantity	VmD Disturbance quantity	pMax Upper alert limit	C
T Temperature	VbT Total quantity	VmT Total quantity	MRL.p Meas. range bottom	C
C Conversion factor	VbA Adjustable counter	VmA Adjustable counter	MRL.p Meas. range top	C
K.F K substitute value	VbME Month end value	VmME Month end value	p.F Substitute value	S
VbME Month-end value	Time Time for VbME	Time Time for VmME	pb Standard pressure	C
Time Time for VbME			Md.p Pressure mode	C
VmME Month-end value			Typ.p Press. sensor type	C
Time Time for VmME			SNp Serial no. of sensor	C
... User value			Eq1.p Equ. coefficient 1	C
Addr Addr. of user value			Eq2.p Equ. coefficient 2	C
			Eq3.p Equ. coefficient 3	C
			p.Mes Pressure meas.	-

**Access rights**

The EK210 differentiates between four access parties. Each party has a lock and an associated combination:

**C** Calibration lock  
**M** Manufacturer's lock  
**S** Supplier's lock  
**K** Customer's lock

- Values which are measured or calculated by the volume corrector, can only be displayed and are identified with a dash.

→

**Entry errors**


Entry errors are displayed when the operator has made invalid entries using the keypad. After releasing the enter key the display returns to its original state.

Example:

					Status				Menu					
					o	k	.		I	n	p	u	t	s
C	P	.	E	1	-	-	-	-	5	-	-	-	-	

----x---- Possible error codes according to the following table.

Code	Description
4	Parameter cannot be changed (constant).
5	No authorisation for changing the value. To change the value the appropriate lock must be opened.
6	Invalid value. Entered value is outside the permissible limits.
7	Incorrect combination. The entered combination (numerical code) is incorrect and the lock is not opened.
8	Entry not possible due to special setting or configuration.
20	Value for the application-specific display is not defined. The value to be displayed can be defined by the user by entering the address. No value is displayed because this has not yet occurred.



A flashing device status signals a prevailing message, a steady device status a message no longer prevailing, but which is still present in the status register. The status register "S.Reg" logs all alerts and warnings since the last "clear". Momentary statuses and reports can only be read via WinPADS.

**Example of a temperature sensor display**

- Change to column **Status** by repeated pressing of the key **→**.
- With **↓** to the message in which a different number is indicated instead of "0".
- "1", on the right in the display for SR.6 indicates a temperature alert.

The following appears in the display:

Status				Menu			
A		S	t	a	t	u	s
S	.	R	e	g			1. 4

Status				Menu			
A		S	.	R	e	g	
S	R	.	6				1






Table: Summary of messages in statuses 1 to 9

Message	St.1, SR.1	St.2, SR.2	St.3, SR.3	St.4, SR.4	St.5, SR.5	St.6, SR.6	St.7, SR.7	St.8, SR.8	St.9, SR.9
1	Alert for:								
	-	-	-	-	C*	T	p	K	z*
2	No useful inputs values for:								
	-	-	-	-	T	p			
4	Output error on output:								
	A1	A2	A3	A4	-	-	-	-	-
5	Error during pulse comparison on input:								
	-	E2	-	-	-	-	-	-	-
8	Warning for input:								
	-	E2	E3	-	-	-	-	-	-
10	Adjustment missing for:								
	-	-	-	-	T	p	-	-	-
13	Report for input:								
	-	E2	E3	-	-	-	-	-	-
14	Lock is open:								
	Cal.	Man.	Suppl.	Cust.	-	-	-	-	-

Service	Inputs	Outputs
Serv.	Inputs	Outp.
Bat.R Remaining batt. life	cp.E1 cp value Input 1	Md.A1 Mode for Output 1
Bat.C Battery capacity	cp.E2 cp value Input 2	SC.A1 Source for Output 1
St.SL Supplier lock	Md.E2 Mode for Input 2	cp.A1 cp value for Output 1
Cod.S Supplier combination	St.E2 Status on Input 2	SpA1 Status pointer A1
St.KL Customer lock	St.E3 Status on Input 3	Md.A2 Mode for Output 2
Cod.K Customer combination	SNM Serial no. of gas meter	SC.A1 Source for Output 2
St.CL Calibration lock		cp.A1 cp value for Output 2
Save Save all data		SpA1 Status pointer A2
Clr.V Clear counter		Md.A3 Mode for Output 3
Clr.X Initialise device		SC.A1 Source for Output 3
Bin.T Temp. raw value		cp.A1 cp value for Output 3
Bin.p Press. raw value		SpA1 Status pointer A3
Frz Freeze		Md.A4 Mode for Output 4
VbFr Frozen value		SC.A1 Source for Output 4
VmFr Frozen value		cp.A1 cp value for Output 4
T.Fr Frozen value		SpA1 Status pointer A4
p.Fr Frozen value		
C.Fr Frozen value		
K.Fr Frozen value		
- Display test		

**Clr**  
**Clear S.Reg**

**Clear status register**

Warnings (W) and/or alerts (A) which are no longer present, i.e. just displayed for information and are no longer flashing, can be cleared in the "Status" menu using the function "Clr". Press key combination  +  (ENTER). A "0" flashes to the right in the display. Pressing the key  sets the value to "1". Pressing  +  (ENTER) again clears the status register and indicates ok in the display. Alerts or warning states still present are then again indicated with the letter A and/or W flashing in the display.