

Short-Form Instructions Volume Conversion Device Type EK230

This product is discontinued!

The display is activated on pressing any key and the momentary counter reading **Vb** (volume at base conditions) is displayed in the menu **User**. All further data associated with the volume at base conditions can be displayed by pressing the key (see first column "Standard volume" on the inside page of these instructions).

The key is pressed to display a value in the column, standard volume. Now, the menu **Std. V** (Standard volume) is displayed. Using the keys and , you can view all the values associated with the volume at base conditions.

To change to a different menu (e.g.: **Press.**), the keys or are pressed until the desired menu name appears in the display. The transitions from one menu to a different one occur at the places identified by arrows (see inside page of the operating instructions).

Entering values

Values in the volume corrector (volume conversion device) which are not subject to the calibration lock or only computed (e.g. flow) or measured (e.g. pressure or temperature) can be changed even without a PC or readout device.

In these short-form instructions all values which are subject to the calibration lock are identified with "C". All values which are determined or measured and therefore can only be read are identified with a "-".

Example of changing a value

(adjustable counter in the menu actual volume (Act.V.))

- The display is activated by pressing any key.

The momentary counter reading **Vb** (volume at base conditions) is indicated in the menu **User** in the display.

Arc.		Status			Menu						Submenu	
		o	k	.	U	s	e	r				
V	b	0	0	0	0	0	1	2	3	4	m 3	

- Changing to the column Actual volume occurs by pressing the key .

The momentary counter reading **V** (actual volume) is indicated in the menu **Act.V.** in the display.

Arc.		Status			Menu						Submenu	
		o	k	.	A	c	t	.	V	.		
V	m	0	0	0	0	0	1	2	3	4	m 3	

- Within the menu, Actual volume, repeated pressing of the key changes to the value **VmA** (adjustable counter).

Arc.		Status			Menu						Submenu	
		o	k	.	A	c	t	.	V	.		
V	m	A	0	0	0	0	0	2	3	4	5	m 3

- The entry-mode is activated by pressing and keys (ENTER).

The modifiable display location **flashes**

The keys and enable skipping to the other places of the displayed value.

These can be changed with the keys and and refreshed by pressing the ENTER keys.

Arc.		Status			Menu						Submenu				
V	m	A													
		0	0	0	0	0	2	3	4	5	.	0	0	0	0

Pressing and keys (before pressing ENTER) causes the entry to be cancelled.

User list	Standard volume	Actual volume	Pressure
User	Std. V.	Act.V.	Press.
Vb Volume at base cond. (predecimal places) C	Vb Volume at base cond. (post-decimal places) C	Vm Actual volume C	p Pressure -
VmA Adjustable counter S	Qb Standard flow -	Qm Actual flow -	pMin Lower alarm limit S
p Pressure -	VbD Disturbance quantity S	VmD Disturbance quantity S	pMax Upper alarm limit S
T Temperature -	VbT Total quantity -	VmT Total quantity -	MRL.p Meas. range bottom S
Z Imperfect-gas factor -	VbA Adjustable counter S	VmA Adjustable counter S	MRU.p Meas. range top S
Zb Imperfect-gas factor in standard state C	VbME Month-end value -	VmME Month-end value -	p.F Substitute value C
C Conversion factor -	Time Time for VbME -	Time Time for VmME -	pb Press. at base cond. S
K.F K subst. value S			Md.p Pressure mode S
VbME Month-end value -			Typ.p Press. sensor type S
Time Time for VbME -			SNp Serial no. of sensor S
VmME Month-end value -			Eq1p Equ.coefficient 1 S
Time Time for VmME -			Eq2p Equ.coefficient 2 S
Menu Select. display menu			Eq3p Equ.coefficient 3 S

Chap. 3.2

Chap. 3.3

Access rights

The EK230 differentiates between 4 access parties. Each party has a lock and a corresponding combination code:

- C** Calibration lock
- M** Manufacturer's lock
- S** Supplier's lock
- K** Customer's lock

- Values which are measured or computed by the volume corrector, but can only be layed and are identified with a dash.

Example:

Status				Menu			
o	k	.		I	n	p	u
t	s			5	-	-	-

----x---- the possible error codes correspond to the following table.

Entry errors

Entry errors are displayed if incorrect entries are made by the operator via the keypad. After the entry key is released, the display skips back to the original state.

Chap. 3.4

Code	Description	Code	Description
1	The archive is empty	8	Entry not possible due to special setting
2	The archive value cannot be read.	11	The entry of the calorific value <i>Ho.b</i> in the energy list is not permitted. Please change <i>Ho.b</i> in the Volume corrector list
4	Parameter cannot be changed (constant)	12	The entry of this source (address) is not permitted.
5	No authorisation for changing the value	13	Clock has to be set to its starting value
6	Invalid value.	14	Gas analysis parameters for AGA-NX-19 do not match
7	Incorrect combination	20	Value for the application-specific display is not defined

Temperature	Conversion	Archive	Status
Temp.	Conv.	Archiv	Status
T Temperature	C Conversion factor	ArMP Meas. per. archive	S.Reg Status register
Tmin Lower alarm limit	K inv. compr. ratio factor	ArDay Day archive	Stat Momentary register
Tmax Upper alarm limit	pbX Pressure at base conditions for gas analysis input	Mper Meas. period	Cl Clear S.Reg.
MRL.T Meas. Range bottom	TbX Temp. at base conditions for gas analysis input	FrMP Freeze ArMP	Logb. Logbook
MRU.T Meas. Range top	Ho.b Calorofic value	Chap. 3.7	
T.F Substitute value	CO2 Carbon dioxide cont.	Chap. 3.8	
Tb Temp. at base cond.	H2 / N2 (accord. to Md.K)		
Md.T Temperature mode	Rhob / dr (accord. to Md.K)		
Typ.T Temp. sensor type	K.F K substitute value		
SNT Serial no. of sensor	Md.K K Mode		
Eq1T Equ. Coefficient 1	Chap. 3.6		
Eq2T Equ. Coefficient 2			
Eq3T Equ. Coefficient 3			
T1Adj Adjustment value 1			
T2Adj Adjustment value 2			
Prog Accept adjust			
T.Mes Temp. meas.			

important status/error messages

Output in the first line of the display


- A** Alarm
- W** Warning
- B** Remaining battery service life reached
- P** Calibration lock open
- o** On-line operation (data transmission)

A flashing device status signals a currently prevailing message, a steady device status shows a message no longer prevailing, but which is still located in the status register. The status register "**S.Reg**" documents all alarms and warnings since the last "clear".

Example of the display of a temperature sensor

- Change to the column **Status** by repeated pressing of the key → .
- The "1" on the right in the display, indicates a temperature alarm.
- Press "ENTER" to recall Status information as short text

Display indication is:



System	Service	Inputs	Outputs
System	Serv.	Inputs	Outp.
Time Date and time	Bat.R Remain. bat. life	cp.I1 cp va. Input 1	Md.O1 Mode for Output 1
MdTim Daylight sav. y/n	Bat.C Battery capacity	cp.I2 cp val. Input 2	SC.O1 Source Output 1
MCyc Meas. cycle time	St.SL Supplier lock	Md.I2 Mode for Input 2	cp.O1 cp value Output 1
Ocyc Operating cycle time	Cod.S Supplier code	St.I2 Status on Input 2	SpO1 Status pointer A1
Disp D. switch-off time	St.CL Customer lock	MdMI2 Mode monitor. E2	Md.O2 Mode for Output 2
Aut.V D. changeover tm.	Cod.C Customer code	SC.I2 Source mon. E2	SC.O2 Source Output 2
Ta.Rg Ambient temp.	St.PL Calibration lock	L1.I2 Limit 1 for E2	cp.O2 cp value Output 2
Vers Software version	Adj.T Adjustment factor	L2.I2 Limit 2 for E2	SpO2 Status pointer A2
Chk Softw. checksum	Save Save all data	SpI2 Stat. pointer E2	Md.O3 Mode for Output 3
	Clr.A Clear meas. archive	St.I3 Status on Input 3	SC.O3 Source Output 3
	Clr.V Clear counter	MdMI3 Mode mon. E3	cp.O3 cp value Output 3
	Clr.X Initialise device	SC.I3 Source mon. E3	SpO3 Status pointer A3
	Bin.T Temp. raw value	L1.I3 Limit 1 for E3	Md.O4 Mode for Output 4
	Bin.p Pressure raw value	SpI3 Stat. pointer mon. E3	SC.O4 Source Output 4
	Addr Addr. user display	SNM Serial no. of meter	cp.O4 cp value Output 4
	UsD2 User display		SpO4 Status pointer A4
	WRp Repair counter W		
	VbRp Repair Counter Vb		
	VmRp Repai counter V		
	Rep. Repair Mode		
	ArCal Frozen values		
	Frz Freeze		
	- Display test		

Chap. 3.9

Chap. 3.11

Chap. 3.12

Clr
Clear S.Reg

Clear status register

Warnings (W) and/or alarms (A) which are no longer prevailing, i.e. only displayed for information, but no longer flashing, are cleared in the menu "Status" – "Clr" by pressing the – ↑ +↓ keys (ENTER) . To the right in the display a "0" flashes. By pressing the ↑ key the value is set to "1". Pressing the – ↑ +↓ keys (ENTER) again clears the status register and **ok** appears in the display. Alarm or warning statuses still prevailing are then again indicated with the letter A and/or W flashing in the display.

to
"Outputs"

Interfaces

Ser.IO	
Md.S2 Mode Interface 2	S
DF.S2 Data format Interf. 2	S
Bd.S2 Baud rate interf. 2	S
Num.T Ring tones bef. answer	S
M.INI initialise modem	S
Csync Remote clock setting	C
GSM.N GSM network	-
GSM.L Reception level	-
Bd.S1 Baud rate interf. 1	S
CW1.S Call window 1 Start	S
CW1.E Call window 1 end	S
CW2.S/M.Cw1 (accord. to setting)	S
CW2.E/M.onl (accord. to setting)	S

Chap. 3.13

Energy

Energy	
W Energy	S
P Power	-
WD W disturbance	S
WT W total	-
WA W adjustable	S
Ho.b Calorific value	S
W.ME W month end	-
Time Time of W.ME	-

Chap. 3.14