


This product is discontinued!

Short-Form Instructions Volume Conversion Device Type EK260



The display is activated on pressing any key and the momentary counter reading V_b (volume at base conditions) is displayed in the menu **Stand. V**. All further data associated with the volume at base conditions can be displayed by pressing the key \downarrow (see first column "Standard volume" on the inside page of these instructions).

The key \rightarrow is pressed to display a value in the column, Actual volume. Now, the menu **Act. V** (Actual volume) is displayed. Using the keys \downarrow and \uparrow , you can view all the values associated with the actual volume.

To change to a different menu (e.g.: **Press.**), the keys \leftarrow or \rightarrow are pressed until the desired menu name appears in the display. The transitions from one menu to a different one occur at the places identified by arrows (see inside page of the operating instructions).

Standard volume		Actual volume		Pressure		Temperature	
StandV.		Act.V.		Press.		Temp.	
Vb Volume at base conditions	C	Vm Actual volume	C	p Pressure	-	T Temperature	-
Qb Standard flow	-	Qm Actual flow	-	p.LW Lower warn. limit	S	T.LW Lower warn. limit	S
VbD Disturbance quant.	S	VmD Disturbance quant	S	p.UW Upper warn. limit	S	T.UW Upper warn. limit	S
VbT Total quantity	-	VmT Total quantity	-	pMin Lower alarm limit	C	Tmin Lower alarm limit	C
VbA Adjustable counter	S	VmA Adjustable counter	S	pMax Upper alarm limit	C	TMax Upper alarm limit	C
SC.Qb Source monitoring	S	SC.Qm Source monitoring.	S	MRL.p Meas. range bottom	C	MRL.T Meas. range bottom	C
QbUW Upper warn. limit	K	Qm.UW Upper warn. limit	K	MRU.p Meas. range top	C	MRU.T Meas. range top	C
QbLW Lower warn. limit	K	Qm.LW Lower warn. limit	K	p.F Substitute value	S	T.F Substitute value	S
VbMP Δ Meas. per. counter	-	Vm.MP Δ Meas. per. counter	-	pb Pressure at base conditions	C	Tb Temperature at base conditions	C
VbMP max S	-	Vm.MP max S	-	Md.p Pressure mode	C	Md.T Temperature mode	C
VbDy Δ Daily counter	-	Vm.Dy Δ Daily counter	-	Typ.p Press. sensor type	C	Typ.T Temp. sensor type	C
VbDy max S	-	Vm.Dy max S	-	SNp Serial no. of sensor	C	SNT Serial no. of sensor	C

Operating Instructions Chapter 3.1

Chap. 3.2

Chap. 3.3

Chap. 3.4

Access rights

The EK260 differentiates between 4 access parties. Each party has a lock and a corresponding combination code:

- C** Calibration lock*
- M** Manufacturer's lock
- S** Supplier's lock
- K** Customer's lock
- Values which are measured or computed by the volume corrector, but can only be displayed and are identified with a dash.
- S Submenu for entry press ENTER quit with ESC

Chap. 3.3


Chap. 3.4

to Temp	Correction	Archive	Status + Logbook	System	to Serv.
↔	Correct	Archive	Status	System	↔
	C Conversion factor -	ArMo1 Arc Month archive 1 -	S.Reg S Status register -	Time Date and time S	
	K inv. compr. ratio factor -	ArMo2 Arc Month archive 2 -	Stat S Current status -	MdTim Daylight sav.yes/no S	
	Ho.b Calorific value S	ArMP Arc Meas. per. archive -	Clr Clear S.Reg S	MCyc Meas. cycle time C	
	CO2 Carb. dioxide cont. S	MPer Meas. period C	Logb. Arc Logbook -	OCyc Oper. cycle time S	
	H2 Hydrogen content S	MP.Re Remain. time of MP -	AudTr Arc Audit Trail -	Disp Disp.switch-off time S	
	Rhob Density gas at base cond. S	FrMP ArMP frozen S	Chap. 3.7	Aut.V Display changeover time C	
	K.F K substitute value S	Chap. 3.6	important status/error messages	Ta.Rg Amb. temp. range C	
	Md.K K Mode C	Output in the first line of the display	A Alarm	Vers Software version -	
Chap. 3.5		W Warning	B Remaining battery service life reached	ChK Software checksum -	
		P Calibration lock open	o Online operation (data transmission)	Chap. 3.8	

A flashing device status signals a currently prevailing message, a steady device status shows a message no longer prevailing, but which is still located in the status register. The status register "S.Reg" documents all alarms and warnings since the last "clear". The momentary status "Stat" indicates momentary alarms, warnings and reports as numbers, separated in each case by a point.

Example of the display of a temperature sensor

- Change to the column **Status** by repeated pressing of the key \rightarrow
- The following appears in the display:



	Message	St.1, SR.1	St.2, SR.2	St.3, SR.3	St.4, SR.4	St.5, SR.5	St.6, SR.6	St.7, SR.7	St.8, SR.8	St.9, SR.9
Alarms	1	Alarm for:								
		-	-	-	-	C*	T	p	K	z*
Warnings	2	No usable input values for:								
		E1	-	-	-	T	p			
	4	Output error (pulse buffer overflow) on output:								
		A1	A2	A3	A4	-	-	-	-	-
	5	Error during pulse comparison on input:								
		-	E2	-	-	-	-	-	-	-
	6	Warning limits violated for:								
		-	Qb	-	Q	-	T	p	-	-
	8	Warning for input:								
		-	E2	E3	-	-	-	-	-	-

Table: Overview of messages in Status 1 to 8

* "C" = conversion factor, "z" = imperfect-gas factor

All messages > 8 identify reports which represent no alarms or warnings.

Example: 14 = Calibration lock open; 15 = Battery mode; 16 = Call acceptance window open

Service		Inputs		Outputs		Interfaces	
Serv.		Inp.		Out.		Ser.IO	
-	-	Vo	-	Md.A1	C	Md.S2	S
Display test	-	Orig. counter Input 1 only in Encoder mode	-	Mode for Output 1	C	Mode Interface 2	S
Bat.R	-	CP.E1	C	SC.A1	C	DF.S2	S
Remaining bat. life	-	Cp value Input 1	C	Source Output 1	C	Data format Interf. 2	S
Bat.C	S	Md.E1	C	cp.A1	C	Bd.S2	S
Battery capacity	S	Mode for Input 1	C	cp value Output 1	C	Baud rate Interf. 2	S
St.SL	S	V1	S	SpA1	C	TypS2	S
Supplier lock	S	Adj. counter Input 1	S	Status pointer A1	C	RS.232 / RS.485	S
Cod.S	S	CP.E2	C	Md.A2	C	Num.T	S
Supplier code	S	Cp value Input 2	C	Mode Output 2	C	Ring tones bef. ans.	S
St.CL	K	Md.E2	S	SC.A2	C	M.INI	S
Customer lock	K	Mode for Input 2	S	Source Output 2	C	Initialise Modem	S
Cod.C	K	V2	S	cp.A2	C	Bd.S1	S
Customer code	K	Adj. counter Input 2	S	Cp value Output 2	C	Baud rate Int. 1	S
St.PL	K	St.E2	-	SpA2	C	CW1.S	S
Calibration lock	K	Status on Input 2	-	Status pointer A2	C	Call window 1 Start	S
Contr	S	MdME2	S	Aj1A2	S	CW1.E	S
Display contrast	S	Mode monitoring E2	S	HF adjust. factor 1	S	Call window 1 End	S
AdjTm	C	SC.E2	S	Aj2A2	S	CW2.S	S
Adjustment factor	C	Source monitor'g E2	S	HF adjust. factor 2	S	Call window 2 Start	S
Sel.p	C	L1.E2	S	f1.A2	S	CW2.E	S
Select. press. sens	C	Limit 1 for E2	S	Frequ. for Aj1A2	S	Call window 2 End	S
Save	S	L2.E2	S	f2.A2	S		
Save all data	S	Limit 2 for E2	S	Frequ. for Aj2A2	S		
Clr.V	C	SpE2	S	Md.A3	S		
Clear counter	C	Stat. point. mon. E2	S	Mode Output 3	S		
Clr.X	C	St.E3	-	SC.A3	S		
Initialise device	C	Status on Input E3	-	Source Output 3	S		
Bin.T	-	MdME3	S	cp.A3	S		
Temp. raw value	-	Mode monitoring E3	S	Cp value Output 3	S		
Bin.p	-	SC.E3	S	SpA3	S		
Pressure raw value	-	Source monitor'g E3	S	Status pointer A3	S		
ArCal	Arc	L1.E3	S	Md.A4	S		
Frozen values	-	Limit 1 for E3	S	Mode Output 4	S		
Frz.	S	SpE3	S	SC.A4	S		
Freeze	S	Stat. point. mon. E3	S	Source Output 4	S		
		SNM	S	cp.A4	S		
		Serial no. gas meter	S	Cp value Output 4	S		
				SpA4	S		
				Status pointer A4	S		

Chap. 3.9

Chap. 3.10

Chap. 3.11

Chap. 3.12

Chap. 3.13

Clr
Clear S.Reg

Clear status register

Warnings (W) and/or alarms (A) which are no longer prevailing, i.e. only displayed for information, but no longer flashing, are cleared in the menu "Status" – "Clr" by pressing the – **ENTER** key. To the right in the display a "0" flashes. By pressing the ↑ key the value is set to "1". Pressing the **ENTER** key again clears the status register and **ok** appears in the display. Alarm or warning statuses still prevailing are then again indicated with the letter A and/or W flashing in the display.

User list

User	
VbT	-
Vb total	-
VmT	-
Vm total	-
p	-
Pressure	-
T	-
Temperature	-
K	-
Gas law dev. factor	-
C	-
Conversion factor	-
S.Reg	S
Status register	S
VbMP max	-
Month maximum Vb	-
Date	-
For month max. Vb	-
Time	-
For month max. Vb	-
Qb	-
Standard flow	-
Qm	-
Actual flow	-

Entering values

Values in the volume corrector (Volume Conversion Device) which are not subject to the calibration lock or only computed (e.g. flow) or measured (e.g. pressure or temperature) can be changed even without a PC or readout device.

In these short-form instructions all values which are subject to the calibration lock are identified with "C". All values which are determined or measured and therefore can only be read are identified with a "-".

Example of changing a value

(adjustable counter in the menu actual volume (Act.V.))

- The display is activated by pressing any key.

The momentary counter reading **Vb** (volume at base conditions) is indicated in the menu **StandV** in the display.

Prefix		Arc.	Status			Menu								
			o	k	.	S	t	a	n	d	V	.		Submenu
V	b		0	0	0	0	0	1	2	3	4		m	3

- Changing to the column Actual volume occurs by pressing the key

The momentary counter reading **Vm** (actual volume) is indicated in the menu **Act.V** in the display.

Prefix		Arc.	Status			Menu								
			o	k	.			A	c	t	.	V		Submenu
V	m		0	0	0	0	0	1	2	3	4		m	3

- Within the menu, Actual volume, repeated pressing of the key changes to the value **VmA** (adjustable counter).

Prefix		Arc.	Status			Menu									
			o	k	.			A	c	t	.	V		Submenu	
V	m	A	*	0	0	0	0	0	2	3	4	5		m	3

- The entry mode is activated by pressing the **Enter** key.

The modifiable display location .

The keys and enable skipping to the other places of the displayed value.

These can be changed with the keys and and refreshed by pressing the **Enter** key.

Prefix		Arc.	Status			Menu									
V	m	A												Submenu	
		0	0	0	0	0	2	3	4	5	.	0	0	0	0

Pressing the **ESC** key (before the **Enter** key is pressed) causes the entry to be cancelled.

Entry errors

Entry errors are displayed if incorrect entries are made by the operator via the keypad. After the entry key is released, the display skips back to the original state.

Example:

Prefix		Arc.	Status			Menu				Submenu	
			o	k	.		l	n	p		.
C	P	.	E	1	-	-	-	5	-	-	-

----x---- the possible error codes correspond to the following table.

Code	Description
1	The archive is empty, no values are available yet.
2	The archive value cannot be read. The archive has possibly just been opened by the interface for reading out.
4	Parameter cannot be changed (constant).
5	No authorisation for changing the value. To change the value the appropriate lock must be opened.
6	Invalid value. Entered value is outside the permissible limits.
7	Incorrect combination. The entered combination (numerical code) is incorrect and the lock is not opened.
11 *	Entry not possible due to special setting or configuration - The entry of V and VD in the encoder mode (<i>Md.E1</i> = 5) is not possible. - <i>Md.E1</i> cannot be set to "5" with devices without encoder capability.
12	The entry of this source (address) is not permissible with Output Mode 8. The addresses of Qb, Q, p, T are, for example, allowed.
20	Value for the application-specific display is not defined. The value to be displayed can be defined by the user by entering the address. No value is displayed because this has not yet occurred.

* With an EK260 with a software version below 2.10, this error is displayed with code "8".