





Eclipse Mark IV Combination Gas/Oil Burners

Series "MF"



Copyright

Copyright 1986 by Eclipse, inc. All rights reserved worldwide. This publication is protected by federal regulation and shall not be copied, distributed, transmitted, transcribed or translated into any human or computer language, in any form or by any means, to any third parties, without the express written consent of Eclipse, inc.

Disclaimer Notice

In accordance with the manufacturer's policy of continual product improvement, the product presented in this brochure is subject to change without notice or obligation.

The material in this manual is believed adequate for the intended use of the product. If the product is used for purposes other than those specified herein, confirmation of validity and suitability must be obtained. Eclipse warrants that the product itself does not infringe upon any United States patents. No further warranty is expressed or implied.

Liability & Warranty

We have made every effort to make this manual as accurate and complete as possible. Should you find errors or omissions, please bring them to our attention so that we may correct them. In this way we hope to improve our product documentation for the benefit of our customers. Please send your corrections and comments to our Technical Documentation Specialist.

It must be understood that Eclipse's liability for its product, whether due to breach of warranty, negligence, strict liability, or otherwise is limited to the furnishing of replacement parts and Eclipse will not be liable for any other injury, loss, damage or expenses, whether direct or consequential, including but not limited to loss of use,

income, or damage to material arising in connection with the sale, installation, use of, inability to use, or the repair or replacement of Eclipse's products.

Any operation expressly prohibited in this manual, any adjustment, or assembly procedures not recommended or authorized in these instructions shall void the warranty.

Document Conventions

There are several special symbols in this document. You must know their meaning and importance.

The explanation of these symbols follows below. Please read it thoroughly.

How To Get Help

If you need help, contact your local Eclipse representative. You can also contact Eclipse at:

1665 Elmwood Rd.
Rockford, Illinois 61103 U.S.A.
Phone: 815-877-3031
Fax: 815-877-3336
<http://www.eclipsenet.com>

Please have the information on the product label available when contacting the factory so we may better serve you.

 ECLIPSE <small>Innovative Thermal Solutions</small>	www.eclipsenet.com
Product Name	
Item #	
S/N	
DD MMM YYYY	



This is the safety alert symbol. It is used to alert you to potential personal injunt hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



Indicates a hazardous situation which, if not avoided, will result in death or serious injury.



Indicates a hazardous situation which, if not avoided, could result in death or serious injury.



Indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

Is used to address practices not related to personal injury.

NOTE

Indicates an important part of text. Read thoroughly.



Table of Contents

Introduction	4
Product Description	4
Audience.....	4
Mark IV Documents.....	4
Safety	5
Safety Warnings	5
Capabilities.....	5
Operator Training	5
Replacement Parts.....	5
Installation	6
Introduction.....	6
Handling & Storage	6
Approvals of Components	6
Checklist Before Installation	7
Mounting the Burner	7
Electrical Connections.....	8
Sequence of Operation for Suggested Control Panel	9
Bill of Materials	10
Gas, Oil and Atomizing Air Piping	11
Initial Lightoff	12
Adjustment, Start & Stop	13
Linkage Adjustment - 100 and 200 MF.....	13
Combustion Air Flow Adjustment - 100 and 200 MF	13
Linkage Adjustment - 300 and 500 MF.....	15
Combustion Air Flow Adjustment - 300 and 500 MF	15
Gas Flow Adjustment - all models	17
Oil Flow Adjustment - all models	17
Maintenance & Troubleshooting	18
Appendix.....	i

Introduction

1

Product Description

Eclipse Mark IV Burners are packaged, nozzle-mixing, combination gas/oil burners for use in process heating applications including ovens and dryers. Mark IV burners can be used with any commercially available fuel gas and with fuel oils up to #2 oil.

Mark IV burners have been used to dry paint, paper and paper products, fabric, food products, ink, laminates, packaging film, carpets and a wide variety of other products. In addition, the Mark IV is capable of firing boilers, furnaces, incinerators, metal smelters and other equipment requiring a combustion block.




Figure 1.1 Mark IV Burner

Audience

This manual has been written for people who are already familiar with all aspects of a nozzle-mix burner and its add-on components, also referred to as “the burner system”.

These aspects are:

- Design / Selection
- Use
- Maintenance

The audience is expected to have previous experience with this type of equipment.

Mark IV Documents

Installation Guide 130

- This document

Datasheet 130

- Required to complete design and selection

Related Documents

- EFE 825 (Combustion Engineering Guide)
- Eclipse Bulletins and Info Guides: 684, 710, 732, 756, 760, 902, 930

Safety

Important notices which help provide safe burner operation will be found in this section. To avoid personal injury and damage to the property or facility, the following warnings must be observed. All involved personnel should read this entire manual carefully before attempting to start or operate this system. If any part of the information in this manual is not understood, contact Eclipse before continuing.

Safety Warnings



DANGER

- **The burners, described herein, are designed to mix fuel with air and burn the resulting mixture. All fuel burning devices are capable of producing fires and explosions if improperly applied, installed, adjusted, controlled or maintained.**
- **Do not bypass any safety feature; fire or explosion could result.**
- **Never try to light a burner if it shows signs of damage or malfunction.**



WARNING

- **The burner and duct sections are likely to have HOT surfaces. Always wear the appropriate protective equipment when approaching the burner.**
- **Eclipse products are designed to minimize the use of materials that contain crystalline silica. Examples of these chemicals are: respirable crystalline silica from bricks, cement or other masonry products and respirable refractory ceramic fibers from insulating blankets, boards, or gaskets. Despite these efforts, dust created by sanding, sawing, grinding, cutting and other construction activities could release crystalline silica. Crystalline silica is known to cause cancer, and health risks from the exposure to these chemicals vary depending on the frequency and length of exposure to these chemicals. To reduce the risk, limit exposure to these chemicals, work in**

a well-ventilated area and wear approved personal protective safety equipment for these chemicals.

NOTICE

- **This manual provides information regarding the use of these burners for their specific design purpose. Do not deviate from any instructions or application limits described herein without written approval from Eclipse.**

Capabilities

Only qualified personnel, with sufficient mechanical aptitude and experience with combustion equipment, should adjust, maintain or troubleshoot any mechanical or electrical part of this system. Contact Eclipse for any needed commissioning assistance.

Operator Training

The best safety precaution is an alert and trained operator. Train new operators thoroughly and have them demonstrate an adequate understanding of the equipment and its operation. A regular retraining schedule should be administered to ensure operators maintain a high degree of proficiency. Contact Eclipse for any needed site-specific training.

Replacement Parts

Order replacement parts from Eclipse only. All Eclipse approved valves or switches should carry UL, FM, CSA, CGA and/or CE approval where applicable.

Installation

Introduction

In this chapter you will find information and instructions needed to install the burner and system components.

Handling & Storage

Handling

- Make sure that the area is clean.
- Protect the components from the weather, damage, dirt and moisture.
- Protect the components from excessive temperatures and humidity.
- Take care not to drop or damage components.

Storage

- Make sure that the components are clean and free of damage.
- Store the components in a cool, clean, dry room.
- After you have made sure that everything is present and in good condition, keep the components in the original package as long as possible.

Approval of Components

Limit Controls & Safety Equipment

All limit controls and safety equipment must comply with all applicable local codes and/or standards and must be listed for combustion safety by an independent testing agency. Typical application examples include:

- American: NFPA 86 with listing marks from UL, FM, CSA
- European: EN 746-2 with CE mark from TuV, Gastec, Advantica

Electrical Wiring

All the electrical wiring must comply with all applicable local codes and/or standards such as:

- NFPA Standard 70
- IEC60364
- CSA C22
- BS7671

Gas Piping

All the gas piping must comply with all applicable local codes and/or standards such as:

- NFPA Standard 54
- ANSI Z223
- EN 746-2

Where to Get the Standards:

The NFPA Standards are available from:

National Fire Protection Agency
Batterymarch Park
Quincy, MA 02269
www.nfpa.org

The ANSI Standards are available from:

American National Standard Institute
1430 Broadway
New York, NY 10018
www.ansi.org

The UL Standards are available from:

333 Pfingsten Road
Northbrook, IL 60062
www.ul.com

The FM Standards are available from:

1151 Boston-Providence Turnpike
PO Box 9102
Norwood, MA 02062
www.fmglobal.com/approvals

Information on the EN standards and where to get them is available from:

Comité Européen de Normalisation
Stassartstraat 36
B-1050 Brussels
Phone: +32-25196811
Fax: +32-25196819
www.cen.eu

Comité Européen de Normalisation Electronique
Stassartstraat 36
B-1050 Brussels
Phone: +32-25196871
Fax: +32-25196919
www.cenelec.org

Checklist Before Installation

Intake

To admit fresh combustion air from outdoors, provide an opening in the room of at least one square inch per 4,000 Btu/h (1.17 kW). If there are corrosive fumes or materials in the air, then supply the burner with clean air from an uncontaminated area, or provide a sufficient air filtering system.

Exhaust

Do not allow exhaust fumes to accumulate in the work area. Provide some positive means for exhausting from the furnace and the building.

Access

Make sure that you install the burner in such a way that you can gain easy access for inspection and maintenance.

Environment

Make sure the local environment matches the original operating specifications. Check the following items:

- Voltage, frequency and stability of the electrical power
- Type and supply pressure of the fuel
- Availability of enough fresh, clean combustion air
- Humidity, altitude and temperature of air
- Presence of damaging corrosive gases in the air
- Prevent direct exposure to water

Mounting the Burner **(see Figures 3.1 and 3.2)**

1. Figure 3.1 illustrates burner mounting when there is access to the inside of the appliance wall. This method is preferred since the tube can be removed for replacement or to allow servicing of the nozzle without disturbing the burner or its linkage and piping. Figure 3.2 illustrates burner mounting when there is no access to the inside of the appliance wall. The studs are pressed in or welded to the wall. The burner and the tube mount from the outside. The nozzle can be removed through the rear of the burner in these installations.
2. If the burner weight is to be supported entirely by the appliance wall, the wall must be at least 1/4" thick plate. If it is not, support must be provided for the burner.
3. Bolts or studs can be utilized to mount the burner and firing tube to the appliance wall. Care should be taken to match the mounting bolt pattern to the burner mounting flange bolt circle. All Mark IV burners and firing tubes have (8) 9/16" diameter holes for mounting. Bolt circle diameters are as follows: 100 and 200 MF, 10-1/2"; 300 and 500 MF, 14-5/8". Bolts or studs used for mounting should be 1/2" NC

4. An adequately sized opening must be provided in the appliance wall to grant clearance for the burner firing tube. If the appliance wall is insulated, 4" additional clearance should be provided all around the firing tube so air can circulate around the tube and protect the firing tube from overheating in the area of the insulation.
5. If the burner has been supplied with a combustion block, refer to P-5 Installation Instructions covering combustion blocks and block holders.




Figure 3.1. Mounting with Access to Inside of Appliance




Figure 3.2. Mounting with No Access to Inside of Appliance

Electrical Connections

1. All electrical equipment furnished with the "complete" Mark IV burner is prewired to a terminal strip. See Figure 3.3.
2. A combustion control panel is required for all Mark IV burners. Figure 3.4 illustrates the suggested control panel wiring diagram and operating sequence.

Interface wiring between the control panel and the burner terminal strip must be done correctly and electrical sources supplying power to the burner must be of proper voltage and frequency. The three phase motor supplied with the Mark IV burner to drive the combustion air fan has been wired for the voltage requested on the customer's order. If motor voltage is questioned, check motor nameplate and physical wiring in the motor terminal box.

The Eclipse Mark IV burner is not supplied standard with flame monitoring equipment. Eclipse offers three different scanner mounting parts groups: a PCI scanner; a Honeywell scanner; or a Fireye scanner. If ordered, each is installed on the burner with necessary fittings and conduit and wired to the terminal strip. It is

the customer's responsibility to provide a compatible relay in the control panel. If the Mark IV burner has been ordered without one of the three scanner mounting parts groups, it is also the customer's responsibility to provide a scanner for mounting on the burner and all wiring from the scanner to the relay.

NOTICE

- **Do not attempt to operate this burner without adequate flame monitoring equipment. The owner/user and/or his insurance underwriter must assume responsibility for the acceptance, use, and proper maintenance of the limit controls and other safety devices included with this burner. They must also assume responsibility of the flame supervision provided in the control panel, the interfacing of all electrical equipment, and the sequencing of burner operation between the control panel and the burner.**




Figure 3.3. Terminal Strip Wiring Diagram for MF-CGO-IRI (FIA) Burner

A	Combustion Blower Motor
B	Low and High Gas Pressure Switches
C	Low and High Oil Pressure Switches
D	Combustion Air Flow Switch
E	Atomizing Air Pressure Switch
F	Pilot Valve
G	Ignition Transformer (115/6000 V)
H	Automatic Main Gas Valve
J	Automatic Gas Shutoff Valve

K	Vent Valve
L	Main Oil Shutoff Valves, #1 and #2
M	Atomizing Air Valve
N	
P	Ultraviolet Flame Detector
Q	Control Motor M941-A with Cover Mounted Transformer
R	High Fire Proving Limit Switch (optional)
S	Low Fire Proving Limit Switch (optional)

Sequence of Operation for Suggested Control Panel

Gas Operation Sequence

Power on, fuel selector in "GAS" position.

1. The "start" push button is depressed, powering the motor starter (MS) coil through the "MS-OLS" NC contacts.
2. The MS NO auxiliary contacts close; to hold in the start circuit and initiate the FS limit circuit.
3. The combustion blower motor starts to run and the combustion air flow switch (CAFS) closes, causing the "blower on" yellow light to illuminate.
4. If the customer's external limiting circuit (ELC) is closed and all necessary fuel pressure switches are closed, power will pass through both the "gas-oil" selector switch and the TR2 and CR2 NC contacts to energize the CR1 relay.
5. The CR1 NC and NO contacts reverse to drive TCA control motor to the high fire (open register) position.
6. The high fire proving limit switch (HFLS) closes to power the pre-purge timer (PPT) and illuminate the "purging" amber light through PPT NC contact.
7. When the 0 - 5 minute adjustable, pre-purge timer times out, it switches to energize the CR2 relay and turn off the "purging" amber light.
8. The CR2 NC contact opens to de-energize the CR1 relay, and the CR2 NO contact closes for the PPT timer holding circuit.
9. The CR1 NC and NO contacts return to normal position and the TCA control motor drives back to low.
10. The low fire proving limit switch (LFLS) closes to power terminal 1 on the protectofier and starts the ignition cycle.
11. Protectofier terminal 3 powers the ignition transformer through TR1 NC contact, the pilot valve through TR2 NC contact, and the TR1 timed relay (10 seconds).
12. Protectofier terminal 5 powers the "flame on" blue light.
13. After a 10 second delay, the TR1 NC contact opens to de-energize the ignition transformer, the TR1 NO contact closes to hold in the circuit around the PPT timer and the LFLS, and the TR1 NO contact closes to energize the main gas valve, the gas shutoff valve and the vent valve.
14. When the main gas valve is fully opened, it switches to illuminate the "gas burner on" green light and to energize the TR2 timed relay (10 seconds).
15. After a 10 second delay, the TR2 NC contact opens to reset the purge timer, the TR2 NC contact opens to de-energize the pilot gas valve, and the TR2 NC and NO contacts reverse to release the TCA control motor from low fire start.
16. The burner is now on (flame proven) and operating from the temperature controller.

Oil Operation Sequence

Power on, fuel selector in "OIL" position.

1. The "start" push button is depressed, powering the motor starter (MS) coil through the "MS-OLS" NC contacts.
2. The MS NO auxiliary contacts close; to hold in the start circuit and initiate the FS limit circuit.
3. The combustion blower motor starts to run and the combustion air flow switch (CAFS) closes, causing the "blower on" yellow light to illuminate.
4. If the customer's external limiting circuit (ELC) is closed and all necessary fuel pressure switches are closed, power will pass through both the "gas-oil" selector switch and the TR2 and CR2 NC contacts to energize the CR1 relay.
5. The CR1 NC and NO contacts reverse to drive TCA control motor to the high fire (open register) position.
6. The high fire proving limit switch (HFLS) closes to power the pre-purge timer (PPT) and illuminate the "purging" amber light through PPT NC contact.
7. When the 0 - 5 minute adjustable, pre-purge timer times out, it switches to energize the CR2 relay and turn off the "purging" amber light.
8. The CR2 NC contact opens to de-energize the CR1 relay, and the CR2 NO contact closes for the PPT timer holding circuit.
9. The CR1 NC and NO contacts return to normal position and the TCA control motor drives back to low.
10. The low fire proving limit switch (LFLS) closes to power terminal 1 on the protectofier and starts the ignition cycle.
11. Protectofier terminal 3 powers the ignition transformer through TR1 NC contact, the pilot valve through TR2 NC contact, and the TR1 timed relay (10 seconds).
12. Protectofier terminal 5 powers the "flame on" blue light.
13. After a 10 second delay, the TR1 NC contact opens to de-energize the ignition transformer, the TR1 NO contact closes to hold in the circuit around the PPT timer and the LFLS, and the TR1 NO contact closes to energize the atomizing air valve.
14. The atomizing air pressure switch (AAPS) should close shortly after the atomizing air valve is powered. This will power the main oil valves, which will illuminate the "oil burner on" green light and energize the TR2 timed relay (10 seconds).
15. After a 10 second delay, the TR2 NC contact opens to reset the purge timer, the TR2 NC contact opens to de-energize the pilot gas valve, and the TR2 NC and NO contacts reverse to release the TCA control motor from low fire start.
16. The burner is now on (flame proven) and operating from the temperature controller.

Bill of Material

MF Burner Equipment

- LGPS Low Fire Gas Pressure Switch
- HGPS High Gas Pressure Switch
- LOPS Low Oil Pressure Switch
- HOPS High Oil Pressure Switch
- CAFS Combustion Air Flow Switch
- AAPS Atomizing Air Pressure Switch
- LFLS Low Fire Proving Limit Switch (optional)
- HFLS High Fire Proving Limit Switch (optional)
- PGV Pilot Gas Valve
- PIT Ignition Transformer (115 / 6000V)
- VGW Vent Valve (NO)
- SGV Automatic Gas Shutoff Valve
- MGV Automatic Main Gas Valve
- MOV1 Mail Oil Shutoff Valve #1
- MOV2 Mail Oil Shutoff Valve #2
- AAV Atomizing Air Valve
- UVS Ultraviolet Flame Detector
- TCA Control Motor (Electric - Honeywell shown)

Panel Equipment

- CB Circuit Break or Disconnect Switch
(See Note 1)
- MS Motor Starter (See Note 1)
- CCT Control Circuit Transformer
(See Notes 1 and 3)
- FI Fuse
- PPT Pre-Purge Timer (0 - 5 minute adjustment)
- 7256BH PCI Protectofier Combustion Safeguard
- AH Alarm Horn (Flame Failure Lockout)
- CR1 Relay, Drive Control Motor to High Fire Position
- CR2 Relay, interrupts power to CR1 and provides holding circuit for purge timer
- TR1 Timed Relay (10 seconds) interrupted ignition, FS holding circuit and delay on energizing main fuel valves
- TR2 Timed Relay (10 seconds) interrupted pilot, low fire start and purge timer reset

External Equipment

- ELC External Limiting Circuit (example: high temperature limit switch)
- TC Temperature Controller (Partlow shown)




Figure 3.4. Wiring Diagram for Suggested Control Panel

Gas, Oil and Atomizing Air Piping (see Figure 3.5)

1. All field piping, particularly the fuel oil and atomizing air supply pipes, should be inspected during field assembly to insure they are free from foreign material and pipe scale. Use of clean pipe will help ensure trouble-free startup and operation.
2. Never use Teflon tape for field piping connections. Since commercial piping usually does require some type of sealant on the threads to ensure leak-free connections, Eclipse suggests the use of Loctite Teflon Pipe Sealant #92-31. Any pipe sealant used should be applied with care and excess sealant should be removed before joints are made up. Fittings should be torqued to 60 in. lb. +/- 20 in. lb.
3. Eclipse recommends that suitable pipe union disconnects be used in the pipe trains as near to the burner as is convenient. Burner pipe sizes supplied on the burner are adequate for short piping runs. If longer piping runs are to be utilized, piping loss must be taken into consideration and pipe sized accordingly.
4. Refer to the "Inlet Pressure Requirements" table on page 12 for pressures required at the burner valve train inlets.
5. It is the customer's responsibility to supply #2 or lighter fuel oil to the burner at the steady pressure indicated in the table on page 12. The fuel supply must be clean and it is the customer's responsibility to supply filters and strainers capable of removing particles larger than 40 microns in the oil pipe line. The oil filter on the burner should be considered only as a final filter.
6. It is the customer's responsibility to supply #2 or lighter fuel oil to the burner at the steady pressure indicated in the table on page 12. The fuel supply must be clean and it is the customer's responsibility to supply filters and strainers capable of removing particles larger than 40 microns in the oil pipe line. The oil filter on the burner should be considered only as a final filter.
7. It is the customer's responsibility to supply compressed air to the atomizing air valve train at the pressure indicated in the chart. The atomizing air must be clean (40 micron maximum particle size) and dry (dew point 30°F below ambient). The customer is to supply adequate dryers and filters in the atomizing air supply piping. The filter and moisture separator supplied on the burner assembly should be considered only as a final filter and separator.
8. All piping should be checked for leakage before attempting initial lightoff.
9. See "Pressure Settings" table on page 12 for pressures at locations A, B, C and D on Figure 3.5.

Figure 3.5 shows the order in which the components appear in the valve trains and the approximate location where the valve trains connect to the burner. The pressure checking cocks are also shown in their approximate locations. This schematic is NOT an exact representation of the burner's appearance and is intended only to aid in identification of the various components.




Figure 3.5. Component Identification

Inlet Pressure Requirements*

Burner Catalog Number	Natural Gas, 0.65 sp. gr.	Propane, 1.52 sp. gr.	#2 Fuel Oil	Atomizing Air Required Flow and Pressure
100 MF	14" - 28" w.c.	6" - 12" w.c.	75 - 100 psig	3.25 scfm @ 65 - 100 psig
200 MF	14" - 28" w.c.	6" - 12" w.c.	75 - 100 psig	3.25 scfm @ 65 - 100 psig
300 MF	14" - 28" w.c.	6" - 12" w.c.	75 - 100 psig	13.0 scfm @ 65 - 100 psig
500 MF	14" - 28" w.c.	6" - 12" w.c.	75 - 100 psig	14.5 scfm @ 65 - 100 psig

*Figures are for complete burners only and are taken at the valve train inlets.

Pressure Settings

Burner Catalog Number	A		B		C		D
	Combustion Air Pressure		Natural Gas Pressure, 0.65 sp. gr.	Propane Pressure, 1.52 sp. gr.	Atomizing Air Pressure		Oil Landing Pressure
	Low Fire	High Fire	High Fire	High Fire	Low Fire	High Fire	High Fire
100 MF	0.2" w.c.	7.3" w.c.	6.4" w.c.	2.6" w.c.	20 psig	45 psig	50 psig
200 MF	0.15" w.c.	5.5" w.c.	12.0" w.c.	4.8" w.c.	20 psig	45 psig	50 psig
300 MF	0.2" w.c.	6.0" w.c.	5.8" w.c.	2.3" w.c.	10 psig	45 psig	50 psig
500 MF	0.2" w.c.	6.0" w.c.	4.6" w.c.	1.8" w.c.	20 psig	45 psig	50 psig

NOTE: All above pressure settings are approximate. For actual settings, refer to the tags supplied with the burner.

Initial Lightoff

1. The burner has been test fired and adjusted at the factory. If duct suction/pressure varies no more than 0.5" w.c. from neutral, no further adjustments should be required to put the burner in operation.
2. On a new installation, the gas pipe line usually requires some purging to remove trapped air from the gas line. On a new installation it is recommended that the oil pipe line be bled before attempting a startup. This is to remove the foreign materials normally found in new systems.
3. Before attempting initial lightoff, refer to any instructions included with the control panel and familiarize yourself with the sequence of operation that is under control of the panel.
4. When observing the burner fuel and air controls, it should be noted that the control motor (air or electric) and the connected flow control valves (air, gas and oil) move through an arc of approximately 90°. The flow control valves are preset at the factory, however, the linkage can be readjusted to obtain the exact low and high fire capacities desired (see "Linkage Adjustment 100 and 200 MF" section or "Linkage Adjustment 300 and 500 MF" section).

Pilot Ignition

1. Read the control panel instructions and set the panel for the desired fuel.
2. Open the inlet lubricated plug cock and the adjustable orifice pilot cock.

3. Begin the ignition sequence on the control panel. Check for spark and opening of the pilot solenoid valve.
4. Several trials for ignition may be required if the piping was inadequately purged.
5. If, after several tries, ignition cannot be established with the pilot solenoid valve open and the spark present, it will be necessary to adjust the adjustable orifice pilot cock.
6. To adjust the pilot cock, remove the top screw and top screw washer. This gives access to the adjusting screw. Turn the adjusting screw "in" for less gas or "out" for more. Replace the washer and the top screw.

Main Flame Ignition

1. Once the pilot is established, open the gas cock (gas operation ONLY). The motorized gas valves or oil solenoid valves should open.
2. Check the gas or oil pressure and atomizing air pressure (oil ONLY) at low fire. If they are not the same as those on the test tags, adjustments will be necessary (see "Linkage Adjustment 100 and 200 MF" section or "Linkage Adjustment 300 and 500 MF" section).
3. Check the gas or oil pressure and atomizing air pressure (oil ONLY) at high fire. If they are not the same as those on the test tags, adjustments will be necessary (see "Linkage Adjustment - 100 and 200 MF" section or "Linkage Adjustment - 300 and 500 MF" section).
4. After all adjustments have been made, run the burner through its complete operating range, from full off to high fire, several times.

Adjustment, Start & Stop

4

Linkage Adjustment - 100 and 200 MF

1. The components involved in the linkage are as follows (see Figure 3.5): rod A and driven arm A transfer the motion of the control motor to the jackshaft; driving arm B, rod B and driven arm B1 transfer motion from the jackshaft to the combustion air butterfly valve; driving arm C, rod C and driven arm C1 transfer motion from the jackshaft to the gas butterfly valve; driving arm D, rod D and driven arm D1 transfer motion from the jackshaft to the oil metering valve.
2. All linkage arms move in an upward direction when going from low to high fire.
3. When adjusting linkage, start with the driving and driven arms approximately parallel to each other. (Does not apply to the gas butterfly valve. See Figure 3.6 for approximate position).
4. Lengthening the distance between the rotating center of the driving arm and the link connecting point on the driving arm will cause the driven arm to move through a larger angle. Shortening this distance will cause the driven arm to move through a smaller angle. Making these adjustments on the driven arm will reverse the results.
5. All linkage adjustments, including those which will alter the high fire rate, must be made with the burner at low fire. Care should be taken not to alter the low fire setting, as it serves as a constant reference point. Making an adjustment at the link connecting point **ONLY** will alter both the high and low firing rates. To maintain one firing rate while changing the other, the link and rod connecting points must both be loosened.
6. Adjust rod and arm A so that the jackshaft will rotate 90° as the control motor drives from low to high fire.

Combustion Air Flow Adjustment - 100 and 200 MF

1. Close the lubricated plug cock and the oil solenoid valves, set the control motor at low fire and start the combustion air blower.
2. Loosen the link and rod connecting points at arm B1, set the butterfly valve to give a differential pressure between the burner windbox and the firing chamber of approximately 0.25" w.c. (low fire).
3. Tighten the loose connecting points.
4. Drive the control motor to high fire. The differential pressure should be 6" w.c. If it is not, return to low fire, loosen the link and rod connecting points at either arm B or B1 and move the link connecting point in the appropriate direction (see step 4 under "Linkage Adjustment - 100 and 200 MF" above) without moving arms B and B1 or changing the low fire air flow rate.
5. Tighten the loose connecting points and recheck the high fire differential pressure. Once the burner is firing, it may be necessary to readjust the air flow slightly.




Figure 3.1. 100 and 200 MF

Linkage Adjustment - 300 and 500 MF

1. The components involved in the linkage are as follows (see Figure 3.5): rod A and driven arm A transfer the motion of the control motor to butterfly shaft B; driving arm C, rod C and driven arm C1 transfer motion from butterfly shaft B to the gas butterfly valve; driving arm D, rod D and driven arm D1 transfer motion from butterfly shaft B to the oil metering valve.
2. All linkage arms move in an upward direction when going from low to high fire.
3. When adjusting linkage, start with the driving and driven arms approximately parallel to each other.
4. Lengthening the distance between the rotating center of the driving arm and the link connecting point on the driving arm will cause the driven arm to move through a larger angle. Shortening this distance will cause the driven arm to move through a smaller angle. Making these adjustments on the driven arm will reverse the results.
5. All linkage adjustments, including those which will alter the high fire rate, must be made with the burner at low fire. Care should be taken not to alter the low fire setting, as it serves as a constant reference point. Making an adjustment at the link connecting point ONLY will alter both the high and low firing rates. To maintain one firing rate while changing the other, the link and rod connecting points must both be loosened.

Combustion Air Flow Adjustment - 300 and 500 MF

1. Close the lubricated plug cock and the oil solenoid valves, set the control motor at low fire and start the combustion air blower.
2. Loosen the link and rod connecting points at arm A and the shaft connecting points for arms C and D, and set the butterfly valve to give a differential pressure between the burner windbox and the firing chamber of approximately 0.25" w.c. (low fire).
3. Tighten the loose connecting points.
4. Drive the control motor to high fire. The differential pressure should be 6" w.c. If it is not, return to low fire, loosen the link and rod connecting points at arm A and move the link connecting point in the appropriate direction (see step 4 under "Linkage Adjustment - 100 and 200 MF" above) without moving arm A or changing the low fire flow rate.
5. Tighten the loose connecting points and recheck the high fire differential pressure. Once the burner is firing, it may be necessary to readjust the air flow slightly.




Figure 3.2. 300 and 500 MF

Gas Flow Adjustment - all models

1. Make sure the burner is in the gas operation mode. Refer back to the Initial Lightoff section above, light the burner and set the control motor for low fire.
2. If the butterfly valve does not go to the full "off" position or it is at full "off" and there is not sufficient leakage past the butterfly to maintain a stable low fire, loosen the link and rod connecting points at arm C1 and move arm C1 in the appropriate direction (see step 4 under "Linkage Adjustment - 100 and 200 MF" above).
3. Tighten the loose connecting points.
4. Drive the control motor to high fire. If the gas pressure is not within 1/2" w.c. of that indicated on the test tag, adjust the gas pressure regulator to give the required pressure.
5. If the required high fire pressure cannot be achieved by adjusting the regulator, return to low fire, loosen the link and rod connecting points at either arm C or C1, and move the connecting point in the appropriate direction (see step 4 under "Linkage Adjustment - 100 and 200 MF" above) without moving arms C and C1 or changing the low fire flow rate.
6. Tighten the loose connecting points and recheck the gas pressure at high fire.

Oil Flow Adjustment - all models

1. Set the oil pressure regulator for a static output of 60 - 65 psig. Set the atomizing air filter regulator for a static output pressure of 55 psig.
2. Make sure the burner is in the oil operation mode. Refer back to the Initial Lightoff section above, light the burner and set the control motor for low fire.
3. Read the low fire atomizing air pressure at the nozzle gauge. If it is not the same as on the test tag, adjust it using the screw on top of the atomizing air proportioning regulator. Be sure to tighten the locking nut after the adjustment is made.
4. Low fire oil pressure is adjusted by loosening the rod and link connecting points at arm D1 and moving arm D1 until the oil pressure is as indicated on the test tag. This pressure can be read at the loading line gauge on the atomizing air proportioning regulator.
5. Tighten the loose connecting points, drive the control motor to high fire and check the atomizing air pressure at the nozzle gauge. If it is as indicated on the test tag, proceed to the next step below, if it is not, adjust the atomizing air filter regulator.
6. If the oil pressure is not as indicated on the test tag, return to low fire, loosen the link and rod connecting points at either D or D1 and move the connecting point in the appropriate direction without moving arms D and D1 or changing the low fire oil pressure.
7. Tighten the loose connecting points and recheck the oil pressure at high fire.



Maintenance & Troubleshooting

5

1. Air, oil and compressed air filters must be cleaned routinely, depending on ambient conditions.
2. Fuel oil must be purchased from a dependable source and be free of impurities, and especially, free of sulfur.
3. Kerosene or hydro-treated oil may be required for the product being processed.
4. Linkage and valves must be lubricated and inspected to assure proper operation.
5. Flame monitoring equipment must be cycled, tested and understood.
6. Ignition system - spark plugs, transformer and lead wires - must be maintained in topnotch conditions.
7. Oil spills, leaks, etc. must be cleaned up - just good housekeeping.
8. Fuel oil piping must be tight, air must be purged from the system, and the oil must be filtered.
9. Compressed air must be of sufficient quantity, DRY, and free of oil and dirt. Air pressure should be steady so it doesn't affect any of the burner controls.

- If there is a large amount of water present at a burner, this can be reduced considerably by putting an air/oil separator at each burner with an automatic water drain. The burners already have a filter with a visible bowl to remove the moisture but the amount of water in an air supply may exceed the ability of this filter regulation unit to remove the large quantity of water present. There are several makes of filters available that can be supplied with automatic water drains. This is strictly a stopgap or final filter ahead of the burner, and the least desirable solution.

- The preferred method is to remove the moisture from the air to a saturation point below the lowest expected temperature to which the air piping is likely to drop. For most piping in factories or mills, a temperature of 50°F should be low enough for this purpose. This degree of saturation can only be achieved with refrigeration-type air drying equipment.

Reducing the saturation point of air down to 50°F reduces the moisture down to 4.076 grains per cubic foot. This compares to 7.980 at 70°F. This is a very significant reduction in water content. Reducing the saturation point below 70°F is a very good improvement in removing water content from air lines.



Appendix

Conversion Factors

Metric to English

From	To	Multiply By
actual cubic meter/h (am ³ /h)	actual cubic foot/h (acfh)	35.31
normal cubic meter/h (Nm ³ /h)	standard cubic foot /h (scfh)	38.04
degrees Celsius (°C)	degrees Fahrenheit (°F)	(°C x 9/5) + 32
kilogram (kg)	pound (lb)	2.205
kilowatt (kW)	Btu/h	3415
meter (m)	foot (ft)	3.281
millibar (mbar)	inches water column ("w.c.)	0.402
millibar (mbar)	pounds/sq in (psi)	14.5 x 10 ⁻³
millimeter (mm)	inch (in)	3.94 x 10 ⁻²
MJ/Nm ³	Btu/ft ³ (standard)	26.86

Metric to Metric

From	To	Multiply By
kiloPascals (kPa)	millibar (mbar)	10
meter (m)	millimeter (mm)	1000
millibar (mbar)	kiloPascals (kPa)	0.1
millimeter (mm)	meter (m)	0.001

English to Metric

From	To	Multiply By
actual cubic foot/h (acfh)	actual cubic meter/h (am ³ /h)	2.832 x 10 ⁻²
standard cubic foot /h (scfh)	normal cubic meter/h (Nm ³ /h)	2.629 x 10 ⁻²
degrees Fahrenheit (°F)	degrees Celsius (°C)	(°F - 32) x 5/9
pound (lb)	kilogram (kg)	0.454
Btu/h	kilowatt (kW)	0.293 x 10 ⁻³
foot (ft)	meter (m)	0.3048
inches water column ("w.c.)	millibar (mbar)	2.489
pounds/sq in (psi)	millibar (mbar)	68.95
inch (in)	millimeter (mm)	25.4
Btu/ft ³ (standard)	MJ/Nm ³	37.2 x 10 ⁻³

