




PARTS LIST

IPG GAS PILOT BURNERS WITH SOLENOID VALVES 1400 SERIES – 5400 SERIES




Key No.	Description	Series	Pilot Size			
			1	2	3	
1	Pilot Assembly, A-21	1400	12790		12792	
	Pilot Assembly, NM 200	2400	41177		---	
	Pilot Assembly, A-20	5400	30337		---	
1A	Nozzle Assembly	1400	42905		C	---
		2400	42905		O	30334
		5400	42906		N	32976
1B	Sparkplug Assembly	1400	13283x001		S	---
		2400	41068		U	30333
		5400	13283x003		L	32968x001
			---		T	---
2	Flexible Pipe Nipple	---	14341	H	14342	
			13724	A	13726	
			41693	U	41694	
			54971	C	54971	
			15796	K	15796	
			20433	---	20433	
			---	---	---	
			---	---	---	
			---	---	---	
			---	---	---	
---	---	---				

This page left intentionally blank.



**IPG GAS PILOT BURNERS
LESS SOLENOID VALVES
1400 SERIES – 5400 SERIES**



Y2848
(NOT TO SCALE)

Key No.	Description	Series	Pilot Size		
			1	2	3
1	Pilot Assembly, A-21	1400	12790	C	12792
	Pilot Assembly, NM 200	2400	41177	O	---
	Pilot Assembly, A-20	5400	30337	N	30334
1A	Nozzle Assembly	1400	42905	S	32976
		2400	42905	U	---
		5400	42906	L	30333
1B	Sparkplug Assembly	1400	13283x001	T	32968x001
		2400	41068	---	---
		5400	13283x003	H	32968x002
2	Flexible Pipe Nipple		14341	A	14342
3	Mixer Assembly		13724	U	13726
4	Ball Valve		41693	C	41694
5	Gas Regulator		54971	K	54971

This page left intentionally blank.