

Assembly Numbers

For these products, please order per the following product numbers:
(configured products are those with alphanumeric text)

RAMFIRE® Burners	Series "G" Gas only			
	1.5"	2"	3"	4"
Complete Burner Assemblies	0150 RF	0200 RF	0300 RF	0400 RF

Segment choices are as follows for *configured* products:

- Air Connection Type
- Gas Connection Type
- Pilot Orifice
- Flame Detection
- Block Material
- Seal and Support
- Mounting Ring
- Mounting Ring Gasket
- Test Connection Kit (Combustion Air)
- Test Connection Kit (Fuel)
- Backplate Connection

Spare Parts for RAMFIRE® Burners

RAMFIRE® Burners		1.5"	2"	3"	4"
Complete Burner Assemblies		0150 RF	0200 RF	0300 RF	0400 RF
Spare Parts & Accessory Items	Mounting plate (A) [1]	34237		34238	34239
	Mounting plate gasket (A) [1]	34391		34392	34393
	Pilot gas adjustable orifice (A/R)	50431			
	1/8" test connection kit (A)	34137			
	Gas swing check valve (size) C _v flow (A)*	35618 (3/4") C _v = 21.2	35619 (1") C _v = 34	---	---
	Series "BV" balancing valves (size) C _v flow (A)*	For air	19122 (1-1/2") C _v = 80	19123 (2") C _v = 138	---
For gas		19119 (3/4") C _v = 11	19120 (1") C _v = 18	---	---
Replacement & Spare Parts	Spark ignitor sub-assembly includes rubber cover (R)	34042		39782	
	Rubber cover (R)	18722			
	Observation glass (R)	19284			
Replacement Burner Block & Sleeve Sub-Assemblies	Standard block with C.S. sleeve (R)	33853	33855	33857	33859
	Standard block with S.S. sleeve (R)	33854	33856	33858	33860

[1] Mounting plates and gaskets are required options. Mounting plate is normally welded in place at assembly to give desired block placement relative to inner firing chamber wall. If you do not specify a desired mounting plate location, it will be shipped "loose," requiring welding at installation.

*Must be ordered as loose items