Veri-Flame Part Number Denotation

VF560 □ □ □ □ □

Reset Mode
A = Normal, Auto Reset on Power Up
B = Manual, Requires Push-button reset on power up
(Discontinued Feature)

Air Switch Input Mode
A = Normal, pre-purge failure if switch is not made after 10s
X = Sequence Hold, purge cycle is stopped until switch makes
(Not Available on All Models)

Sensor Type
2 = UV Scanner model
3 = Flame Rod model
7 = IR or Solid State UV/IR model (Discontinued Model)

Purge Cycle
2 = Purge model with 4 LEDs
3 = No-Purge model with 3 LEDs
4 = Modulation model with 7 LEDs

Power Supply and TFI (Trial for Ignition)
2 = 120VAC, 5 or 10s
3 = 230VAC, 5 or 10s
5 = 120VAC, 10 or 15s

ECLIPSE®
Innovative Thermal Solutions