Burner Application Details Packaged Versions

CYCLOMAX® Burners were designed for low to moderate temperature oven-type applications only. They may be used in any oven whose combustion chamber temperature is 800°F (427°C) or less.

NOTE: CYCLOMAX [®] Burners should not be used in any application where there is a static (no moving air) condition.

Packaged CYCLOMAX® Burners include a low horsepower combustion air blower in your choice of the voltages listed below.

| Packaged CYCLOMAX® Burner Model | 0.4M | 0.8M | 1.6M | 2.7M | 3.7M |
|---------------------------------------|--------|--------|--------|------|------|
| Horsepower | 1/2 HP | 1/2 HP | 3/4 HP | 2 HP | 3 HP |
| 208-230/460/3/60 | 1/2 HP | 1/2 HP | 3/4 HP | 2 HP | 3 HP |
| 575/3/60 | 1/2 HP | 1/2 HP | 3/4 HP | 2 HP | 3 HP |

IMPORTANT: The combustion air blower must be in operation any time the air stream temperature is above 200°F (93°C). If not, damage to the blower, burner and piping is possible.

To adjust the Packaged burner, set the gas pressure according to the values shown in the table below. During adjustment, observe the flame if possible. The flame should be blue and it should be totally contained inside the combustion sleeve, especially at low firing rates. Blue flame outside of the combustion sleeve is caused by combustion that is either too rich or too lean and will result in high levels of CO. Yellow or orange flames are normally an indicator of a too-rich flame. Higher oven suction will require higher gas pressure to the burner for optimum performance. Higher back pressure will require less gas pressure to the burner for optimum performance. The values listed in the table below are for a near balanced condition.

IMPORTANT: The pilot must be interrupted in order to obtain the emissions listed in the following table. Continuous pilot is not recommended.

Packaged CYCLOMAX® – Natural Gas Capacities and Specifications (60 Hz)

| Burner Size | 0.4M | 0.8M | 1.6M | 2.7M | 3.7M | |
|--------------------------------------|------------|------------|------------|------------|------------|--|
| Recommended Gas Pressure "w.c. | 15.5 | 11.5 | 14.2 | 11.0 | 10.0 | |
| Maximum Capacity (1000's Btu/hr) | 425 | 850 | 1600 | 2700 | 3700 | |
| Minimum Capacity (1000's Btu/hr) | 30 - 45 | 56 - 70 | 107 - 133 | 180 - 225 | 247 - 308 | |
| Pilot Capacity (1000's Btu/hr) | 15 - 35 | 60 - 70 | 50 - 100 | 70 - 150 | 100 - 150 | |
| Turndown | Up to 10:1 | Up to 10:1 | Up to 15:1 | Up to 15:1 | Up to 15:1 | |
| Emission Turndown based on high fire | 15:1 | 15:1 | 3.5:1 | 6:1 | 4:1 | |
| Maximum Air Pressure "w.c. | 5.5 | 5 | 5 | 8 | 8 | |
| Air Flow SCFM (Maximum) | 105 | 210 | 400 | 670 | 930 | |
| NOx (corrected to 3% oxygen) | 25 | 25 | 25 | 25 | 25 | |
| CO (corrected to 3% oxygen) | 75 | 75 | 75 | 75 | 75 | |
| Sound Level (without silencer) dB(A) | 83 - 89 | 83 - 89 | 83 - 89 | 86 - 90 | 86 - 90 | |
| Flame Length (ft) | 0.5 | 0.5 | 1.0 | 2.0 | 1.5 | |

NOTE: On the packaged unit, gas pressure is measured at the pressure tap on the gas valve body (not the backplate). The backplate pressure tap is for the EBMRV version.

Burner Application Details EBMRV Versions

Maxon CYCLOMAX® Burners are available in four external blower versions. By using the specified external blower, it is possible to double the capacity of the burner over the Packaged version. Emissions are similar to the burner operating with a packaged fan. With the EBMRV versions, there is slightly more flame outside of the can and this makes the burner more sensitive to cross velocity.

The external blower versions are very similar to the packaged versions except they do not include gas or air internal control devices. A threaded EB Air Adapter allows the MICRO-RATIO® Valve to be mounted.

The recommended (minimum) FG Blower is shown in the chart below. If you use a butterfly style gas valve on the MICRO-RATIO® Valve, turndown could be affected. Poppet style gas valves should be used. If your air piping is unusually long and/or contains many fittings, please review your blower size to compensate for higher pressure drops through the air

piping. Set the MICRO-RATIO® Valve to obtain the gas and air pressures shown on the graphs on pages 2805 - 2808. The following table lists the recommended MICRO-RATIO® Valve and FG Blower selections.

The values in the table below are guidelines. To meet your capacity and turndown needs, pressures must be set to match the graphs on pages 2805 - 2808.

IMPORTANT: The EBMRV versions, like the packaged versions, should be operated with interrupted pilot. Emissions can be 20% higher if the pilot is left on continuously and combustion sleeve life is reduced.

IMPORTANT: Whenever the combustion chamber temperature is above 200°F (93°C), air should be flowing through the burner. If not, damage to gaskets in the burner could result and increase the chance for leaks.


| Burner Size | EB2MRV CM | EB3MRV CM | EB4MRV CM | EB5MRV CM | | |
|-------------------------------|-------------|---------------|---------------|---------------|--|--|
| Maximum Capacity (Btu/hr) | 1,600,000 | 3,200,000 | 5,400,000 | 7,400,000 | | |
| MICRO-RATIO® Valve | 1"-P x M-3" | 1.5"-P x M-4" | 2.5"-P x M-6" | 2.5"-P x M-6" | | |
| Minimum FG Blower Recommended | C-2370-16 | C-4520-16 | C-9180-24 | C-11220-24 | | |


CYCLOMAX® EB Versions – Natural Gas Capacities and Specification (60 Hz)

| OTOLOMAX EB Versions (Valuation Gus Supulation and Openinoation (Gu 112) | | | | | | | | | | | |
|--|---|---|--|--|--|--|--|--|--|--|--|
| EB2MRV CM | EB3MRV CM | EB4MRV CM | EB5MRV CM | | | | | | | | |
| 1,600,000 | 3,200,000 | 5,400,000 | 7,400,000 | | | | | | | | |
| 100,000 | 180,000 | 200,000 | 180,000 | | | | | | | | |
| 100,000 | 150,000 | 180,000 | 200,000 | | | | | | | | |
| 34 | 40 | 38.5 | 35.5 | | | | | | | | |
| 15 | 15 | 28.5 | 30 | | | | | | | | |
| 15:1 | 15:1 | 15:1 | 15:1 | | | | | | | | |
| 15:1 | 13:1 | 15:1 | 12:1 | | | | | | | | |
| 400 | 800 | 1350 | 1850 | | | | | | | | |
| 1.5 to 2 | 2 to 3 | 2 to 2.5 | 2.5 to 3.5 | | | | | | | | |
| <25 | <25 | <25 | <25 | | | | | | | | |
| <75 | <75 | <75 | <75 | | | | | | | | |
| <25 | <25 | <25 | <25 | | | | | | | | |
| <100 | <100 | <200 | <100 | | | | | | | | |
| 1.0 | 1.5 | 2.0 | 1.5 | | | | | | | | |
| | 1,600,000 1,000,000 100,000 34 15 15:1 400 1.5 to 2 <25 <75 <25 <100 | EB2MRV CM EB3MRV CM 1,600,000 3,200,000 100,000 180,000 100,000 150,000 34 40 15 15 15:1 15:1 400 800 1.5 to 2 2 to 3 <25 | EB2MRV CM EB3MRV CM EB4MRV CM 1,600,000 3,200,000 5,400,000 100,000 180,000 200,000 100,000 150,000 180,000 34 40 38.5 15 15 28.5 15:1 15:1 15:1 400 800 1350 1.5 to 2 2 to 3 2 to 2.5 <25 | | | | | | | | |


NOTE: Operation above the recommended gas pressure for a given air pressure will result in higher NOx and lower CO. Operation below the recommended gas pressure curves will result in lower NOx and higher CO. Use of propane as a fuel will result in higher emissions. Oven cross velocities and back pressures have a slight affect on the optimum pressures to set.

EB2MRV - Natural Gas







EB3MRV - Natural Gas





EB3MRV - Propane






EB4MRV - Propane






EB5MRV - Propane



Dimensions (in inches)

Dimensions – Packaged Versions




Dimensions (in inches)

| Burner Size | Α | В | С | D | E | F | G | Н | J | К | L | М | N NPT | Р | R | s | Т |
|-------------|-------|------|------|-------|-------|-------|-------|------|-------|-------|------|-------|----------|------|-------|-------|-------|
| 0.4M | 10.03 | 3.06 | 6.32 | 13.66 | 8.90 | 19.88 | 13.47 | 2.66 | 4.65 | 26.95 | 7.03 | 9.88 | 1" | .937 | 10.3 | 20.27 | 11.82 |
| 0.8M | 10.03 | 3.06 | 6.32 | 13.66 | 8.90 | 19.88 | 13.47 | 2.66 | 4.65 | 26.95 | 7.03 | 9.88 | 1" | .937 | 10.3 | 20.27 | 11.82 |
| 1.6M | 10.03 | 3.06 | 6.32 | 13.66 | 8.90 | 19.88 | 13.47 | 2.66 | 4.65 | 26.95 | 7.03 | 9.88 | 1" | .937 | 10.3 | 20.27 | 11.82 |
| 2.7M | 13.02 | 3.40 | 7.73 | 16.5 | 11.72 | 18.47 | 20.21 | 3.67 | 11.64 | 34.0 | 9.03 | 14.12 | 1-1/4" | .930 | 13.25 | 27.52 | 16.38 |
| 3.7M | 13.02 | 3.40 | 7.73 | 16.5 | 11.72 | 28.57 | 20.21 | 3.67 | 11.64 | 34.0 | 9.03 | 14.12 | 1-1/2" | .930 | 13.25 | 27.52 | 16.38 |

Dimensions (in inches)

Dimensions - EBMRV Version

EB2MRV & EB3MRV



EB4MRV & EB5MRV 6" NPT Combustion Air Inlet 3.38 15.32 1/4" NPT Air Pressure **Test Connection** 2" NPT 0.93 Main Gas Inlet 10.88 4.199 16.48 dia. 11.72 dia. 13.25 dia. 1/4" NPT Port **Gas Pressure Test Connection D** Pilot Gas 3/8" NPT Spark Ignitor 1/2" NPT -√-22.0-7.73 rad. Spark Ignitor -0.38 Removal Clearance 5/8" (.625) dia. 22° Scanner 3/4" NPT Burner Mtg. Holes 8 holes equally spaced

Dimension "A" 18.47 for EB4MRV 28.57 for EB5MRV