

# Choose the configuration that's right for your system.

		Panel Options		
		LED Indicator Lights	LCD Touchscreen Display	DCS Integration
		No display, has buttons and indicator lights	Display only, easy-to-use interface	Plain panel, connects through system
Features		1-5 Valve Systems	1-9 Valve Systems	1-9 Valves Systems
CONFIGURATION	Partial Stroke Test verification of test pass/fail	•	•	•
	Data logging		•	
	Valve degradation error detection		•	•
	Export of valve trending information		•	
RATING	SIL 2		Optional	Optional
	Class I Division 1 (Z-Purge via pressurized panel)		Special Order	Special Order
	Class I Division 2		Optional	Optional
	General purpose Type 12 enclosure	Optional	Optional	Optional
	Type 4x enclosure	Optional	Optional	Optional
SOFTWARE	Date valve built (manufacturer setting)	Factory set	Factory set	
	Date valve is installed and commissioned	Factory set	•	
	Valve identification/location		•	
	Trending of valve performance		•	
	Compare valve historical trending data		•	
	View alarm history		•	
	Manual test	Keyed access	•	•
	Automatically run partial stroke tests	•	•	•
	Set frequency of test	Factory set	•	
	Set limits on hard and soft alarms		•	
User authorization	Keyed access	•		
SPECIALS	Panel heater	Special Order	Special Order	Special Order
	Panel cooler	Special Order	Special Order	Special Order
	Pressure transducer - air line pressure measurement		Special Order	Special Order
HARDWARE PANEL ADD-ON	Inlet panel voltage options:	24VDC, 110-240VAC or 24VAC	24VDC, 110-240VAC or 24VAC	24VDC, 110-240VAC or 24VAC
	Communications options - • Ethernet • Modbus 1761-NET • Modbus AIC+ • Non-safety communications		•	•

## Panel Sizes

### Non-SIL, Type 12, Type 4X panel sizes:

1-2 Valve Systems	20"H x 20"W x 8"D
3-5 Valve Systems	24"H x 24"W x 8"D
6-9 Valve Systems	36"H x 30"W x 10"D

### SIL, Type 4X panel size:

1-9 Valve Systems	36"H x 36"W x 12"D
-------------------	--------------------

## Explanation of features

### CONFIGURATION

**Partial Stroke Test verification of test pass/fail** – The partial stroke test can be run manually or automatically at pre-set times. Depending on the system capabilities, the valve's health status will be conveyed either by LED indicator lights on the panel, via an icon on the touch screen display, or via direct communication to the DCS.

**Data logging** – Valve health trending data is captured in non-volatile microprocessor memory and will retain all of the valve health information for up to 10 years or longer dependent on how many times a year the valve partial stroke test is run.

**Valve degradation error detection** – Tests performed by MAXON PSCHECK systems will identify a soft or hard failure (on the 8000 pneumatic SSOV) by checking the amount of time required for the valve to 'trip', signaling a capability to either open or close. The longer time it takes to trip the valve indicates potential performance issues. If the valve is degrading it will signal a soft failure alert, if the valve fails it will indicate a failure.

**Export of valve trending information** – It is simple to export the valve health trending data via a supplied Compact Flash (CF) drive. The information is presented in a .CSV format that can be modified for analysis, audits, and for presentation to regulatory or insurance authorities.

### SOFTWARE

**Date valve built** – A factory build date will be established in permanent memory.

**Date valve installed and commissioned** – During the commissioning process, the customer will be required to set the date the system is installed which will also establish the base line for the valve's health.

**Valve identification/location** – The customer has the ability to set a custom number for each valve to help identify its location.

**Trending of valve performance** – Diagnostics captures the valve testing information and tracks the overall health of the 8000 pneumatic safety shut-off valve by plotting this information on a touch screen display showing the valves health trending over the life of the valve. This trending information or predictive

indicator shows a linear relationship between the initial installation health data vs. the degradation of the valve's performance over the life of the valve. This trending data is used to indicate when the valve may require maintenance, replacement or that it will potentially fail.

**Compare valve historical trending data** – Ability to switch between three different screens changing the number of captured data points enabling better short and long term viewing of the trending information.

**View alarm history** – Captures all alarms, the dates of the alarms, and valve testing information when either a soft 'alert' alarm or a hard 'failure' alarm is triggered. The system will track all alarm instances over the life of the valve.

**Manual test** – Ability to start an immediate manual test on the valves by pushing a button on the panel, an icon on the touch screen display or initiated via the DCS dependent on the configuration ordered. The test will return immediate results on the valve's performance and will not interfere with any pre-set automatic tests nor will it interfere with any of the valve or burner management functions.

**Automatic test** – The unit will ship from factory with all systems pre-set to a monthly partial stroke test schedule. In systems with the touch screen display or via DCS connection, the customer will have the option to change the frequency of the test timing to daily, weekly, monthly, quarterly, bi-annually, annually or a custom set test rate.

**Set limits on hard and soft alarms** – The unit will ship with factory set limits on when a hard or soft alarm will trigger indicating that the valve's performance is degrading and maintenance should be scheduled or that the valve has failed the test. Both can be changed by the customer during the commissioning process or at a later date. These limits can be increased meaning the valve will run longer without any warnings or alerts, or can be lowered meaning the system will alarm out, indicating the valve's degradation sooner.

**User authorization** – For systems with a touch screen display, enables password protected access to limit who can modify the settings and to limit general access to the trending and tracking information. For manual units with LED indicator lights, a key is provided to conduct a manual test.

**Safety First.  
Efficiency First.  
Success First.**



**Commercial & Industrial Combustion (C&I)**

Honeywell  
**MUNCIE, INDIANA, USA**  
 Maxon  
 201 East 18th Street  
 P.O. Box 2068  
 Muncie, IN 47307-0068  
 Tel: 765.284.3304  
 Fax: 765.286.8394  
**GOLDEN VALLEY, MINNESOTA, USA**  
 Honeywell Automation and Control Solutions  
 1985 Douglas Drive North  
 Golden Valley, MN 55422-3992  
 www.honeywell.com

**Canada Sales Office**  
**TORONTO**  
 Maxon Industrial Equipment  
 3333 Unity Drive  
 Mississauga, Ontario L5L 3S6  
 Tel: 800.489.4111  
 Fax: 855.262.0792

**European Sales Office**  
**BELGIUM**  
 Maxon International BVBA  
 Luchtlaan 16-18  
 1800 Vilvoorde, Belgium  
 Tel: 32.2.255.09.09  
 Fax: 32.2.251.82.41

**Asia/Pacific Sales Office**  
**SINGAPORE**  
 Maxon  
 17 Changi Business Park  
 Central 1  
 Singapore 486073  
 Tel: 65.6580.3358  
 Fax: 65.6580.3345

**China Sales Office**  
**SHANGHAI**  
 Maxon Combustion Equipment  
 (Shanghai) Co., Ltd.  
 1st Floor & Section A, 4th Floor  
 225 Weisheng Road  
 Wai Gao Qiao Free Trade Zone  
 Pudong New Area  
 Shanghai 200131, P.R. China  
 Tel: 86.21.5868.1166  
 Fax: 86.21.5868.1569

**India Sales Office**  
**PUNE**  
 Maxon  
 53, 54, 56, 57 Hadapsar Industrial Estate  
 Environmental & Combustion Controls  
 Sapphire Building 2nd floor, A wing  
 Pune, 411013, India  
 Tel: 91.98.5090.7894  
 Tel: 91.20.6600.8530  
 Tel: 91.20.6600.8509  
 Fax: 91-20-66039979

Sales Offices &  
 Representatives Worldwide  
**www.maxoncorp.com**  
**customer.honeywell.com**

02-00019 PR  
 July 2014  
 © 2014 Honeywell International Inc.

**MAXON PSCHECK™**  
 Partial Stroke Technology with Series 8000 Pneumatic Safety Shut-off Valve



**Selection Guide**

Follow us on Twitter:  
 @honeywellpro

YouTube:  
 @honeywellpro

**Honeywell**